



NVIDIA Firmware Tools (MFT) Documentation v4.34.0

Table of contents

Release Notes	6
General Information	6
Dependencies	11
Supported Operating Systems and Platforms	11
Supported Flash Types	18
Supported NVIDIA Devices	19
Supported Adapter Cards Firmware Versions	20
Supported Switch Systems Software	20
Changes and New Features	20
Customer Affecting Changes	21
Declared Unsupported Features	22
MFT Bug Fixes in this Version	22
MFT Known Issues	23
User Manual	32
Access to Hardware Devices	33
Compilation and Installation	37
Firmware Generation, Configuration, and Update Tools	39
mst Service	40
Linux	40
Running mst in an Environment without a Kernel	46
Windows	47
FreeBSD	50
VMware ESXi	52
MFT Configuration	54
mlxfwmanager – Firmware Update and Query Tool	54

Updating the Device	64
UPMF	71
UPMF Generation Flow	72
Updating Firmware Using an UPMF	76
mlxarchive – Binary Files Compression Tool	77
mlxconfig – Changing Device Configuration Tool	79
Examples of mlxconfig Usage	84
Using mlxconfig	89
mlxconfig Commands	104
MFT Supported Configurations and Parameters	110
flint – Firmware Burning Tool	111
Burning a Firmware Image	119
Querying the Firmware Image	133
Verifying the Firmware Image	135
Performing Checksum Calculation on Image/Device	137
Managing an Expansion ROM Image	137
Setting GUIDs and MACs	139
Setting the VSD	151
Disabling/Enabling Access to the Hardware	152
Flash Operations	153
Firmware Timestamping for Multi-Host Environment	156
flint/mlxburn Limitations	159
Secure Host	159
Secure Firmware Update	164
Burning/Querying a Component	168
mlxburn – Firmware Image Generator and Burner	169
mlxfwreset – Loading Firmware on 5th Generation Devices Tool	175
mlxphyburn – Burning Tool for Externally Managed PHY	182
mlx_fpga – Burning and Debugging Tool for NVIDIA Devices with FPGA	184
cpldupdate – Tool for Programming On-Board CPLDs on NVIDIA Devices	190

mlxprivhost - NIC Configuration by the Host Restriction Tool (Zero Trust Mode)	192
mlxtokengenerator - Token Creation Tool	195
mlxdpa – DPA Applications Sign Tool	197
mlxcableimgen - Cable Firmware Image Wrapper Generation Tool	201
nvredfish	202
Debug Utilities	203
fwtrace Utility	204
mlxtrace Utility	208
mlxptrace Utility	211
mstdump Utility	213
mlx2c Utility	214
i2c Utility	215
mget_temp Utility	217
mlxdump Utility	218
mlxmcg Utility	221
pckt_drop Utility	224
mlxuptime Utility	224
wqdump Utility	225
mlxmdio Utility	231
mlxreg Utility	234
mlxlink Utility	239
mlxfwstress Utility	272
resourcedump Utility	290
resourceparse Utility	295
stedump Utility	302
Cable Utilities	309
Working with Cables	312

mlx cables - Cables Tool	313
MTUSB Cable Board	321
Cable Firmware Upgrade with Live-Patch	322
Troubleshooting	325
Appendixes	331
Assigning PSID	332
Remote Access to NVIDIA Devices	333
Booting HCA Device in Livefish Mode	346
Burning a New Device	348
Connect-IB Adapter Card	348
ConnectX-4 onwards Adapter Cards Family	353
Spectrum or Switch-IB 2 Switch Systems	357
Switch-IB Switch System	361
Generating Firmware Secure and NV LifeCycle Configurations Files	365
Updating Firmware Using ethtool/devlink and .mfa2 File	366
Using MFT tools on Secured GPU Devices	370
ESXi	370
Document Revision History	376
Release Notes Revision History	376
MFT Release Notes Change Log History	376
MFT Bug Fixes History	383
User Manual Revision History	388
Document Conventions and Related Documents	391
Legal Notices and 3rd Party Licenses	393

Overview

The NVIDIA® Firmware Tools (MFT) package is a set of firmware management and debug tools for NVIDIA devices. The document describes MFT features, tools content and configuration.

The documentation here relates to:

- [Release Notes](#)
- [User Manual](#)

Intended Audience

This manual is intended for system administrators responsible for managing and debugging firmware for NVIDIA devices.

See also [Document Conventions and Related Documents](#).

Software Download

To download product software, please refer to the [Firmware Tools \(MFT\)](#) product page.

Document Revision History

A list of the changes made to the user manual are provided in [User Manual Revision History](#).

Release Notes

These are the release notes for NVIDIA® Firmware Tools (MFT). MFT supports the following operating systems: Linux, Windows, VMware ESXi and FreeBSD. Please see the supported platform table for further details.

The tools functionality is identical in all operating systems unless otherwise noted.

Release Notes Update History

Revision	Date	Description
4.34.0-145	November 10, 2025	Initial release of this Release Notes version. This version introduces Bug Fixes .

General Information

Package Tools

The following is a list of the available tools in the package, together with a brief description of each tool. The tools apply to single switch systems or adapter cards.

Note

Please note that running MFT tools in parallel or simultaneously on the same device is not supported and might cause unexpected behavior.

The MFT tools do not provide cluster wide functionality.

Category	Tool	Description	Operating System
MST Service	mst	- Lists the available mst devices - Start/stop the register access driver for Linux and VMware ESXi OSs.	All
Firmware Update and Configuration	mlxburn	This tool provides the following functions: - Generating a standard or customized firmware image for burning in .bin format - Burning an image to the Flash attached to an HCA or switch device - Querying the firmware version loaded on a device - Displaying the Vital Product Data (VPD) of a network adapter	All
	flint	This tool burns a firmware binary image or an expansion ROM image to the Flash of a network adapter/ switch device. It includes query functions to the burnt firmware image and to the binary image file.	All
	mlxconfig	Allows the user to change some of the device configurations without having to create and burn a new firmware.	All
	mlxfwmanager	The mlxfwmanager is a firmware update and query utility. It provides a simple 'single click' firmware update functionality. Note: The same tool with embedded firmware binaries is released separately and is named mlxup.	All
	mlxarchive	The mlxarchive tool allows the user to create a file with the mfa2 extension. The new file contains several binary files of a given firmware for different adapter cards.	Linux Windows FreeBSD
	mlxphyburn	A tool for burning externally managed PHY	Linux
	mlx_fpga	A tool for burning and debugging devices with FPGA. It allows the user to burn their own hardware code on an FPGA integrated with HCA board. It also provides the user	Linux

Category	Tool	Description	Operating System
		with read/write registers in the QDR memory of the FPGA.	
	cpldupdate	A tool for programming on board CPLDs for NVIDIA devices for the OEM packages only.	Linux
Debug and Diagnostics Utilities	itrace	Extracts and prints trace messages generated by the firmware of a ConnectX-3 adapter cards.	All
	fwtrace	Extracts and prints trace messages generated by the firmware of 5th generation devices	Linux Windows FreeBSD
	mlxtrace	Dumps trace messages generated by the device hardware.	All
	mlxdump	Dumps device internal configuration registers. The dump file can be used by the Support team for hardware troubleshooting.	All
	mlxmcg	Displays the current multicast groups and flow steering rules configured in the device. Target users: Developers of Flow Steering aware applications.	All
	wqdump	Dumps the current QP contexts and Work Queues of ConnectX family network adapter cards and Connect-IB adapter cards.	All
	i2c	Generates an i2c transaction using an mtusb usb to i2c adapter or using the device internal i2c compatible master	Linux Windows FreeBSD
	mlx2c	Scans the i2c bus Routes the i2c bus of an externally managed Infiniscale/IV/SwitchX system to connect to the switch silicon.	Linux Windows
	mget_temp	Reads the hardware temperature from NVIDIA devices internal sensors and prints the reading in Celsius degrees.	All

Category	Tool	Description	Operating System
	pckt_drop	Corrupts the next transmitted packet from the ConnectX family network adapter cards and Connect-IB adapter cards.	All
	mlxuptime	Prints NVIDIA devices' up time and measured/configured core clock frequency	All
	mlxfwreset	Loads the firmware after firmware update on ISFU capable devices. (5th generation devices)	Linux Windows FreeBSD
	mlxmdio	Reads/writes MDIO registers (Clause 45) on boards with externally managed PHY	All
	mlxreg	Exposes supported access registers, and allows users to obtain information regarding the registers fields and attributes, and to set and get data with specific register.	All
	mstdump	Dumps device internal configuration data.	All
	mcra	Reads/writes a single word from/to a device configuration register space	All
	mlxcables	Reads/writes NVIDIA cable registers and queries the cables info	All
	mlxlink	Displays and configures port related data at the physical layer.	All
	mlxvpd	Reads PCI device VPD	All
	mlxprivhost	Enables the user to restrict the hosts from configuring the NIC.	Linux
	resourcedump	Extracts and prints data segments generated by the firmware.	Linux Windows
	resourceparse	Parses and prints data segments content.	Linux Windows
	stedump	A packet simulator for host NIC steering solutions.	Linux

Detailed installation instructions along with complete descriptions of the various tools in the package can be found in the Firmware Tools User Manual.

Software Dependencies

Software Package	Required Version
Linux	
Kernel sources	Machine's kernel version
DOCA-Host ^{1, 2}	1.5.0 or later
Perl	5.24 or later
Python ³	3.6 or later
lsusb ⁴	
rpmbuild	
xz ⁵	
Windows	
NVIDIA WinOF ⁶	3.0.0 or later
VMware ESXi	
Python	3.6 or later

Notes:

1. DOCA-Host can be downloaded from <http://www.openfabrics.org>. Note that installing DOCA-Host is *not* required if you wish to install MFT without In-Band capabilities.
2. For the 'mst ib add' command to run, one of the DOCA-Host packages "ibutils" or "ibutils2" or "infiniband-diags" should be installed and available in the PATH. (For details on DOCA-Host installation, visit <https://docs.nvidia.com/networking/category/mlnxofedib>.)
3. Required for the mlxmcg tool only.
4. Required for the mtusb device usage.
5. For creating UPMF (update package for NVIDIA firmware).
6. WinOF is required only for In-Band access. The package can be downloaded from the [WinOF](#) page..

7. Python 2.x is now end-of-life and no longer supported by MFT. To use the latest and up-to-date MFT tools, we recommend you use Python 3.x.

Dependencies

3rd Part MFT Dependencies

Component name	Component version name	Home Page	License names
JSON-CPP	0.6.0	https://github.com/open-source-parsers/jsoncpp	MIT License
OpenSSL	1.1.1l	http://www.openssl.org/	The Open SSL License
Perl	v5.32.0	http://www.perl.org/	Artistic License 1.0 (Perl)
SQLite	3.33.0	http://sqlite.org/	Public Domain
XZ Utils	5.0.4	http://tukaani.org/xz/	Public Domain
Curl	7.79.1	https://curl.se/	curl License
Iniparser	4.1	http://ndevilla.free.fr/iniparser	MIT License
Libexpat	2.4.1	http://www.libexpat.org/	MIT License
libxml2	2.9.10	http://www.xmlsoft.org/	MIT License
Zlib	1.2.11	http://www.zlib.net/	zlib License

Supported Operating Systems and Platforms

MFT is supported on the following platforms:

Table Legend:

+ (Green)	Supported and tested
** (Orange)	Supported but not tested

*** Blue	Partially tested
----------	------------------

Supported Operating Systems and Platforms

OS	Platform	Status
RH/ CentOS 8.2	x86_64	+
RH/ CentOS 8.2	PPC64LE	+
RH/ CentOS 8.4	PPC64LE	**
RH/ CentOS 8.4	x86_64	+
RH/ CentOS 8.6	x86_64	+
RH/ CentOS 8.6	PPC64LE	+
RH/ CentOS 8.8	x86_64	+
RH/ CentOS 8.8	PPC64LE	**
RH/ CentOS 8.8	ARM64	+
RH/ CentOS 8.9	x86_64	+
RH/ CentOS 8.9	PPC64LE	+
RH/ CentOS 8.9	ARM64	+
RH/ Rocky 9.0	x86_64	+
RH/ Rocky 9.0	PPC64LE	+
RH/ Rocky 9.1	x86_64	+
RH/ Rocky 9.1	PPC64LE	+
RH/ Rocky 9.2	x86_64	+
RH/ Rocky 9.2	PPC64LE	+
RH/ Rocky 9.2	ARM64	+
RH/ Rocky 9.3	x86_64	+
RH/ Rocky 9.3	PPC64LE	+
RH/ Rocky 9.3	ARM64	+
RH/ Rocky 9.4	x86_64	+
RH/ Rocky 9.4	PPC64LE	+
RH/ Rocky 9.4	ARM64	+

OS	Platform	Status
RH/ Rocky 9.5	x86_64	+
RH/ Rocky 9.5	PPC64LE	+
RH/ Rocky 9.5	ARM64	+
RH/ Rocky 9.6	x86_64	+
RH/ Rocky 9.6	PPC64LE	+
RH/ Rocky 9.6	ARM64	+
RH/ Rocky 10	x86_64	+
RH/ Rocky 10	PPC64LE	+
RH/ Rocky 10	ARM64	+
Centos Stream v8 - Community	x86_64	**
Centos Stream v8 - Community	PPC64LE	**
Centos Stream v9 - Community	x86_64	+
Centos Stream v9 - Community	ARM64	+
Centos Stream v9 - Community	PPC64LE	**
OEL 8.4	x86_64	+
OEL 8.6	x86_64	+
OEL 8.7	x86_64	+
OEL 8.8	x86_64	+
OEL 9.0	x86_64	+
OEL 9.1	x86_64	+
OEL 9.2	x86_64	+
OEL 9.5	x86_64	+
Fedora 32 - Community	x86_64	+
Fedora 35 - Community	x86_64	**
Sles15 SP2	x86_64	+
Sles15 SP2	PPC64LE	+
Sles15 SP3	PPC64LE	+
Sles15 SP3	x86_64	+

OS	Platform	Status
Sles15 SP4	PPC64LE	+
Sles15 SP4	x86_64	**
Sles15 SP5	PPC64LE	+
Sles15 SP5	x86_64	+
Sles15 SP6	PPC64LE	+
Sles15 SP6	x86_64	+
Sles15 SP7	x86_64	+
Sles15 SP7	PPC64LE	+
Sles15 SP7	ARM64	+
EulerOS V2.0 SP9 - Community	x86_64	**
EulerOS V2.0 SP10 - Community	x86_64	+
EulerOS V2.0 SP11	x86_64	+
EulerOS V2.0 SP12	x86_64	+
EulerOS V2.0 SP12	ARM64	+
OpenEuler 20.3 SP1 - Community	x86_64	**
OpenEuler 20.3 SP3	x86_64	+
OpenEuler 22.3 LTS	x86_64	+
OpenEuler 22.3 SP1	x86_64	+
Ubuntu 20.04	PPC64LE	+
Ubuntu 20.04	ARM64	+
Ubuntu 20.04	x86_64	+
Ubuntu 22.04	x86_64	+
Ubuntu 23.10	x86_64	+
Ubuntu 24.04	x86_64	+
Ubuntu 24.04	ARM64	+
Ubuntu 24.04	PPC64LE	**
Ubuntu 25.04	x86_64	+
BCLinux 21.10 SP2	x86_64	+

OS	Platform	Status
BCLinux 21.10 SP2	ARM64	**
BCLinux 22.10 SP2	x86_64	+
BCLinux 22.10 SP2	ARM64	+
Debian 10.8	x86_64	+
Debian 10.9	x86_64	+
Debian 10.13	x86_64	+
Debian 10.13	ARM64	+
Debian 11.3	ARM64	+
Debian 11.3	x86_64	+
Debian 12.1	x86_64	+
Debian 12.1	ARM64	+
Debian 12.5	x86_64	+
Debian 12.5	ARM64	+
Debian 13.0	x86_64	+
Debian 13.0	ARM64	+
Citrix server 8.2	x86_64	+
Anolis 8.4 - Community	x86_64	**
Anolis 8.6	x86_64	+
Anolis 8.6	ARM64	+
Korg 6.8	x86_64	+
Korg 6.8	ARM64	+
TKLinux 3.3	x86_64	+
TKLinux 3.3	ARM64	**
OpenSUSE 15.3 - Community	x86_64	**
Photon 3.0 - Community	x86_64	**
CTYunOS2	x86_64	+
CTYunOS2	ppc64le	**
CTYunOS3	x86_64	**

OS	Platform	Status
CTYunOS3	ARM64	+
Mariner 2.0	x86_64	+
Alma 8.5	x86_64	**
KylinOS v10 SP2	x86_64	+
KylinOS v10 SP3	x86_64	+
KylinOS v10 SP3	ARM64	+
Allinux 3.2	x86_64	+
Allinux 3.2	ppc64le	+
DriveOS 6.0.5.0	x86_64	+
DriveOS 6.0.5.0	ARM64	+
UOS v20 1040d -Community	x86_64	+
UOS v20 1060a	x86_64	+
UOS v20 1060a	ARM64	**
UOS v20 1060e	x86_64	+
UOS v20 1060e	ARM64	**
UOS v20 1021e	x86_64	+
UOS v20 1021e	ARM64	**
Windows Server 2016	64 Bit	+
Windows Server 2019	64 Bit	+
Windows Server 2022	64 Bit	+
Windows Server 2025	x86_64	+
Windows Server AH2023	64 Bit	+
Windows Server AH2022	64 Bit	+
Windows Server AH2021	64 Bit	+
Windows Server AH2020	64 Bit	+
Windows 10 21H2	64 Bit	+
Windows 10 22H2	64 Bit	+
Windows 10 1809	64 Bit	+

OS	Platform	Status
Windows 11 21H2	64 Bit	+
Windows 11 22H2	64 Bit	+
Windows 11 23H2	64 Bit	+
Windows 11 24H2	64 Bit	+
Windows 11 25H2	64 Bit	+
WinPE 4.0	32 Bit	+
WinPE 4.0	64 Bit	+
WinPE 5.0	32 Bit	+
WinPE 5.0	64 Bit	+
WinPE 5.1	32 Bit	+
WinPE 5.1	64 Bit	+
WinPE 10	32 Bit	+
WinPE 10	64 Bit	+
VMware ESXi 8.0 Native (Vsphere 2022)	64 Bit	+
VMware ESXi 8.0 Native (Vsphere 2022)	ARM	+
VMware ESXi 8.0 u1 Native (Vsphere 2022)	64 Bit	+
VMware ESXi 8.0 u1 Native (Vsphere 2022)	ARM64	+
VMware ESXi 8.0 u2 Native (Vsphere 2022)	x86_64	+
VMware ESXi 8.0 u2 Native (Vsphere 2022)	ARM64	+
VMware ESXi 8.0 u3 Native	64 Bit	+
VMware ESXi 8.0 u3 Native	ARM64	+
VMware ESXi 9.0 Native	64 Bit	+
VMware ESXi 9.0 Native	ARM64	+
FreeBSD 14.0-STABLE	x86_64	+
FreeBSD 15-CURRENT	x86_64	+
MLNX-OS 3.12.1000	64 Bit	+
SONiC 202311	64 Bit	**
Cumulus 5.9	64 Bit	+

OS	Platform	Status
NV-OS 25.02.1000	64 Bit	**
DVS 4.7.1000	64 Bit	+
FreeBSD 14.0-STABLE	ARM64	+
FreeBSD 15.0-CURRENT	ARM64	+
Korg6.10	X86_64	+
Korg6.11	X86_64	+
Mariner 3.0	X86_64	+
OpenEuler 22.03-SP3	X86_64	+
OpenEuler 22.03.LTS	X86_64	+
VMware ESXi 9.0 Native	x86	+
Xenserver 8.2	X86_64	+

Supported Flash Types

MFT supports the following Flash types.

Vendor	Flash Family	Tested P/N
Winbond	W25QxxBV	W25Q32FVSSIG
		W25Q32FVSSIGS
		W25Q32FVSSIGT
		W25Q128FVSSIGS
	W25Qxxx	W25Q256JVBIMT
		W25Q128JVSIQ
Macronix	MX25L16xxx	MX25L12845GM2I-08G
	MX25Lxxx	MX25L25645GXDI-08G
Micron	N25Q0xxx	MT25QL128ABA1ESE-OSIT
ISSI	IS25LPxxx	IS25LP128-JBLE SPA# U1323A
	IS25WPxxx	IS25WP256E-RHLE

Vendor	Flash Family	Tested P/N
Cypress	S25FL256L	S25FL256LDPBHV023
		S25FL128SAGMFVG00
Gigadevice		GD25LB256EBFRY
		GD25B256DFIGR

Supported NVIDIA Devices

The supported NVIDIA devices are listed in the following table:

IC Group	IC Device
Group II/5th Generation	• Adapter Cards: • ◦ NVIDIA ConnectX-8 ◦ ConnectX-8 - PCIe Switch ◦ NVIDIA BlueField-3 ◦ NVIDIA BlueField-2 ◦ NVIDIA ConnectX-7 ◦ ConnectX-7 - PCIe Switch ◦ NVIDIA ConnectX-6 Lx ◦ NVIDIA ConnectX-6 Dx ◦ NVIDIA ConnectX-6 • Switch Systems: ◦ NVIDIA Quantum-3 ◦ NVIDIA Quantum-2 ◦ NVIDIA Quantum ◦ NVIDIA Spectrum-4 ◦ NVIDIA Spectrum-3 ◦ NVIDIA Spectrum-2 ◦ NVIDIA Switch-IB 2 ◦ NVIDIA Switch-IB • GPU ◦ NVIDIA Blackwell • Retimer ◦ Arcus-E

Supported Adapter Cards Firmware Versions

The following NVIDIA® network adapter cards are supported:

Adapter Card	Bundled Firmware Version
ConnectX-8	40.47.1026
BlueField®-3	32.47.1026
BlueField®-2	24.47.1026
ConnectX-7	28.47.1026
ConnectX-6 Lx	26.47.1026
ConnectX-6 Dx	22.47.1026

To download the firmware binaries, please visit [Firmware Downloads](#).

Supported Switch Systems Software

The following are the Supported Switch Systems Software.

Switch Software	Version
MLNX-OS	3.12.1000
SONIC	202311
Cumulus	5.9
DVS	4.7.1000
NV_OS	25.02.1000

Changes and New Features

Component/ Tool	Description	Operating System
Rev. 4.34.0-145		
nvredfish	Added support for nvredfish tool.	All
mdevices_info	Added <code>--enable-vfio</code> configure flag to make VFIO library optional.	All
mlxconfig	Added support for <code>--with_default</code> flag for mlxconfig tool.	All
	Added support for <code>--host_id</code> and <code>pf_index</code> flags in mlxconfig tool.	All
mlxlink	Added support for <code>--rx_modulation</code> and <code>--tx_modulation</code> flags to the test mode flow. Modulation status is shown in mlxlink output when in test mode.	All
mlxreg	Exposed the syndrome in mlxreg in external MFT package.	All
mlxdp	Added commands for creating, signing, and removing a single application. Also, added support for <code>keep_sig</code> flag for container creation.	All

Customer Affecting Changes

Changes in This Release

This section provides a list of changes that took place in the current version and break compatibility/interface, discontinue support for features and/or OS versions, etc.

Planned for Version	Description
N/A	N/A

Changes Planned for Future Releases

This section provides a list of changes that will take place in a future version of the product and will break compatibility/interface, discontinue support for features and/or OS

versions, etc.

Planned for Version	Description
4.34.0	Starting with the October 2025 firmware release, and for all subsequent versions, compatibility with the older MFT releases (4.31.0-149 and 4.30.0-139) is no longer supported.

Changes in Earlier Releases

This section provides a list of changes that took place throughout the past two major releases that broke compatibility/interface, discontinued support for features and/or OS versions, etc.

For an archive of all changes, please refer to the Release Notes History section.

Planned for Version	Description
N/A	N/A

Discontinued Features

List of features which are supported in previous generations of hardware devices.

N/A

Declared Unsupported Features

This section provides a list of features that are not supported by the software.

N/A

MFT Bug Fixes in this Version

For a list of old Bug Fixes, please see [MFT Bug Fixes History](#).

Internal Ref.	Description
4564528	Description: In <code>mlx_fwsfx_gen</code> , removed dependency of <code>/dev/null</code> due to lack of permission in some environments.
	Keywords: <code>mlx_fwsfx_gen</code> , <code>/dev/null</code>
	Discovered in Version: 4.33.0-169
	Fixed in Release: 4.34.0-145

MFT Known Issues

The following table provides a list of known issues and limitations.

Internal Ref. No.	Issue
4682265	Description: When running FWtrace on Python 3.6 with remote device.
	Workaround: Upgrade Python version to 3.8 and above.
	Keywords: FWtrace, Python
	Discovered in Version: 4.34.0-145
4414021	Description: In PCIe Switch-only product, if all PCIe Links are down, the device enters power-save mode.
	Workaround: Remove the device from the power-save mode in order to resume normal operation.
	Keywords: PCIe
	Discovered in Version: 4.34.0-145
4524862	Description: Running <code>mlxfwreset</code> over BlueField-2 and BlueField-3 devices.
	Workaround: Use the needed flags for the sync and not rely on the default.
	Keywords: <code>mlxfwreset</code> , BlueField-2, BlueField-3
	Discovered in Version: 4.33.0-3002
4296168	Description: The default reset level is not executed in hot plug system.
	Workaround: Using explicitly reset method 1 parameter in CLI. Execute <code>mlxfwreset -m 1</code> .
	Keywords: BlueField-3, DPU Mode
	Discovered in Version: 4.32.0-120
-	Description: <code>mlxpttrace</code> does not run on SPECTRUM5 due to missing firmware.

Internal Ref. No.	Issue
	Workaround: Use mlxtrace instead of mlxptrace.
	Keywords: mlxptrace, mlxtrace, tracer tools, SPECTRUM5
	Discovered in Version: 4.32.0-120
4294588	Description: In some cases, BlueField-3 users might experience a mis The error message is: "-E- The PCI link is still up even after the expect
	Workaround: Ignore the misleading error message.
	Keywords: mlxfwreset, hot reset
	Discovered in Version: 4.31.0-149
4258362	Description: When testing the tools using RDMA as the device, they c
	Workaround: RDMA rename feature is supported only after running t
	Keywords: tools, mst, RDMA
	Discovered in Version: 4.31.0-149
4129306	Description: Autocomplete feature is not working as expected for Ub functionalities are all working as expected, only autocomplete on Ubu
	Workaround: Execute the following cmd: <code>ln -snf /usr/etc/bash</code>
	Keywords: Autocomplete, Ubuntu
	Discovered in Version: 4.30.0-139
4089179	Description: When using mlxlink with --show_module(-m) flag, Rx/TX
	Workaround: To get the Power Current values, use mlxreg with PDDR page_select=3, module_info_ext=1, local_port=<local_port> and read For example:
	<pre> mlxreg -d /dev/mst/hgx-isr1-020:23108, @dev@mst@mt41692_ "port_type=0,plane_ind=0,lp_msb=0,pnat=0,local_port=1,page_select=3,group_opcc --op "module_info_ext=1" </pre>
	Keywords: mlxlink, Rx/TX Power Current
	Discovered in Version: 4.29.0-131
3262855	Description: The mlxfwreset tool might fail when using PPC64LE on t
	Workaround: N/A

Internal Ref. No.	Issue
	Keywords: mlxfwreset, PPC64LE
	Discovered in Version: 4.29.0-131
3926386	Description: Secure boot devices, such as ConnectX7 and above, doe
	Workaround: N/A
	Keywords: ConnectX7, PXE/UEFI ROM data, IMG file
	Discovered in Version: 4.29.0-131
3886315	Description: '--sync 0' argument must be specified when resetting or
	Workaround: N/A
	Keywords: mlxfwreset, sync 0, ARM
	Discovered in Version: 4.28.0-92
3872303	Description: Activation of MMS4X00-NS transceivers may fail with rc
	Workaround: Reset the Switch/HCA to activate the new firmware on
	Keywords: MMS4X00-NS
	Discovered in Version: 4.28.0-92
3743317	Description: Reset flow is not supported when Hotplug is enabled. Th
	Workaround: N/A
	Keywords: Reset flow, Hotplug
	Discovered in Version: 4.26.1
3738146	Description: mlxfwreset does not support MRSR-6 when using Quant
	Workaround: N/A
	Keywords: mlxfwreset, MRSR-6
	Discovered in Version: 4.26.1
3641618	Description: Running a command triggers the following error messag /lib/libgcc_s.so.1: version GCC_4.5.0 required by /us
	Workaround: Run the following command: export LD_LIBRARY_PATH=/usr/local/lib/gcc12:\$LD_LIBRA
	Keywords: libstd, gcc, mft, libgcc
	Discovered in Version: 4.26.0

Internal Ref. No.	Issue
3549141	Description: mlxfwreset usage by the Prometheus PCIe switch is curr
	Workaround: N/A
	Keywords: mlxfwreset, Prometheus PCIe switch
	Discovered in Version: 4.25.0
3262855	Description: The mlxfwreset tool might fail when using PPC64LE on t
	Workaround: N/A
	Keywords: mlxfwreset, PPC64LE, RH 8.7
	Discovered in Version: 4.25.0
3090162	Description: The PCIe Error Injection feature is not supported due to
	Workaround: N/A
	Keywords: PCI Error Injection
	Discovered in Version: 4.22.0
3446066	Description: When using ConnectX-7 and later cards, the link should
	Workaround: N/A
	Keywords: mlxlink
	Discovered in Version: 4.23.0
3352983	Description: mlxfwreset does not work on mlnx-os/sonic/cumulus.
	Workaround: N/A
	Keywords: mlxfwreset
	Discovered in Version: 4.23.0
3418112	Description: Loading a new firmware may require running <code>mlxfwres</code>
	Workaround: N/A
	Keywords: mlxfwreset
	Discovered in Version: 4.24.0
3314750	Description: When entering link speed values, you can specify a single suggesting possible values, only works for the first value in a list of va. Additionally, the autocompletion list includes all possible speeds. Some Affected shell commands are: <pre>port speed port autonegotiation on speed port autoneg</pre>

Internal Ref. No.	Issue
	Any inconvenience caused by these limitations will be addressed in future releases. Workaround: When entering a link speed, you may press the key first type a comma (,) to select the next speed. Repeat the process to form the command. Once the command is fired, the underlying MFT tool will inform you if the speed is supported or not of the available options. Keywords: mft-shell, link-speed Discovered in Version: 4.23.0
3188577	Description: Some firmware scratchpad registers have been moved to the MFT package. Otherwise, the mstdumps device will not retrieve the firmware version. Workaround: N/A Keywords: CSV, mstdump Discovered in Version: 4.22.0
2787479	Description: mlx cables shows the wrong firmware version for OSFP cables. Workaround: N/A Keywords: mlx cables, OSFP, firmware version Discovered in Version: 4.18.0
2823492	Description: mlx fwreset is not supported on DPU with GPU boards. Workaround: N/A Keywords: mlx fwreset Discovered in Version: 4.18.0
2715716	Description: mlx fwreset is not supported on secure-boot host device. Workaround: N/A Keywords: mlx fwreset Discovered in Version: 4.18.0
2752916	Description: The information of the IB/ETH protocols should not be stored in the MFT package. Workaround: N/A Keywords: mlxlink Discovered in Version: 4.18.0
2838222	Description: mlx fwreset is not supported on kernel 3.10.0-1062.el7.x86_64.

Internal Ref. No.	Issue
	Workaround: N/A
	Keywords: mlxfwreset
	Discovered in Version: 4.18.0
2703663	Description: Running flint commands on the hypervisor while a Virtual
	Workaround: N/A
	Keywords: flint, kernel, VM
	Discovered in Version: 4.17.0
2670833	Description: Burning firmware using DMA might fail on virtual FreeBS
	Workaround: N/A
	Keywords: Firmware burning, DMA, FreeBS, VM
	Discovered in Version: 4.17.0
2484780	Description: Configuring TX/RX_rate to 200GbE in test mode fails.
	Workaround: To work with the new speeds specify the number of lanes • 100G_1X/200G_2X/400G_4X/800G_8X for NDR speeds • 50G_1X/100G_2X/200G_4X/400G_4X for HDR speeds
	Keywords: 200GbE, Tx/Rx
	Discovered in Version: 4.17.0
2392334	Description: Using the MFT with the --with-pcap option to install stec • Libraries and header files for the libpcap library • Libraries and header files for Python development library • Package Installer for Python (PIP) available
	Workaround: To install the third-party dependencies, perform the following steps: 1. Install <code>libpcap-devel</code> or <code>libpcap-dev</code> on Debian-based distributions 2. Install <code>python3-devel</code> or <code>python3-dev</code> on Debian-based distributions 3. Bootstrap the PIP installer in one of the following ways: • On Python 3.4 or newer bootstrap it from the standard library bootstrap • Install PIP with Linux Package Manager, for more details see: http://www.dabeaz.com/pip.html

Internal Ref. No.	Issue
	Keywords: stedump utility
	Discovered in Version: 4.16.0
2376425	Description: Direct Device Assignment (DDA, aka. pass-through) faci
	Workaround: Burn the firmware in PF and then attach the HCA to the
	Keywords: DDA
	Discovered in Version: 4.16.0
2208845/2099263	Description: mlxlink does not support test mode for 50GE-KR4 speed
	Workaround: N/A
	Keywords: mlxlink
	Discovered in Version: 4.16.0
-	Description: Port toggling with Inband devices using mlxlink fails and
	Workaround: To avoid this issue, perform one of the following options • Use OpenSM (with or without -o) • Use only active ports
	Keywords: Port toggling, mlxlink, Inband devices
	Discovered in Version: 4.14.0-105
2234589	Description: For Multi-Host systems, enabling the PRBS test mode ca
	Workaround: Maintain another interface for enabling the link back.
	Keywords: mlxlink
	Discovered in Version: 4.15.0
2167841	Description: <code>"mlxfwmanager --download"</code> and <code>"mlxfwmanager</code>
	Workaround: N/A
	Keywords: mlxup/mlxfwmanager
	Discovered in Version: 4.14.3
2149437	Description: When the SLTP configuration is wrongly set, the “Bad st
	Workaround: N/A
	Keywords: SLTP configuration

Internal Ref. No.	Issue
	Discovered in Version: 4.14.2
1780276	Description: "mst server start" runs at foreground instead of the background
	Workaround: Use <code>'&'</code> --> <code>'mst server start &'</code>
	Keywords: 'mst server start', FreeBSD, VMWare ESXi
	Discovered in Version: 4.14.0-105
2001890	Description: The argparse module is installed by default in Python version 3.6.5 and above.
	Workaround: N/A
	Keywords: Python, argparse module
	Discovered in Version: 4.13.3
1923665 / 1939791	Description: Force Mode does not work when using mlxlink in ConnectX-6 IB
	Workaround: N/A
	Keywords: mlxlink, Force Mode, ConnectX-6 IB
	Discovered in Version: 4.13.3
1802662	Description: Due to mst signing process, some executions might be slow
	Workaround: N/A
	Keywords: mst
	Discovered in Version: 4.13.0
1431471	Description: In ConnectX-5 adapter cards, the time-stamp capability is not supported
	Workaround: Use the "-d" flag to set the time-stamp.
	Keywords: flint
	Discovered in Version: 4.11.0
1442454	Description: Occasionally, when running mstfwreset over a Multi-Homed network interface, the command fails
	Workaround: N/A
	Keywords: mstfwreset
	Discovered in Version: 4.11.0
-	Description: Running mstfwreset on ConnectX-5 Socket-Direct adapter cards fails
	Workaround: Reboot the server

Internal Ref. No.	Issue
	Keywords: mstfwreset, ConnectX-5 Socket-Direct
	Discovered in Version: 4.8.0


User Manual

MFT package is a set of firmware management and debug tools for NVIDIA[®] devices. MFT can be used for:

- Generating a standard or customized NVIDIA firmware image
- Querying for firmware information
- Burning a firmware image to a single NVIDIA device

The list of the available tools in the package can be found in the [Release Notes](#) document.

MFT – A Scheme of Operation



Supported Operating Systems

Please refer to the release notes of your version for supported operating systems and platforms.

Note

Unless explicitly specified, the usage of the tools is identical for all operating systems.

MFTshell

Note

This is an early alpha release of MFTshell with limited capabilities.

The MFTshell is a frontend for a variety of MFT tools. It is designed to be a starting point for entry-level users to become familiar with the functionality of the tools. In general, commands entered in the shell, result in the execution of the corresponding tool.

You can use the autocompletion feature of MFTshell by pressing the tab key. You may access helpful information by typing ".help" followed by the command on which you wish to receive helpful information.

Access to Hardware Devices

The table below lists the NVIDIA[®] devices supported by MFT, the supporting tools, and the access methods to these devices.

Device Type	Product Name	HW Access Method			
		PCI	I2C	In-Band	NVIDIA Driver
IB/ETH Network Adapter	NVIDIA ConnectX-8	V	V	V	
	NVIDIA ConnectX-4	V	V	V	
	NVIDIA ConnectX-5	V	V	V	
	NVIDIA ConnectX-5 Ex	V	V	V	

Device Type	Product Name	HW Access Method			
	NVIDIA ConnectX-6	V	V	V	
	NVIDIA ConnectX-6 Dx	V	V	V	
	NVIDIA ConnectX-7	V	V	V	
	NVIDIA BlueField-2	V	V	V	
	NVIDIA BlueField-3	V	V	V	
Ethernet Adapter (NIC)	NVIDIA ConnectX-8	V	V		
	NVIDIA ConnectX-4 Lx	V	V		
	NVIDIA ConnectX-6 Dx	V	V		
	NVIDIA ConnectX-6 Lx	V	V		
	NVIDIA ConnectX-7	V	V		
	NVIDIA BlueField-2	V	V		
Switch	NVIDIA Switch-IB®	V ¹	V	V	
	NVIDIA Switch-IB 2	V ¹	V	V	
	NVIDIA Spectrum™	V	V		
	NVIDIA Spectrum-2	V	V		
	NVIDIA Spectrum-3	V	V		
	NVIDIA Quantum	V	V	V	
GPU	NVIDIA Blackwell				V

Note. V¹ indicates managed switch products only. MFT tools access NVIDIA devices via the PCI Express interface, via a USB to I2C adapter (P/N: MTUSB-1), or via vendor-specific MADs over the InfiniBand fabric (In-Band).

Note

In-Band device access requires the local IB port to be in the ACTIVE state and connected to an IB fabric.

All MFT tools address the target hardware device using an *mst device name*. This name is assigned by running the command 'mst start' (in Windows, it is not required to run the "mst start" command) for PCI and I2C access. In-Band devices can be assigned by running the 'mst ib add' command. In-Band devices can be assigned by running the 'mst ib add' command.

To list the available mst device names on the local machine, run 'mst status'. Local PCI devices may also be accessed using device aliases. Supported aliases are:

- PCI device "bus:dev.fn" (e.g. 03:00.0)
- OFED RDMA device (e.g. mlx4_0)
- Network interface with "net-" prefix (e.g. net-eth2)

Run `mst status -v` to list the devices and their available aliases. The format of an mst device name is as follows:

Via PCI:

```
# mt4099_pci_crX
```

```
# mt4099_pciconf0
```

Where:

X is the index of the adapter on the machine.

_crX devices access the adapter directly (recommended if possible).

_pciconfX devices use configuration cycles to access the adapter.

For example:

```
# mt25418_pci_cr0
```

Via USB to I2C adapter: For example, `mtusb-1`.

Via Remote device:

```
/dev/mst/mft:23108,@dev@mst@mt4103_pci_cr0
```

Via ibdr device: For example,

```
/dev/mst/CA_MT4113_server1_HCA-3_ibdr-0,mlx- 5_0,1 or ibdr-0,mlx5_0,1.
```

Via In-Band: `<string>lid-<lid_number>.`

For example:

```
/dev/mst/CA_MT4099_mft_HCA-1_lid-0x0002 or simply "lid-2"
```

The “mst ib add” command adds devices in the format:

- For adapters:

```
CA_<device id >_<ib node description>_lid-<lid number>
```

- For switches:

```
SW_<device id >_lid-<lid number>
```

See Step 3 in [.Remote Access to NVIDIA Devices v4.18.1](#) for instructions on how to obtain the device LID.

Via PCI user level: `<bus:dev.fn>`

For example, if you run `lspci -d 15b3`: NVIDIA devices and PCI Device IDs will be displayed.

```
# /sbin/lspci -d 15b3:
02:00.0 Ethernet controller: Mellanox Technologies Unknown device
6368 (rev a0)
```

VFIO Access:

The purpose of this access is to work in a Kernel lockdown mode, since user space access to the Kernel is not allowed in that environment.

To use it:

1. Load the VFIO driver by running: `modprobe vfio.`
2. Access the device using its DBDF.

Compilation and Installation

Download the relevant MFT package for your OS from the [MFT](#) webpage and continue as described in table below according your OS.

OS	Install	Uninstall
Linux	1. Untar the downloaded package 2. Allow packaging of bins to a self-executing file. 3. Run 'install.sh' For OEM only: 'install.sh --oem' 4. Start the mst driver by running: mst start NOTE: It is possible to customize some installation parameters (such as the target installation path). Run 'install.sh --help' for details.	Uninstall MFT on Linux by running the following command: mft_uninstall.sh

OS	Install	Uninstall
Windows	The installation is EXE based: 1. Double click the EXE file and follow the instructions presented by the installation wizard.	1. Go to Add or remove programs. 2. Remove WinMFT64 depending on the platform type.
FreeBSD	1. Untar the downloaded package. 2. Run "install.sh"	Uninstall MFT on FreeBSD, run the following command: mft_uninstall.sh
VMware	1. Install the package. Run: # esxcli software vib install -v <MST Vib> # esxcli software vib install -v <MFT Vib> NOTE: For VIBs installation examples, please see below. 2. Reboot system. 3. Start the mst driver. Run: # /opt/mellanox/bin/mst start	1. Uninstall the package. Run: # esxcli software vib remove -n mft 2. Uninstall the mst: • VMKlinux: # esxcli software vib remove -n net-mft • Native: # esxcli software vib remove -n nmst 3. Reboot system.

Example (VIBs installation):

VMK:

```
esxcli software vib install -v /tmp/net-mst_4.6.0.22-10EM.600.0.0.2295424.vib
esxcli software vib install -v /tmp/mft-4.6.0.22-10EM-600.0.0.2295424.x86_64.vib
```

Native:

```
esxcli software vib install -v /tmp/nmst-4.6.0.22-10EM.600.0.0.2295424.x86_64.vib
```

```
esxcli software vib install -v /tmp/mft-4.6.0.22-10EM-  
600.0.0.2295424.x86_64.vib
```

Firmware Generation, Configuration, and Update Tools

This chapter contains the following sections:

- [mst Service](#)
- [MFT Configuration](#)
- [mlxfwmanager – Firmware Update and Query Tool](#)
- [mlxarchive – Binary Files Compression Tool](#)
- [mlxconfig – Changing Device Configuration Tool](#)
- [flint – Firmware Burning Tool](#)
- [mlxburn – Firmware Image Generator and Burner](#)
- [mlxfwreset – Loading Firmware on 5th Generation Devices Tool](#)
- [mlxphyburn – Burning Tool for Externally Managed PHY](#)
- [mlx_fpga – Burning and Debugging Tool for NVIDIA Devices with FPGA](#)
- [cpldupdate – Tool for Programming On-Board CPLDs on NVIDIA Devices](#)
- [mlxprivhost - NIC Configuration by the Host Restriction Tool \(Zero Trust Mode\)](#)
- [mlxtokengenerator - Token Creation Tool](#)
- [mlxdpa – DPA Applications Sign Tool](#)
- [mlxcableimngen - Cable Firmware Image Wrapper Generation Tool](#)
- [nvredfish 1](#)

- [nvredfish](#)

mst Service

This section contains:

- [Linux](#)
- [Running mst in an Environment without a Kernel](#)
- [Windows](#)
- [FreeBSD](#)
- [VMware ESXi](#)

Linux

This script is used to start mst service and to stop it. It is also used in other operations with NVIDIA devices, such as in resetting or enabling remote access.

mst Synopsis - Linux

```
mst <command> [switches]
```

mst Commands and Switches Description - Linux

```
mst start [--with_msix] [--with_unknown] [--with_i2cdev] [--with_lpcdev] [--with_fpga] [--with_fpga_fw_access]
```

Create special files that represent NVIDIA devices in directory /dev/mst. Load appropriate kernel modules and saves PCI configuration headers in directory /var/mst_pci. After successfully completion of this command the MST driver is ready to work. You can configure the start command by editing the configuration file: /etc/mft/mst.conf, for example you can rename you devices.

Options:

- --with_msix: Create the msix device.

	• <code>--with_unknown</code>: Do not check if the device ID is supported. • <code>--with_i2cdev</code>: Create Embedded I2C master • <code>--with_fpga</code>: Create MST device for the attached FPGA card (Access via Driver) • <code>--with_fpga_fw_access</code>: Create an extended MST device for the attached FPGA (Access via Firmware)
<code>mst stop [--force]</code>	Stop the MST driver service, remove all special files/ directories and unload kernel modules. Options: • <code>--force</code>: Force try to stop mst driver even if it's in use.
<code>mst restart [--with_msix] [--with_unknown] [--with_i2cdev] [--with_lpcdev] [--with_fpga] [--with_fpga_fw_access]</code>	Just like "mst stop" followed by "mst start [--with_msix] [--with_unknown] [--with_i2cdev] [--with_lpcdev] [--with_fpga] [--with_fpga_fw_access]"
<code>mst server start [port-p <port> [-s <passphrase>]</code>	Start mst MST server to allow incoming connection. The default port is 23108. Use the '-s' flag to define the passphrase used by the server.If no passphrase is provided, a random one will be generated.
<code>mst server stop</code>	Stop the mst server.
<code>mst remote add <hostname>[:port] [-s <passphrase>]</code>	Establish a connection with a specified host on a specified port. The default port is 23108. Add devices on a remote peer to a local devices list.<hostname> may be the host name as well as an IP address.Use the '-s' flag to provide the host's passphrase.If no passphrase is provided, you will be prompted to insert one.
<code>mst remote del <hostname>[:port]</code>	Remove all remote devices on specified hostname. <hostname>[:port] should be specified exactly as in the "mst remote add" command.
<code>mst ib add [OPTIONS] [local_hca_id] [local_hca_port]</code>	Add devices found in the IB fabric for inband access. Requires OFED installation and an active IB link. If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, the default subnet is scanned. Options:

	• <code>--discover-tool <discover-tool></code>: The tool that is used to discover the fabric Supported tools: <code>ibnetdiscover</code>, <code>ibdiagnet</code>. default: <code>ibdiagnet</code> • <code>--add-non-mlnx</code>: Add non NVIDIA nodes • <code>--topo-file <topology-file></code>: A prepared topology file which describes the fabric. For <code>ibnetdiscover</code>: provide an output of the tool. For <code>ibdiagnet</code>: provide LST file that <code>ibdiagnet</code> generates • <code>--use-ibdr</code>: Access by direct route MADs. Available only when using <code>ibnetdiscover</code> tool, for SwitchX and ConnectIB devices NOTE: If a topology file is specified, device are taken from it. Otherwise, a discover tool is run to discover the fabric. • <code>--planarized</code> : Add planarized device NOTE: this device is only supported by <code>mlxlink</code> tool.
<code>mst ib del</code>	Remove all inband devices.
<code>mst cable add</code> <code>[OPTIONS] [params]</code>	Add the cables that are connected to 5th generation devices. There is an option to add the cables found in the IB fabric for Cable Info access, requires WinOF-2 installation and active IB links. If <code>local_hca_id</code> and <code>local_hca_port</code> are given, the IB subnet connected to the given port is scanned. Otherwise, all the devices will be scanned. Options: <code>--with_ib</code>: Add the inband cables in addition to the local PCI devices. params: <code>[local_hca_id] [local_hca_port]</code>
<code>mst cable del</code>	Remove all cable devices.
<code>mst i2c add</code> <code>[--with_retimer]</code> <code>[--with_chipset]</code>	Add I2C devices for each i2c secondary address.
<code>mst gpu add</code>	Add GPU device via NVIDIA Driver.
<code>mst gpu del</code>	Remove all GPU devices.

mst status	Print current status of NVIDIA devices Options: -v run with high verbosity level (print more info on each device)
mst save	Save PCI configuration headers in directory /var/mst_pci.
mst load	Load PCI configuration headers from directory /var/mst_pci.
mst version	Print the version info

Using mst.conf File in Linux

Edit the /etc/mft/mst.conf configuration file to configure the start operation in Linux (only).

The configuration file consists of lines of rules. Every line will be a rule for mst start. It must be valid, and the rules should be unique. There should also be no duplication of new names and/or serials.

The rule general format is the following:

```
$OPCODE $PARAMS
```

mst start Supported OPCODES

OPCODE	Definition	Description
RENAME	renames mst devices	- Rule format: RENAME \$TYPE \$NEW_NAME \$ID - Supported types: # MTUSB (where \$ID is the iSerial) - Example: RENAME USB my 0x2A4C. - Effect: MTUSB with serial 0x2A4C will be renamed to /dev/mst/mymtusb-1 (always mtusb-1 will be concatenated to the new name).

Examples of mst Usage - Linux

To start the mst driver service:

```
# mst start
```



```
Starting MST (Mellanox Software Tools) driver set
Loading MST PCI module - Success
Loading MST PCI configuration module - Success
Create devices
MTUSB-1 USB to I2C Bridge - Success
```

To stop the service:

```
Success# mst stop
Stopping MST (Mellanox Software Tools) driver set
Unloading MST PCI module - Success
```

To print the current status of NVIDIA devices:

```
# mst status
MST modules:
-----
    MST PCI module loaded
    MST PCI configuration module loaded

MST devices:
-----
/dev/mst/mt4099_pciconf0          - PCI configuration cycles
access.

domain:bus:dev.fn=0000:0b:00.0 addr.reg=88 data.reg=92
                                Chip revision is: 01
/dev/mst/mt4099_pci_cr0          - PCI direct access.

domain:bus:dev.fn=0000:0b:00.0 bar=0xd2600000 size=0x100000
                                Chip revision is: 01
/dev/mst/mtusb-1                 - USB to I2C adapter as I2C
master
```

```
iSerial = 0x1683
```

To show the devices status with detailed information

```
# mst status -v
PCI devices:
DEVICE_TYPE          MST                                PCI            RDMA
NET          NUMA
ConnectX4(rev:0)      /dev/mst/mt4115_pciconf0      08:00.0      mlx5_0
net-ib2      -1
ConnectX4(rev:0)      /dev/mst/mt4115_pciconf0.1    08:00.1      mlx5_1
net-ib3      -1
ConnectIB(rev:0)      /dev/mst/mt4113_pciconf0      0b:00.0      mlx5_2
net-ib4,

net-ib5      -1
ConnectX3(rev:1)      /dev/mst/mt4099_pciconf0
ConnectX3(rev:1)      /dev/mst/mt4099_pci_cr0        0e:00.0      mlx4_0
net-ib0,

net-ib1      -1
I2C devices:
-----
MST          Serial
/dev/mst/mtusb-1    0x1B5C
```

In case the device has Function Per Port (FPP) enabled on it, a new device will appear in the `mst status -v` output with information about the second physical function. Example:

```
DEVICE_TYPE          MST                                PCI            RDMA
NET          NUMA
ConnectX4(rev:0)      /dev/mst/mt4115_pciconf0      07:00.0      mlx5_4
net-ib4      -1
```

```
ConnectX4(rev:0)    /dev/mst/mt4115_pciconf0.1    07:00.1    mlx5_5
net-ib5            -1
```

Running mst in an Environment without a Kernel

mst can work even without kernel module being installed on the machine or if the kernel is down. In this case, the devices' names will be the PCI address of the devices.

Example:

```
> mst status
MST modules:
-----
    MST PCI module is not loaded
    MST PCI configuration module is not loaded

PCI Devices:
-----
05:00.0
08:00.0
82:00.0

> mst status -v
MST modules:
-----
    MST PCI module is not loaded
    MST PCI configuration module is not loaded

PCI devices:
-----
```

DEVICE_TYPE	MST	PCI	RDMA	NET
NUMA				
ConnectX3Pro(rev:0)	NA	05:00.0	mlx4_0	net-ib0,net-ib1
ConnectX4(rev:0)	NA	08:00.0	mlx5_0	net-ib2
ConnectX4(rev:0)	NA	08:00.1	mlx5_1	net-ib3
ConnectIB(rev:0)	NA	82:00.0	mlx5_2	net-ib4,net-ib5

Note

The MST interface will be NA in mst status -v[v] output.

Run commands with these devices:

```
> flint -d 08:00.0 q
Image type:          FS3
FW Version:          12.16.0048
FW Release Date:     14.3.2016
Description:         UID                               GuidNumber
Base GUID:           7cfe90030029205e                  4
Base MAC:            00007cfe9029205e                  4
Image VSD:
Device VSD:
PSID:                MT_2190110032
```

Windows

mst Synopsis - Windows

mst status [-v] | help | server <start|stop> | ib <add|del> | version | remote <add|del>
<hostname>

mst Commands and Switches Description - Windows

Note

There are no mst start or stop operations in Windows.

mst server start [port]	Start mst server to allow incoming connection. Default port is 23108.
mst server stop	Stop mst server.
mst remote add <hostname>:[port] [-s <passphrase>]	Establish a connection with a specified host on a specified port (the default port is 23108). Add devices on a remote peer to a local devices list. <hostname> may be host name as well as an IP address Use the '-s' flag to provide the host's passphrase. If no passphrase is provided, you will be prompted to insert one. Note: [-s] is applicable when the host server OS is not windows.
mst remote del <hostname>:[port]	Remove all remote devices on a specified hostname <hostname>:<port> should be specified exactly as in the "mst remote add" command.
mst ib del	Remove all inband devices.
mst cable add [OPTIONS] [params]	Add the cables that are connected to 5th generation devices. There are an option to add the cables found in the IB fabric for Cable Info access, requires OFED installation and active IB links.If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, all the devices will be scanned.OPTIONS:--with_ib: Add the inband cables in addition to the local PCI devices.params: [local_hca_id] [local_hca_port]
mst cable del	Remove all cable devices.
mst status	Print current status of NVIDIA devices.
mst version	Print the version info.
mst ib add [OPTIONS] [local_hca_id]	Add devices found in the IB fabric for inband access.

[local_hca_port] [lst-file]	Requires MLNX_WinOF installation and an active IB link.If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, the default subnet is scanned.If an lst-file is specified, devices are taken from this file. Otherwise, ibnetdiscover tool is run to discover the fabric. Options: • --discover-tool <discover-tool>: The tool used to discover the fabric. Supported tools: ibnetdiscover, ibdiagnet. default: ibnetdiscover NOTE: The discover tool argument is intended only for parsing purposes, thus you need to specify an lst-file with it. • --add-non-mlnx: Add non NVIDIA nodes. • --use-ibdr: Access by direct route MADs. Available only when using ibnetdiscover tool, for SwitchX and ConnectIB devices. • --no-format-check: Do not check the format of the given local_hca_id. The expected format of the local_hca_id is: ibv_device[0-9]+. • --topo-file <topology-file>: A prepared topology file which describes the fabric. For ibnetdiscover: provide an output of the tool. For ibdiagnet: provide and lst-file that ibdiagnet generates. NOTE: If a topology file is specified, the devices are taken from it. Otherwise, a discover tool is run to discover the fabric.
mst help	Print this help information.

Examples of mst Usage - Windows

To print the current status of NVIDIA devices:

```
# mst status
MST devices:
-----
mt4115_pciconf0
```

```
mtusb-1  
mtusb-2
```

To show the devices status with detailed information:

```
# mst status -v  
  
MST devices:  
-----  
mt4115_pciconf0    bus:dev.fn=13:00.0  
mt4115_pciconf0.1 bus:dev.fn=13:00.1  
mtusb-1           iSerial=0x1ccc  
mtusb-2           iSerial=0x1cd5
```

FreeBSD

mst Synopsis - FreeBSD

```
mst <command> [switches]
```

Commands and Switches Description - FreeBSD

Note

There are no mst start or stop operations in FreeBSD.

mst status	Print current status of NVIDIA devices.
mst help	Print this help information.
mst version	Print mst version information.
mst server start [port]	Start mst server to allow incoming connection. Default port is 23108.
mst server stop	Stop mst server.
mst cable add	Add the cables that are connected to the device
mst cable del	Delete the added cables

Examples of mst Usage - FreeBSD

To print the current status of NVIDIA devices:

```
VMwareMST devices:
-----
pci0:3:0:0 - MT27500 Family [ConnectX-3]
```

Note

The mst status output is taken from parsing the `pciconf` output.

To show the devices status with detailed information:

```
# mst status -v

PCI devices:
-----
DEVICE_TYPE          MST   PCI          RDMA      NET      NUMA
```


ConnectX4LX(rev:0)	pci0:2:0:0	02:00.0	mlx5_0
ConnectX4LX(rev:0)	pci0:2:0:1	02:00.1	mlx5_1
ConnectX4(rev:0)	pci0:3:0:0	03:00.0	mlx5_2

VMware ESXi

mst Synopsis - VMware

```
mst <command> [switches]
```

Commands and Switches Description - VMwareMST

mst start	Create special files that represent NVIDIA devices in directory/dev. Load appropriate modules. After successfully completing this command, the mst driver will be ready to work.
mst stop	Stop NVIDIA mst driver service and unload the kernel modules.
mst restart	"mst stop" followed by "mst start"
mst server start [-p --port portport] [-s <passphrase>]	Start the MST server to allow incoming connection. The default port is 23108. Use the '-s' flag to define the passphrase used by the server.If no passphrase is provided, a random one will be generated.
mst server stop	Stop the mst server.
mst status	Print current status of NVIDIA devices Options:-v run with a high verbosity level (print more info on each device)
mst version	Print the version info

Examples of mst Usage - VMware

To print the current status of NVIDIA devices:

Native

```
# /opt/mellanox/bin/mst status
MST devices:
-----
mt4099_pciconf0
mt4099_pci_cr0
```

VMK Linux

```
# /opt/mellanox/bin/mst status
MST devices:
/dev/mt4099_pciconf0
/dev/mt4099_pci_cr0
```

To show the devices status with detailed information:

```
# /opt/mellanox/bin/mst status -vv
PCI devices:
DEVICE_TYPE          MST                PCI          RDMA    NET
NUMA
ConnectX4(rev:0)      mt4115_pciconf0    03:00.0      net-
vmnic4
ConnectX4(rev:0)      mt4115_pciconf0.1  03:00.1      net-
vmnic5
ConnectX3Pro(rev:0)   mt4103_pci_cr0     05:00.0      net-
vmnic1,netvmnic1000102
ConnectX3Pro(rev:0)   mt4103_pciconf0    05:00.0      net-
vmnic1,netvmnic1000102
```

For further information on In-Band and Remote Access, please refer to [In-Band Access to Multiple IB Subnets](#), [Accessing Remote InfiniBand Device by Direct Route MADs](#), and [Remote Access to Device by Sockets](#).

MFT Configuration

MFT configuration file resides in `/etc/mft/mft.conf`. It includes a list of defines and their values in the following syntax: `<DEF> = <value>`.

Note

This capability is available in Linux only.

MKey Configuration

In order to use the mft tools when the MKEY is configured, please edit the `/etc/mft.conf` file as shown below:

- `mkey_enable=yes` (default: no)
- `sm_config_dir=` (if empty, the SM config directory will be: `/var/cache/opensm/`)
- `sm_conf_file_path=<opensm configuration file full path>` (default `/etc/opensm/opensm.conf`)

mlxfwmanager – Firmware Update and Query Tool

The `mlxfwmanager` is a firmware update and query utility which scans the system for available NVIDIA devices (only mst PCI devices) and performs the necessary firmware updates.

For further information on firmware update, please refer to [Bootting HCA Device in Livefish Mode](#).

Note

The examples throughout the document use pci “bus.dev.fn” format. However, all the examples are inter-changeable with the `mlxfwmanager -d /dev/mst/<device>` format.

mlxfwmanager Synopsis

```
# [-d|--dev DeviceName] [-h|--help] [-v|--version] [--query] [--query-format Format] [-u|--update] [-i|--image-file FileName] [-D|--image-dir DirectoryName] [-f|--force] [-y|--yes] [--no] [--clear-semaphore] [--exe-rel-path] [-l|--list-content] [--archive-names] [--nofs] [--log] [-L|--log-file LogFileName] [--no-progress] [-o|--outfile OutputFileName] [--online] [--online-query-psid PSIDs] [--key key] [--download DirectoryName] [--download-default] [--get-download-opt OPT] [--download-device Device] [--download-os OS] [--download-type Type] [--ssl-certificate Certificate] [--no_fw_ctrl] [--component_type componentName] [--skip_if_same]
```

where:

<code>-d --dev DeviceName</code>	Perform operation for specified mst device(s). Run 'mst status' command to list the available devices. Multiple devices can be specified delimited by semicolons. A device list containing semicolons must be quoted.
<code>-h --help</code>	Show this message and exit.
<code>-v --version</code>	Show the executable version and exit.
<code>--query</code>	Query device(s) info

--query-format Format	(Query Onlinequery)outputformat,XML Text-defaultText
-u --update	Update firmware image(s) on the device(s).
-i --image-file FileName	Specified image file to use.
-D --image-dir DirectoryName	Specified directory instead of default to locate image files.
-f --force	Force image update
-y --yes	Answer is yes in prompts
--no	Answer is no in prompts
--clear-semaphore	Force clear the flash semaphore on the device, No command is allowed when this flag is used. NOTE: May result in system instability or flash corruption if the device or another application is currently using the flash. Exercise caution.
--exe-rel-path	Use paths relative to the location of the executable
-l --list-content	List file/Directory content, used with --image-dir and --image-file flags
--archive-names	Display archive names in listing
--nofs	Burn image in a non failsafe manner
--log	Create log file
-L --log-file LogFileName	Use specified log file
--no_fw_ctrl	Do not use firmware Ctrl update
--no-progress	Do not show progress
-o --outfile OutputFileName	Write to specified output file
--online	Fetch required FW images online from NVIDIA server
--online-query-psid PSIDs	Query FW info, PSID(s) are comma separated
--key key	Key for custom download/update
--download DirectoryName	Download files from server to a specified directory
--download-default	Use Default values for download
--get-download-opt OPT	Get download options for OS or Device Options are: OS, Device

<code>--download-device Device</code>	Use ' <code>--get-download-opt Device</code> ' option to view available devices for device specific downloads
<code>--download-os OS</code>	Only for self_extractor download: Use ' <code>--get-download-opt OS</code> ' option to view available OS for sfx download
<code>--download-type Type</code>	MFA self_extractor - default All
<code>--ssl-certificate Certificate</code>	SSL certificate for secure connection
<code>--component_type componentName</code>	Specify the PLDM component type to extract
<code>--skip_if_same</code>	Skip firmware update if current and new versions match

Querying the Device

To query a specific device, use the following command line:

```
# mlxfwmanager -d <device> --query
```

To query all the devices on the machine, use the following command line:

```
# mlxfwmanager --query
```

Examples:

Query the device.

```
mlxfwmanager -d 18:00.0 --query
Querying Mellanox devices firmware ...
```

```
Device #1:
-----
```

```

Device Type:      ConnectX7
Part Number:      CX713106AE-HEA_QP1_Ax
Description:      NVIDIA ConnectX-7 HHHL adapter Card; 200GbE
(default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0 x16 with x16
PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN
for internal use
PSID:             MT_00000000894
PCI Device Name:  18:00.0
Base MAC:         1070fd875230
Versions:         Current      Available
FW               28.43.0180    28.45.1008
PXE              N/A          3.7.0500
UEFI             N/A          14.38.0016

Status:           Update required
-----
Found 1 device(s) requiring firmware update. Please use -u flag
to perform the update.

```

Query all the devices.

```

Querying Mellanox devices firmware ...

```

```

Device #1:
-----

```

Device Type: ConnectX6
Part Number: MCX653106A-ECA_Ax
Description: ConnectX-6 VPI adapter card; H100Gb/s
(HDR100; EDR IB and 100GbE); dual-port QSFP56; PCIe3.0 x16; tall
bracket; ROHS R6

PSID: MT_0000000224
PCI Device Name: 0000:04:00.0
Base GUID: b8599f030023f954
Versions: Current Available
FW 20.43.1014 20.43.1014
PXE 3.7.0500 3.7.0500
UEFI 14.36.0016 14.36.0016

Status: Up to date

Device #2:

Device Type: ConnectX6LX
Part Number: MCX631102AN-ADA_Ax
Description: ConnectX-6 Lx EN adapter card; 25GbE ; Dual-
port SFP28; PCIe 4.0 x8; No Crypto

PSID: MT_0000000531
PCI Device Name: 0000:07:00.0
Base GUID: 0c42a1030060614c
Base MAC: 0c42a160614c
Versions: Current Available
FW 26.45.0386 26.45.1008
PXE 3.7.0500 3.7.0500

UEFI 14.38.0014 14.38.0016

Status: Update required

Device #3:

Device Type: ConnectX5
Part Number: MCX556A-ECA_Ax
Description: ConnectX-5 VPI adapter card; EDR IB (100Gb/s)
and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall bracket; ROHS R6
PSID: MT_0000000008
PCI Device Name: 0000:21:00.0
Base GUID: 248a0703008db026
Versions: Current Available
FW 16.35.3004 16.35.3004
PXE N/A 3.6.0902
UEFI N/A 14.29.0015

Status: Up to date

Device #4:

```

Device Type:      ConnectX4
Part Number:      MCX455A-FCA_Ax
Description:      ConnectX-4 VPI adapter card; FDR IB (56Gb/s)
and 40GbE; single-port QSFP28; PCIe3.0 x16; ROHS R6
PSID:             MT_2160111021
PCI Device Name:  0000:24:00.0
Base GUID:        8e0b01e681d98270
Versions:         Current          Available
FW                12.28.2006       12.28.2006
PXE               3.6.0102         3.6.0102
UEFI              14.21.0017       14.21.0017

Status:           Up to date

```

```

Device #5:
-----

```

```

Device Type:      ConnectX6LX
Part Number:      MCX631102AN-ADA_Ax
Description:      ConnectX-6 Lx EN adapter card; 25GbE ; Dual-
port SFP28; PCIe 4.0 x8; No Crypto
PSID:             MT_0000000531
PCI Device Name:  0000:0a:00.0
Base GUID:        0c42a10300a981fe
Base MAC:         0c42a1a981fe
Versions:         Current          Available
FW                26.45.0386       26.45.1008
PXE               3.7.0500         3.7.0500
UEFI              14.38.0014       14.38.0016

```

Status: Update required

Found 2 device(s) requiring firmware update. Please use -u flag to perform the update.

Query XML:

```
mlxfwmanager --query-format xml
<Devices>
  <Device pciName="0000:04:00.0" type="ConnectX6" psid="MT_0000000224"
partNumber="MCX653106A-ECA_Ax">
    <Versions>
      <FW current="20.43.1014" available="20.43.1014"/>
      <PXE current="3.7.0500" available="3.7.0500"/>
      <UEFI current="14.36.0016"
available="14.36.0016"/>
    </Versions>
    <GUIDs Base_Guid="b8599f030023f954" />
    <Status>Up to date</Status>
    <Description>ConnectX-6 VPI adapter card;
H100Gb/s (HDR100; EDR IB and 100GbE); dual-port QSFP56; PCIe3.0
x16; tall bracket; ROHS R6</Description>
  </Device>
  <Device pciName="0000:07:00.0" type="ConnectX6LX" psid="MT_0000000531"
partNumber="MCX631102AN-ADA_Ax">
    <Versions>
      <FW current="26.45.0386" available="26.45.1008"/>
      <PXE current="3.7.0500" available="3.7.0500"/>
```

```

        <UEFI current="14.38.0014"
available="14.38.0016"/>
    </Versions>
    <MACs Base_Mac="0c42a160614c" />
    <GUIDs Base_Guid="0c42a1030060614c" />
    <Status>Update required</Status>
    <Description>ConnectX-6 Lx EN adapter card; 25GbE
; Dual-port SFP28; PCIe 4.0 x8; No Crypto</Description>
</Device>
    <Device pciName="0000:21:00.0" type="ConnectX5" psid="MT_00000000008"
partNumber="MCX556A-ECA_Ax">
        <Versions>
            <FW current="16.35.3004" available="16.35.3004"/>
            <PXE current="N/A" available="3.6.0902"/>
            <UEFI current="N/A" available="14.29.0015"/>
        </Versions>
        <GUIDs Base_Guid="248a0703008db026" />
        <Status>Up to date</Status>
        <Description>ConnectX-5 VPI adapter card; EDR IB
(100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6</Description>
    </Device>
    <Device pciName="0000:21:00.0" type="ConnectX5" psid="MT_00000000008"
partNumber="MCX556A-ECA_Ax">
        <Versions>
            <FW current="16.35.3004" available="16.35.3004"/>
            <PXE current="N/A" available="3.6.0902"/>
            <UEFI current="N/A" available="14.29.0015"/>
        </Versions>
        <GUIDs Base_Guid="248a0703008db026" />
        <Status>Up to date</Status>
        <Description>ConnectX-5 VPI adapter card; EDR IB
(100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6</Description>
    </Device>
</Devices>

```

Archived Images Content

Supports listing the contents of images archive.

- When running this command, the tool will list all firmware images within this PLDM package for each image it displays.

Usage:

```
mlxfwmanager -i <pldm-path> --list-content
```

- When running this command, the tool will list all firmware images within this mfa package.

Usage:

```
mlxfwmanager -i <mfa-file> --list-content
```

For each image, it displays the following: PSID, Part Number, firmware version, and device description.

Updating the Device

To update a device on the machine, use the following command line: (Note: If only PXE rom needs update, please add -f to the command line.)

```
# mlxfwmanager -u -d <device> -i <existingMFAFile>
```

Update the device using PLDM:

```
mlxfwmanager -d <device> -i <pldm_package>
```

Example:

```
mlxfwmanager -u -d 18:00.0 -i /tmp/fw-ConnectX7-rel-28.45.1008.mfa
Querying Mellanox devices firmware ...

Device #1:
-----

Device Type:      ConnectX7
Part Number:      CX713106AE-HEA_QP1_Ax
Description:      NVIDIA ConnectX-7 HHHH adapter Card; 200GbE
(default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0 x16 with x16
PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN
for internal use
PSID:             MT_00000000894
PCI Device Name:  18:00.0
Base MAC:         1070fd875230
Versions:         Current      Available
FW               28.43.0180    28.45.1008
PXE              N/A          3.7.0500
UEFI             N/A          14.38.0016

Status:          Update required

-----

Found 1 device(s) requiring firmware update...
```

Updating the Device Online

To update the device online on the machine from website, use the following command line:

```
mlxfwmanager --online -u -d <device>
```

Example:

```
mlxfwmanager --online -u -d 21:00.0 -y
Querying Mellanox devices firmware ...

Device #1:
-----

Device Type:      ConnectX7
Part Number:      MCX75210AAS-NEA_Ax
Description:      NVIDIA ConnectX-7 HHHL Adapter Card; NDR IB;
Single-port OSFP; PCIe 5.0 2x8 in a row (Socket Direct); Crypto
Disabled; Secure Boot Enabled
PSID:             MT_00000000851
PCI Device Name:  /dev/mst/mt4129_pciconf0
Base GUID:        N/A
Base MAC:         N/A
Versions:         Current      Available
FW                28.43.1014    28.43.1014
PXE                3.7.0500      N/A
UEFI               14.36.0016    N/A

Status:           Forced update required

-----
Found 1 device(s) requiring firmware update...

Please wait while downloading MFA(s) 100%
Device #1: Updating FW ...
FSMST_INITIALIZE - OK
```

```
Writing Boot image component - OK
Done
```

```
Restart needed for updates to take effect.
```

Downloading Firmware Images and Firmware Update Packages

To download firmware images/firmware update packages, use the following command line:

```
mlxfwmanager --download <DownloadDir> --download-device
<DeviceType> --download-os <OS> --download-type <DownloadType>
```

To get the list of the supported devices or OSes, use the flag "--get-download-opt OPT"

```
mlxfwmanager --get-download-opt OS
esxi_6_5_native
esxi_6_native
fbsd10_64
linux
linux_arm64
linux_ppc64
linux_ppc64le
linux_x64
windows
windows_x64

mlxfwmanager --get-download-opt Device
All
```

Examples:

Downloading Firmware Images/Firmware Update Packages:

```
mlxfwmanager --download /tmp/DownloadDir --download-device All --  
download-os All --download-type self_extractor
```

```
----- Files To Be Downloaded -----
```

```
All :
```

```
-----
```

```
<Files>:
```

- 0 - linux_x64/mlxup
- 1 - windows/mlxup.exe
- 2 - esxi_6_native/mlxup
- 3 - windows_x64/mlxup.exe
- 4 - linux_ppc64/mlxup
- 5 - linux_arm64/mlxup
- 6 - linux_ppc64le/mlxup
- 7 - linux/mlxup
- 8 - fbsd10_64/mlxup
- 9 - esxi_6_5_native/mlxup

```
<Release Notes>:
```

For more details, please refer to the following FW release notes:

- 1- ConnectX3 (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-FW-2_42_5000-release_notes.pdf
- 2- ConnectX3Pro (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-Pro-FW-2_42_5000-release_notes.pdf
- 3- Connect-IB (10.16.1200): http://www.mellanox.com/pdf/firmware/ConnectIBFW-10_16_1200-release_notes.pdf
- 4- ConnectX4 (12.28.2008):
<https://docs.mellanox.com/display/ConnectX4Firmwarev12282006>
- 5- ConnectX4Lx (14.30.1004):
<https://docs.mellanox.com/display/ConnectX6LxFirmwarev14301004>
- 6- ConnectX5 (16.30.1004):
<https://docs.mellanox.com/display/ConnectX5Firmwarev16301004>

```
7- ConnectX6 (20.30.1004):  
https://docs.mellanox.com/display/ConnectX6Firmwarev20301004  
8- ConnectX6Dx (22.30.1004):  
https://docs.mellanox.com/display/ConnectX6DxFirmwarev22301004  
9- ConnectX6Lx (26.30.1004):  
https://docs.mellanox.com/display/ConnectX6LxFirmwarev26301004  
10- BlueField (18.30.1004): N/A  
11- BlueField2 (24.30.1004): N/A
```

Perform Download? [y/N]: y

Please wait while downloading Files to : '/tmp/DownloadDir'

```
0 - linux_x64/mlxup : Done  
1 - windows/mlxup.exe : Done  
2 - esxi_6_native/mlxup : Done  
3 - windows_x64/mlxup.exe : Done  
4 - linux_ppc64/mlxup : Done  
5 - linux_arm64/mlxup : Done  
6 - linux_ppc64le/mlxup : Done  
7 - linux/mlxup : Done  
8 - fbsd10_64/mlxup : Done  
9 - esxi_6_5_native/mlxup : Done
```

Downloading file(s) to : '/tmp/DownloadDir' is done successfully

Downloading firmware images/firmware update packages using custom key:

```
mlxfwmanager --download /tmp/DownloadDir --download-device All --  
download-os All --download-type All --key last_release
```

```
----- Files To Be Downloaded -----
```

```
All :
```

<Files>:

- 0 - Mellanox_Firmware_20210407.mfa
- 1 - linux_x64/mlxup
- 2 - windows/mlxup.exe
- 3 - esxi_6_native/mlxup
- 4 - windows_x64/mlxup.exe
- 5 - linux_ppc64/mlxup
- 6 - linux_arm64/mlxup
- 7 - linux_ppc64le/mlxup
- 8 - linux/mlxup
- 9 - fbsd10_64/mlxup
- 10 - esxi_6_5_native/mlxup

<Release Notes>:

For more details, please refer to the following FW release notes:

For more details, please refer to the following FW release notes:

1- ConnectX3 (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-FW-2_42_5000-release_notes.pdf

2- ConnectX3Pro (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-Pro-FW-2_42_5000-release_notes.pdf

3- Connect-IB (10.16.1200): http://www.mellanox.com/pdf/firmware/ConnectIBFW-10_16_1200-release_notes.pdf

4- ConnectX4 (12.28.2008):
<https://docs.mellanox.com/display/ConnectX4Firmwarev12282006>

5- ConnectX4Lx (14.30.1004):
<https://docs.mellanox.com/display/ConnectX6LxFirmwarev14301004>

6- ConnectX5 (16.30.1004):
<https://docs.mellanox.com/display/ConnectX5Firmwarev16301004>

7- ConnectX6 (20.30.1004):
<https://docs.mellanox.com/display/ConnectX6Firmwarev20301004>

8- ConnectX6Dx (22.30.1004):
<https://docs.mellanox.com/display/ConnectX6DxFirmwarev22301004>

9- ConnectX6Lx (26.30.1004):
<https://docs.mellanox.com/display/ConnectX6LxFirmwarev26301004>

```
10- BlueField (18.30.1004): N/A
11- BlueField2 (24.30.1004): N/A
```

```
Perform Download? [y/N]: y
```

```
Please wait while downloading Files to : '/tmp/DownloadDir'
```

```
0 - Mellanox_Firmware_20210407.mfa : Done
1 - linux_x64/mlxup : Done
2 - windows/mlxup.exe : Done
3 - esxi_6_native/mlxup : Done
4 - windows_x64/mlxup.exe : Done
5 - linux_ppc64/mlxup : Done
6 - linux_arm64/mlxup : Done
7 - linux_ppc64le/mlxup : Done
8 - linux/mlxup : Done
9 - fbsd10_64/mlxup : Done
10 - esxi_6_5_native/mlxup : Done
```

```
Downloading file(s) to : '/tmp/DownloadDir' is done successfully
```

UPMF

Update Package for NVIDIA Firmware (UPMF) is a new method used to distribute firmware to end users. Instead of providing multiple binary files (one for each board type) and burning them using the flint tool, the UPMF method requires only a single standalone file.

The UPMF is a self-extracting executable that contains a set of firmware binary images, and the mlxfwmanager firmware update tool.

UPMF provides:

- Single file per firmware release
- Simple 'one click' firmware update
- Compact size (achieved by efficient compression of the firmware images)

- No installation required

When executed, the UPMF:

- Extracts its content into a temporary location
- Scans the locally installed NVIDIA devices firmware versions
- Performs firmware updates if needed
- Cleans up temporary files

UPMF Generation Flow

The `mlx_fwsfx_gen` tool is used for OEMs that wish to create their own UPMFs that contain their own customized firmware images.

To install the `mlx_fwsfx_gen` tool, the installation script should be run with the "`--oem`" command line option.

mlx_fwsfx_gen Usage

This tool packs the firmware images provided in the input directory and the `mlxfwmanager` update tool into a single standalone self-extracting executable.

The UPMF generation is supported on Linux and Windows. Being an executable file, the UPMF should be prepared for Linux and Windows separately.

Usage:


```
# mlx_fwsfx_gen --source-dir <FW images directory> --out-dir
<output directory> [--sfx-name <sfx file name>] [--phy-support --
phy-img <phy-img>][--extra-args <args>]
```

where:

<code>--source-dir</code>	Directory containing NVIDIA firmware images to be included in the package. This option may be used more than once to specify more than one source directory.
---------------------------	--

--out-dir	Specifies the output directory.
--certificate	SSL certificate.
--phy-support	Generate extractor with mlxphyburn support.
--phy-img	PHY firmware image.
--sfx-name	The self-extracting executable filename. The default name is mlxfwmanager-YYYYMMDD-<build number>, where build number is the previous maximum build number existing in the output directory incremented by one.
--extra-args	Extra args passed to mlxfwmanager default arguments. In the case of multiple args, the args are separated by commas. For example: [--extra-args --ret-lvim,--online]

UPMF Package Generation Flow



UPMF Generation Example

The below example packs 3 firmware binaries (named fw-ConnectX-3-1.bin, fw-ConnectX-3-2.bin, fw-ConnectX-3-3.bin) located in the directory '/tmp/fw-ConnectX-3-dir/' into a Linux UPMF package named /tmp/mlxfwmanager-20171004-1.

```
mlx_fw_sfx_gen --source-dir /tmp/fw-ConnectX-3Pro-dir/ --out-dir /tmp/
```

```
Package name: /tmp/mlxfwmanager-20171004-1
Contents:
Source dirs: /tmp/fw-ConnectX-3Pro-dir
Adding file: /etc/mft/ca-bundle.crt
sfx_stub file: /usr/bin/mlx_sfx_stub
Creating intermediate MFA archive from binary files:
4779-314A-X00_Ax~ATT1090111023.bin
Huawei_TD70VMTA_VA_CX3Pro_2P_40G_Ax~HUA0020010017.bin
Inventec_U50_CX3Pro_10GE_A1~INV0010110023.bin
MCX342A-XCQ_Ax~MT_1680116023.bin
MCX353A-FCC_Ax~MT_1100111019.bin
mfa tool: /usr/bin/mlx_mfa_gen
mfa cmd: /usr/bin/mlx_mfa_gen -p /tmp/OMs1D5PvHq/srcs.mfa -s
/tmp/fw-ConnectX-3Pro-dir
Adding bins from /tmp/fw-ConnectX-3Pro-dir
Files copied: 5
Querying images ...
Files queried: 5
Compressing ... (this may take a minute)
Archive: /tmp/OMs1D5PvHq/srcs.mfa
Total time: 0m3s
Adding file: /tmp/OMs1D5PvHq/srcs.mfa
Adding file: /usr/bin/mlxfwmanager
Creating zip /tmp/OMs1D5PvHq/zippackage.zip
adding: srcs.mfa (deflated 0%)
adding: mlxfwmanager (deflated 52%)
adding: ca-bundle.crt (deflated 45%)
sfx auto-run command:
mlxfwmanager -u --log-on-update --ssl-certificate %ca-bundle.crt%
%current-dir% %argv%
Log name: /tmp/mlxfwmanager-20171004-1.log
```

UPMF Generation with PHY Binary Example

The below example packs 3 firmware binaries (named fw-ConnectX-3-1.bin, fw-ConnectX-3-2.bin, fw-ConnectX-3-3.bin) located in the directory '/tmp/fw-ConnectX-3-dir/' and a

PHY image '/tmp/Firmware_1.37.10_N32722.cld' into a Linux UPMF package named /tmp/mlxfwmanager-20141126-2.

```
mlx_fwsfx_gen --source-dir /tmp/fw-ConnectX-3-dir --out-dir /tmp
--phy-support --phy-img /tmp/
Firmware_1.37.10_N32722.cld
```

Creating /tmp/C04TldeQHr/phy_mfa direcotry

Package name: /tmp/mlxfwmanager-20141126-2

Contents:

Source dirs: /tmp/fw-ConnectX-3-dir

Adding file: /etc/mft/ca-bundle.crt

sfx_stub file: /usr/bin/mlx_sfx_stub

Creating intermediate MFA archive from binary files:

fw-ConnectX-3-1.bin

fw-ConnectX-3-2.bin

fw-ConnectX-3-3.bin

mfa tool: /usr/bin/mlx_mfa_gen

mfa cmd: /usr/bin/mlx_mfa_gen -p /tmp/YaH5BAoQ8q/srcs.mfa -s
/tmp/fw-ConnectX-3-dir

Adding bins from /tmp/fw-ConnectX-3-dir

Files copied: 3

Querying images ...

Files queried: 3

Compressing ... (this may take a minute)

Archive: /tmp/YaH5BAoQ8q/srcs.mfa

Total time: 0m1s

Adding file: /tmp/YaH5BAoQ8q/srcs.mfa

Adding file: /usr/bin/mlxfwmanager

Copying /tmp/Firmware_1.37.10_N32722.cld to
/tmp/C04TldeQHr/phy_mfa

Adding file: /tmp/Firmware_1.37.10_N32722.cld


```

Adding file: /usr/bin/mlxphyburn
Creating zip /tmp/YaH5BAoQ8q/zippackage.zip
adding: srcs.mfa (deflated 0%)
adding: ca-bundle.crt (deflated 45%)
adding: phy_mfa/ (stored 0%)
adding: phy_mfa/Firmware_1.37.10_N32722.cld (deflated 44%)
adding: mlxfwmanager (deflated 57%)
adding: mlxphyburn (deflated 60%)
sfx auto-run command:
mlxfwmanager -u --log-on-update --ssl-certificate %ca-bundle.crt%
%current-dir% %argv%
mlxphyburn auto-run command:
mlxphyburn %device% -i ./phy_mfa/Firmware_1.37.10_N32722.cld b
Log name: /tmp/mlxfwmanager-20141126-2.log

```

Updating Firmware Using an UPMF

Updating the firmware is done by simply executing the UPMF. Most of the command line options of the mlxfwmanager tool apply also for the UPMF.

For further detail, please refer to [mlxfwreset - Loading Firmware on 5th Generation Devices Tool](#).

Some of the most commonly used command line options are:

--force	Force firmware update even if the firmware in the UPMF is not newer than the one on the device.
--yes	Non-interactive mode - assume 'yes' to all questions.

In addition to the mlxfwmanager tool command line options, the UPMF has 2 additional options:

Additional UPMF self extractor options:

--sfx-extract-dir <dir>	Use <dir> for temporary files during execution
-------------------------	--

--sfx-no-pause

Do not wait for user keypress after completion.
Note: This flag is used in Windows OSs.

Extraction Example

```
# mlxfwmanager-20130717-1 --sfx-extract-dir ./mydir --sfx-extract-only  
Extracting to mydir/mlxfwmanager-20130717-1 ... Done
```

Run the firmware update command:

```
# ./mydir/mlxfwmanager-20130717-1/mlxfwmanager -u
```

mlxarchive – Binary Files Compression Tool

Note

mlxarchive is not installed by default, and requires installing MFT with the `--oem` option.

The mlxarchive tool allows the user to create a file with the MFA2 extension. The new file contains several binary files of a given firmware for different adapter cards.

mlxarchive accepts the following attributes as its input:

- --bins-dir - The path to a folder with the binary files that will be included in the MFA2 file
- --version - The MFA2 file's version

- --out-file - The output of the mlxarchive file (MFA2 file)
- -m|--mfa2-file mfa2_file - MFA2 file to parse

Example:

```
mlxarchive --bins-dir /full/path/to/bin/directory/ --version 1.1.1
--out-file out.mfa2 mlxarchive --mfa2-file out.mfa2
Creation Time   : 2019-09-18 08:35:43
Devices        2
PSID           : <...>
Num of Images   1
Index          0
Version        : 10.16.1200
Date           : 2019-09-18 08:35:43 PSID   : <...>
Num of Images   1
Index          1
Version        : 10.16.1200
Date           : 2019-09-18 08:35:43
```

mlxarchive Synopsis

```
[--help] [--version version] [--out-file out_file] [--bins-dir
bins_dir] [-m|--mfa2-file mfa2_file]
```

where:

--help	Shows the help message and exit
--version version	MFA2's version in the following format: x.x.x
--out-file out_file	The output file
-bins-dir bins_dir	The directory with the binaries files
-m --mfa2-file mfa2_file	Mfa2 file to parse

Info

The .mfa2 file can be used with ethtool to burn adapter cards firmware. The procedure is described in [Updating Firmware Using ethtool/devlink and .mfa2 File](#) section.

mlxconfig – Changing Device Configuration Tool

The mlxconfig tool allows the user to change some of the device configurations without reburning the firmware. The configuration is kept after reset.

By default, mlxconfig shows the configurations that will be loaded in the next boot. For 5th generation devices, it is also possible to query the default configurations and the configurations that are used by the current running firmware.

Tool Requirements

- mst driver loaded
- OFED/WinOF driver to be installed and enabled
- Access to the device through the PCI interface (pciconf/pci_cr)
- Changing device configurations enabled

Note

For changes after a successful configuration to take effect, reboot the system.

mlxconfig Synopsis

```
# mlxconfig [Options] <commands> [Parameters]
```

where:

-d --dev <device>	Performs operation for a specified mst device.
-b --db <filename>	Use a specific database file.
-f --file <conf.file>	Raw configuration file.
-h --help	Displays help message.
-v --version	Displays version info.
-e --enable_verbosity	Show default and current configurations. Note: For 5th generation (Group II) devices, the --enable_verbosity option works with ConnectX-4 firmware v12.14.0016 and above for querying the default configurations, and with ConnectX-4 firmware v12.17.1010 and above for querying the current configurations.
-j --json_format <file>	Save the query output to file in JSON format, only usable with Query command.
-y --yes	Answers yes in prompt.
--with_default	Set command will fill any missing parameters with default values. If the final configurations matches the current, no set will be done.
-a --all_attrs	Show all attributes in the XML template.
--host_id	Specify host id for Per-Host TLV (class 3).
--pf_index	Specify PF index for Per-Host TLV (class 3).
-p --private_key	pem file for private key.
-u --key_uuid	keypair uuid.
-eng --openssl_engine	OpenSSL engine name.
-k --open_ssl_key_id	OpenSSL key identifier
--aws_hsm	Sign in 3S environment.
-l --private_key_label	Private key label to use for 3S HSM sign.
-t --device_type	Specify the device type.

<switch/hca/linkx>	
--i2c_secondary	Specify I2C secondary address.
-s --session_id	Specify the session id for token keep alive session.
-st --session_time	Specify session time for token keep alive session.
-tkn --token_type	Specify token type.
--sign_algorithm	Specify a signature algorithm from the following: RSA4k, RSA3k or ECDSA256.
--nested_token	Include challenge response for ArcusE.
clear_semaphore	Clear the tool's semaphore.
i[show_confs]	Display information about all configurations.
q[query]	Queries the supported configurations. Note: Query command will query a single device if a device is specified. Otherwise, it will query all devices on the machine.
r[reset]	Resets configurations to their default value.
s[et]	Sets configurations to a specific device.
set_raw	Sets raw configuration file (5th generation/Group II devices only).
get_raw	Gets raw configuration file (5th generation/Group II devices only).
backup	Backs up configurations to a file (only 5th generation (Group II) devices). Use set_raw command to restore file.
gen_tlvs_file	Generate a List of all TLVs. TLVs output file name must be specified.
g[en_xml_template]	Generate an XML template. TLVs input file name and XML output file name must be specified.
xml2raw	Generate a Raw file from an XML file. XML input file name and raw output file name must be specified.
raw2xml	Generate an XML file from a Raw file. raw input file name and XML output file name must be specified.
xml2bin	Generate binary configuration dump file from XML file. XML input file name and bin output file name must be specified.
create_conf	Generate configuration file from XML file. XML input file name and bin output file name must be specified.

apply	Apply a configuration file, that was created with create_conf command. bin input file name must be specified.
challenge_request	Send a token challenge request to the device. Token type must be specified.
remote_token_keep_alive	Start a remote token session for a specified time. session id must be specified.
token_supported	Query which tokens are supported.
query_token_session	Query the status of a token session.
end_token_session	End an active token session.

Bifurcation Configuration

Before working with the Lego Softbank CG1 and Lego C2 flavors, make sure that the device is set to NIC mode (CPU as a RC). Please use the following commands, as specified in the "CPU as RC" column.

Lego Configuration

Configuration of Lego Systems	CPU as RC	DPU as RC
Configuration to bifurcation mode	To configure a BlueField-3 card as a "CPU is RC" of NVMe (DPU as PCIe switch): <pre>mlxconfig -d /dev/mst/mt41692_pciconf0 -y reset</pre> <pre>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_SWITCH0_UPSTRAEM_PORT_BUS=0</pre> <pre>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_SWITCH0_UPSTRAEM_PORT_PEX=0</pre> <pre>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS00_HIERARCHY_TYPE=1</pre> <pre>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS00_WIDTH=5</pre>	To configure a BlueField-3 card "DPU is RC" of NVMe (using SN towards the CPU): <pre>mlxconfig -d /dev/mst/mt41692_pcicon reset</pre> <pre>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS00_HIERARCHY_T</pre> <pre>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS00_WIDTH=5</pre> <pre>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS00_SPEED=4</pre>

Configuration of Lego Systems	CPU as RC	DPU as RC
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS00_SPEED=4</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS10_HIERARCHY_T</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS10_HIERARCHY_TYPE=1</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS10_WIDTH=3</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS10_WIDTH=3</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS10_SPEED=4</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS10_SPEED=4</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS12_HIERARCHY_T</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS12_HIERARCHY_TYPE=1</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS12_WIDTH=3</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS12_WIDTH=3</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS12_SPEED=4</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS12_SPEED=4</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS14_HIERARCHY_T</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS14_HIERARCHY_TYPE=1</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS14_WIDTH=3</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS14_WIDTH=3</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS14_SPEED=4</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS14_SPEED=4</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS16_HIERARCHY_T</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS16_HIERARCHY_TYPE=1</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS16_WIDTH=3</code>
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS16_WIDTH=3</code>	<code>mlxconfig -d /dev/mst/mt41692_pcicon s PCI_BUS16_SPEED=4</code>

Configuration of Lego Systems	CPU as RC	DPU as RC
	<code>mlxconfig -d /dev/mst/mt41692_pciconf0 -y s PCI_BUS16_SPEED=4</code>	
Configuring the card in NIC mode	<code># mlxconfig -d /dev/mst/mt41692_pciconf0 s INTERNAL_CPU_OFFLOAD_ENGINE=1</code>	<code># mlxconfig -d /dev/mst/mt41692_pcicon INTERNAL_CPU_OFFLOAD_EN</code>

Examples of mlxconfig Usage

Querying the Device Configuration

To query the device's configuration, use the following command line:

```
# mlxconfig -d <device> query
```

ConnectX-3 Example:

```
# mlxconfig -d /dev/mst/mt4099_pciconf0 q
```

```
Device type: ConnectX-3
PCI device: /dev/mst/
/dev/mst/mt4099_pciconf0
```

```
Device 1:
```

```
-----
```

```
Configurations:      Next Boot
    SRIOV_EN          True(1)
    NUM_OF_VFS        16
    WOL_MAGIC_EN_P1   False(0)
```

Note

N/A means that the device default configuration is set.

Note

For Array type parameters, the query command will not show a value for it. It will only show you the word "Array" and the range of the array.

- For example: HOST_CHAINING_DESCRIPTOR Array[0..7]
- To query the fifth element in the array, run: `mlxconfig -d <device> query HOST_CHAINING_DESCRIPTOR[5]`
- To specify a range: `mlxconfig -d <device> query HOST_CHAINING_DESCRIPTOR[3..7]`
- To set the fifth element in the array, run: `mlxconfig -d <device> set HOST_CHAINING_DESCRIPTOR[5]=3`
- Or you can set value for more than one element: `mlxconfig -d <device> set HOST_CHAINING_DESCRIPTOR[3..7]=3`

ConnectX-4 Lx Example:

```
# mlxconfig -d /dev/mst/mt4117_pciconf0 --enable_verbosity q

Device #1:
-----
Device type: ConnectX4LX
```

```
PCI device: /dev/mst/mt4117_pciconf0
```

```
Configurations:      Default      Current      Next Boot
* NUM_OF_VFS         8          5          5
  SRIOV_EN           True(1)     True(1)     True(1)
The '*' shows parameters with next value different from
default/current value.
```

Setting Device Configuration

To set the device configuration, use the following command line:

```
# mlxconfig -d <device> set [Parameters....]
```

Example:

```
# mlxconfig -d /dev/mst/mt4099_pciconf0 set WOL_MAGIC_EN_P2=1
NUM_OF_VFS=24
Device type: ConnectX-3
PCI device: /dev/mst/mt4099_pciconf0
Configurations:      Next Boot      New
  NUM_OF_VFS         16          24
  WOL_MAGIC_EN_P2    False(0)     True(1)

Apply new Configuration?(y/n) [n]: y
Applying... Done!

-I- Please reboot the system to load new configurations.
```

Resetting Device Configuration to Default

To reset the device configuration to default, use the following command line:

```
# mlxconfig -d <device> reset
```

Example:

```
# mlxconfig -d /dev/mst/mt4099_pciconf0 reset
Reset configuration for device /dev/mst/mt4099_pciconf0? ? (y/n)
[n] : y
Applying... Done!
```

```
-I- Please power-cycle device to load new configurations.
>mlxconfig -d /dev/mst/mt4099_pciconf0 query
```

```
Device 1:
-----
Device type: ConnectX-3
PCI Device: /dev/mst/mt4099_pciconf0
Configurations:      Next Boot
  SRIOV_EN            True(1)
  NUM_OF_VFS          8
  WOL_MAGIC_EN_P1     False(0)
  WOL_MAGIC_EN_P2     False(0)
```

Setting Missing Parameters with Default Values

Set of commands that will fill any missing parameters with default values. If the final configurations matches the current, no set will be done.

```
# mlxconfig -d <device> --with_default set BOOT_LACP_DIS=False
```

Example:

```
# mlxconfig -d /dev/mst/mt41692_pciconf0 --with_default set
BOOT_LACP_DIS=False
Found a difference, first difference on the list is
VIRTIO_BLK_EMULATION_NUM_MSIX from val 0 to 2
continue to reset and set

Apply reset and set? (y/n) [n] : y

Device #1:
-----

Device type:          BlueField3
Name:                 900-9D3B6-00CV-AAB_Ax
Description:          Nvidia BlueField-3 BF3220 P-Series DPU
200GbE/NDR200 dual-port QSFP112; PCIe Gen5.0 x16 FHHL with x16
PCIe extension option; Crypto Enabled; SB Disabled 32GB on-board
DDR; integrated BMC; Tall Bracket; IPN QP
Device:               /dev/mst/mt41692_pciconf0

Configurations:                                     Next
Boot          New
              BOOT_LACP_DIS                          True(1)
False(0)
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Configuring Per-Host TLV Parameters: Host ID and PF Index

Used to define the target host and physical function for Class 3 Per-Host TLV operations.

```
# mlxconfig -d /dev/mst/mt41692_pciconf0 --host_id 1 --pf_index 1
set ROCE_CONTROL=2
```

Example:

```
# mlxconfig -d /dev/mst/mt41692_pciconf0 --host_id 1 --pf_index 1
set ROCE_CONTROL=2
```

Device #1:

Device type: BlueField3

Name: 900-9D3B6-00CV-AAB_Ax

Description: Nvidia BlueField-3 BF3220 P-Series DPU
200GbE/NDR200 dual-port QSFP112; PCIe Gen5.0 x16 FHHL with x16
PCIe extension option; Crypto Enabled; SB Disabled 32GB on-board
DDR; integrated BMC; Tall Bracket; IPN QP

Device: /dev/mst/mt41692_pciconf0

Configurations: Next

Boot New

ROCE_CONTROL

ROCE_ENABLE(2) ROCE_ENABLE(2)

Apply new Configuration? (y/n) [n] : y

Applying... Done!

-I- Please reboot machine to load new configurations.

Using mlxconfig

Using mlxconfig with PCI Device in Bus Device Function (BDF) Format

In order to access device in BDF format via configuration cycles, use "pciconf-" as prefix to the device.

Example:

```
# mlxconfig -d 0000:86:00.0 q
```

Device #1:

Device type: ConnectX5

Name: MCX556A-ECA_Ax

Description: ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall bracket; ROHS R6

Device: 0000:86:00.0

Configurations:

Next Boot

MEMIC_BAR_SIZE	0
MEMIC_SIZE_LIMIT	_256KB(1)
HOST_CHAINING_MODE	DISABLED(0)
HOST_CHAINING_CACHE_DISABLE	False(0)
HOST_CHAINING_DESCRIPTOR	Array[0..7]
HOST_CHAINING_TOTAL_BUFFER_SIZE	Array[0..7]
FLEX_PARSER_PROFILE_ENABLE	0
FLEX_IPV4_OVER_VXLAN_PORT	0
ROCE_NEXT_PROTOCOL	254
ESWITCH_HAIRPIN_DESCRIPTOR	Array[0..7]
ESWITCH_HAIRPIN_TOT_BUFFER_SIZE	Array[0..7]
PF_BAR2_SIZE	0
NON_PREFETCHABLE_PF_BAR	False(0)
VF_VPD_ENABLE	False(0)
STRICT_VF_MSIX_NUM	False(0)
VF_NODNIC_ENABLE	False(0)

```

NUM_OF_VFS                                0
PARTIAL_WRITE_CACHE_MODE                  DEVICE_DEFAULT(0)
PF_BAR2_ENABLE                            False(0)
SRIOV_EN                                  False(0)
PF_LOG_BAR_SIZE                            5
.....

```

Using mlxconfig to Set IB/ETH Parameters

In order to set IB/ETH parameters through mlxconfig, use the following command line:

```

# mlxconfig -d <device> set [LINK_TYPE_P1=<link_type>]
[LINK_TYPE_P2=<link_type>]

```

Example: Configuring both ports as InfiniBand:

```

# mlxconfig -d /dev/mst/mt4119_pciconf0 set LINK_TYPE_P1=1
LINK_TYPE_P2=1

Device #1:
-----
Device type:    ConnectX5
Name:           MCX556A-ECA_Ax
Description:    ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and
100GbE; dual-port QSFP28; PCIe3.0 x16; tall bracket; ROHS R6
Device:         /dev/mst/mt4119_pciconf0

Configurations:
LINK_TYPE_P1
IB(1)
LINK_TYPE_P2
IB(1)
Next Boot
ETH(2)
New
ETH(2)

```



```
Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Using mlxconfig to Set PHY Parameters

Setting Auto Negotiation

Auto negotiation modes is displayed at mlxconfig available configuration menu (Using <i>command</i>).

In order to set non-volatile auto negotiation mode through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [PHY_AUTO_NEG_P1=
<auto_negotiation_mode>] [PHY_AUTO_NEG_P2=
<auto_negotiation_mode>]
```

Example: Configuring both ports with auto negotiation enabled:

```
# mlxconfig -d /dev/mst/mt4129_pciconf0 set PHY_AUTO_NEG_P1=1
PHY_AUTO_NEG_P2=1

Device #1:
-----

Device type:    ConnectX7
Name:           CX713106AE-HEA_QP1_Ax
Description:    NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default
mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0 x16 with x16 PCIe
extension option; Crypto Enabled; Secure Boot Capable; IPN for
internal use
Device:         /dev/mst/mt4129_pciconf0
```

Configurations:

Next Boot

New

PHY_AUTO_NEG_P1

DEVICE_DEFAULT(0) AUTO_NEG_ENABLED(1)

PHY_AUTO_NEG_P2

DEVICE_DEFAULT(0) AUTO_NEG_ENABLED(1)

Apply new Configuration? (y/n) [n] : y

Applying... Done!

-I- Please reboot machine to load new configurations.

Setting Speed Rate Mask

Speed rate mask enables masking device's available speeds in all link operational modes.

Speed masking requires defining the speed rate mask and enabling speed override configuration.

In order to set non-volatile speed rate mask through mlxconfig, verify first that override mask is enabled using the following command:

```
# mlxconfig -d <device> set [PHY_RATE_MASK_OVERRIDE_P1=  
<True|False>] [PHY_RATE_MASK_OVERRIDE_P2=<True|False>]
```

Example: Enabling both ports' speed mask override:

```
# mlxconfig -d /dev/mst/mt4129_pciconf0 set  
PHY_RATE_MASK_OVERRIDE_P1=1 PHY_RATE_MASK_OVERRIDE_P2=1
```

Device #1:

```

Device type:    ConnectX7
Name:          CX713106AE-HEA_QP1_Ax
Description:    NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default
mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0 x16 with x16 PCIe
extension option; Crypto Enabled; Secure Boot Capable; IPN for
internal use
Device:        /dev/mst/mt4129_pciconf0

Configurations:                                Next Boot
New
    PHY_RATE_MASK_OVERRIDE_P1                  False(0)
True(1)
    PHY_RATE_MASK_OVERRIDE_P2                  False(0)
True(1)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

Configure the wanted speed mask using the following command:

```

# mlxconfig -d <device> set [PHY_RATE_MASK_P1=<rate_mask>]
[PHY_RATE_MASK_P2=<rate_mask>]

```

The rate mask mapping is displayed at mlxconfig available configuration menu (Using <i> command).

Example: Enabling both ports to support CAUI-4 / 100GBASE-CR4 only:

```

# mlxconfig -d /dev/mst/mt4129_pciconf0 set
PHY_RATE_MASK_P1=0x200 PHY_RATE_MASK_P2=0x200

Device #1:

```

Device type: ConnectX7
Name: CX713106AE-HEA_QP1_Ax
Description: NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0 x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
Device: /dev/mst/mt4129_pciconf0

Configurations:	Next Boot
New	

PHY_RATE_MASK_P1	0
0x200(512)	
PHY_RATE_MASK_P2	0
0x200(512)	

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

Setting FEC Mode

Customizes FEC configuration of the port.

Detailed information on FEC modes is displayed at mlxconfig available configuration menu (Using *command*).

In order to set non-volatile FEC mode through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [PHY_FEC_OVERRIDE_P1=<fec_mode>]  
[PHY_FEC_OVERRIDE_P2=<fec_mode>]
```

Example: Setting FEC mode disabled DME, RS FEC for 25G/50G/100G for both port:

```
# mlxconfig -d /dev/mst/mt4129_pciconf0 set
PHY_FEC_OVERRIDE_P1=0x2 PHY_FEC_OVERRIDE_P2=0x2

Device #1:
-----

Device type:      ConnectX7
Name:             CX713106AE-HEA_QP1_Ax
Description:      NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default
mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0 x16 with x16 PCIe
extension option; Crypto Enabled; Secure Boot Capable; IPN for
internal use
Device:           /dev/mst/mt4129_pciconf0

Configurations:                                     Next Boot
New
    PHY_FEC_OVERRIDE_P1
DEVICE_DEFAULT(0) MODE_2(2)
    PHY_FEC_OVERRIDE_P2
DEVICE_DEFAULT(0) MODE_2(2)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Using mlxconfig to Set SR-IOV Parameters

In order to set SR-IOV parameters through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [SRIOV_EN=<0|1>] [NUM_OF_VFS=<NUM>]
```

Example: Turning on SR-IOV and enabling 8 Virtual Functions per Physical Function:

```
# mlxconfig -d /dev/mst/mt4115_pciconf0 set SRIOV_EN=1
NUM_OF_VFS=8

Device #1:
-----
Device type:      ConnectX4
PCI device:       /dev/mst/mt4115_pciconf0
Configurations:   Next Boot      New
  SRIOV_EN        0              1
  NUM_OF_VFS      0              8

Apply new Configuration? ? (y/n) [n] : y Applying... Done!
-I- Please reboot machine to load new configurations.
```

Using mlxconfig to Set Preboot Settings

For a full description of the preboot configurable parameters, refer to [Supported Configurations and their Parameters](#) under "Preboot Settings".

Example: Enable boot option ROM on port 1, set boot retries to 3 and set the boot protocol to PXE (on ConnectX-3 Pro cards only).

```
# mlxconfig -d /dev/mst/mt4103_pciconf0 set
BOOT_OPTION_ROM_EN_P1=1 BOOT_RETRY_CNT_P1=3
LEGACY_BOOT_PROTOCOL_P1=1

Device #1:
-----
Device type:      ConnectX3Pro
PCI device:       /dev/mst/mt4103_pciconf0
Configurations:   Next Boot      New
  BOOT_OPTION_ROM_EN_P1      False(0)      True(1)
  BOOT_RETRY_CNT_P1          0              3
  LEGACY_BOOT_PROTOCOL_P1    2              1
```

```
Apply new Configuration? ? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Example: Configure VLAN ID to 3 on port 2

```
# mlxconfig -d /dev/mst/mt4119_pciconf0 set BOOT_VLAN=3

Device #1:
-----
Device type:    ConnectX5
Name:          MCX556A-ECA_Ax
Description:    ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and
100GbE; dual-port QSFP28; PCIe3.0 x16; tall bracket; ROHS R6
Device:        /dev/mst/mt4119_pciconf0

Configurations:                                Next Boot      New
          BOOT_VLAN                             1                3

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Using mlxconfig to Split a Port in a Remotely Managed Switch

The break-out cable is a unique NVIDIA capability, where a single physical quad-lane HDR or NDR port is divided into 2 dual-lane ports. It maximizes the flexibility of the end user to use the NVIDIA switch with a combination of dual-lane and quad-lane interfaces according to the specific requirements of its network. All system ports may be split into 2-lane ports. Splitting a port changes the notation of that port -

- In HDR ports:

From x/y to x/y/z, with “x/y” indicating the previous notation of the port prior to the split, and “z” indicating the number of the resulting sub-physical port (1,2). Each sub-physical port is then handled as an individual port. For example, splitting port 5 into 2 lanes gives the following new ports: 1/5/1 & 1/5/2.

- In NDR ports:

From x/y/z to x/y/z/i, with “x/y/z” indicating the previous notation of the port prior to the split, and “i” indicating the number of the resulting single-lane port (1,2). Each sub-physical port is then handled as an individual port. For example, splitting port 1/5/1 into 2 lanes results in ports 1/5/1/1 and 1/5/1/2.



To enable the port split, the following actions are required:

Step 1. Set the Split Mode in a Remotely Managed Switch.

```
# mlxconfig -d <device>set SPLIT_MODE=1
```

Example:

```
# mlxconfig -d /dev/mst/mt54000_pciconf0 set SPLIT_MODE=1
```

```
Device #1:  
-----
```



```

Device type:      Quantum
Name:             N/A
Description:      N/A
Device:           /dev/mst/mt54000_pciconf0
Configurations:   Next Boot          New
                  SPLIT_MODE         NO_SPLIT_SUPPORT(0)      SPLIT_2X(1)

```

To create a query for the Split Mode parameter using mlxconfig:

```
# mlxconfig -d <device> q SPLIT_MODE
```

Example:

```

# mlxconfig -d /dev/mst/mt54000_pciconf0 q SPLIT_MODE

Device #1:
-----
Device type:      Quantum
Name:             N/A
Description:      N/A
Device:           /dev/mst/mt54000_pciconf0
Configurations:   Next Boot
SPLIT_MODE        SPLIT_2X(1)

```

Step 2. Split a Port in a Remotely Managed Switch.

- To split a specific port for one or more ports of (1-64) using mlxconfig:

```

# mlxconfig -d <device> set
SPLIT_PORT[<port_num>/<port_range>]=1

```

Note

Please note that although the command, is “set SPLIT_PORT[33..64]”, it splits a specific port for one or more ports of the higher ports (33-40).

Please note that the first port is set as 1, e.g., [1], [1..64].

- How to turn on the split port for the **first port** only:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set  
SPLIT_PORT[1]=1
```

- How to turn on the split port for the **first 32 ports** (range of ports):

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set  
SPLIT_PORT[1..32]=1
```

- How to turn on the split port for the **last 8 ports**:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set  
SPLIT_PORT[57..64]=1
```

- How to turn off the split port for **port 40**:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set  
SPLIT_PORT[40]=0
```

- How to query the split port for the **first 32 ports**:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 query  
SPLIT_PORT[1..32]
```

Step 3. Reboot the switch, or run:

```
flint -d <device> swreset
```

To disable the port split, the following actions are required:

Step 1. Disable the Split Ports in a Remotely Managed Switch:

- To unsplit a specific port for one or more ports (1-32) using mlxconfig:

```
# mlxconfig -d <device> set  
SPLIT_PORT[<port_num>/<port_range>]=0
```

Step 2. Disable the Split Mode in a Remotely Managed Switch.

```
# mlxconfig -d <device> set SPLIT_MODE=0
```

mlxconfig Raw Configuration Files

mlxconfig allows applying raw configuration file for a pre-set configuration. Raw configuration files are intended for advanced users. This document does not cover the generation of such files.

Set the raw configuration file:

```
# mlxconfig -f ./tlv_file.conf -d /dev/mst/mt4115_pciconf1
set_raw
```

Raw TLV #1 Info:

Length: 0xc

Version: 0

OverrideEn: 1

Type: 0x00000080

Data: 0xa0000000 0xa0020010 0x00000000

Raw TLV #2 Info:

Length: 0x4

Version: 0

OverrideEn: 1

Type: 0x01020012

Data: 0x0000000b

Raw TLV #3 Info:

Length: 0x8

Version: 0

OverrideEn: 1

Type: 0x00000190

Data: 0x00000010 0x00007d00

Raw TLV #4 Info:

Length: 0x4

Version: 0

OverrideEn: 1

Type: 0x00000082

Data: 0x0000000c

Operation intended for advanced users.

Are you sure you want to apply raw TLV file? ? (y/n) [n] : y

Applying... Done!

-I- Please reboot machine to load [new](#) configurations.

Note

Never apply files from an unreliable source.

mlxconfig Commands

mlxconfig Backup Command

The backup command is used to save the current non-volatile configurations (TLV) in the device into a file in raw TLV syntax so it can be restored anytime using the `set_raw` command.

mlxconfig backup command allows backing up the all of the configurations which are related only to the PCI Physical Function associated with the given MST device. To back up all of the device configurations, perform the operation from every PCI Physical Function the device exposes. Restoring the configurations must be made from the matching PCI Physical Function.

Note

In a MultiHost environment, these operations are required to be executed per host.

```
# mlxconfig -d /dev/mst/mt4117_pciconf0 -f /tmp/backup.conf
backup
Collecting...
Saving output...
Done!
```

```
# cat /tmp/backup.conf
MLNX_RAW_TLV_FILE
% TLV Type: 0x00000400, Writer ID: ICMD MLXCONFIG(0x09), Writer Host
ID:
0x00 0x00000014 0x00000400 0x00000000 0x00000000 0x000e0000 0x001000f6 0x20160526 0x1
# mlxconfig -d /dev/mst/mt4117_pciconf0 -f /tmp/backup.conf
set_raw
Raw TLV #1 Info:
Length: 0x14
Version: 0
OverrideEn: 0
Type: 0x00000400
Data: 0x00000000 0x000e0000 0x001000f6 0x20160526 0x11250000
Operation intended for advanced users.
Are you sure you want to apply raw TLV file? ? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

Generating an XML Template for the Configurations

Users can generate an XML file that contains a template for the configurations. The template describes the configurations and their parameters. No values are included in the template.

To generate such a template, run the `gen_tlv_file` command. This command will generate a file containing a list of all supported configurations by `mlxconfig`, with a zero appearing in the end of each configuration. To choose a configuration, change the 0 to 1, then save the file and run the `gen_xml_template` command. An XML file containing the required configurations will be generated.

Example:

```
# mlxconfig gen_tlv_file /tmp/confs.txt
Saving output...
Done!
# cat /tmp/confs.txt
```

```
nv_host_to_bmc      0
nv_kdnet_data       0
nv_fpga_data        0
nv_packet_pacing    0
nv_debug_mode       0
nv_global_pci_conf  0
```

In order to include the `nv_kdnet_data` configuration in the template, change the 0 to 1, as demonstrated in the following example.

Example:

```
nv_kdnet_data      1

#mlxconfig gen_xml_template /tmp/confs.txt /tmp/template.xml
Saving output...
Done!

#cat /tmp/template.xml
<?xml version="1.0" encoding="UTF-8"?>
<config xmlns="http://www.mellanox.com/config">
<nv_kdnet_data>

        <!-- Legal Values: False/True -->
        <kdnet_en></kdnet_en>

</nv_kdnet_data>
</config>
```

Advance Options

Add the `-a` flag in order to allow advance options in the XML generated file. When using this flag, each TLV in the XML file has additional attributes that must be filled.

by default, all TLVs will be at MLNX priority. Other possible values are OEM and USER.

mlxconfig xml2raw Command

The xml2raw command is an easy way to generate a flawless raw configuration file that can be used in the set_raw command. The input for the command is an XML file that contains the data of the required configurations. To generate an XML file and fill it with the desired values, run the commands from [Generating an XML Template for the Configurations](#), and then use the xml2raw command to generate a raw file.

Example:

```
# cat /tmp/template.xml
<?xml version="1.0" encoding="UTF-8"?>
<config xmlns="http://www.mellanox.com/config">
<nv_kdnet_data>

    <!-- Legal Values: False/True -->
    <kdnet_en>True</kdnet_en>

</nv_kdnet_data>
</config>

#mlxconfig xml2raw /tmp/template.xml /tmp/confs.raw
Saving output...
Done!

#cat /tmp/confs.raw
MLNX_RAW_TLV_FILE
0x03000004 0x00000085 0x00000000 0x80000000
```

mlxconfig xml2bin Command

The `xml2bin` command is an easy way to generate a binary file that contains a binary dump of configurations. The input for the command is an XML file that contains the data of the required configurations. To generate an XML file and fill it with the desired values, run the commands from Section 2.4.10, and then use the `xml2bin` command to generate a binary file.

Example:

```
#mlxconfig xml2bin /tmp/template.xml /tmp/confs.bin
Saving output...
Done!
# hexdump -C /tmp/confs.bin
00000000 80 00 00 00 | ....|
00000004
```

mlxconfig create_conf Command

The `create_conf` command assists in creating an NV configuration file that can be used for LifeCycle and Secure Firmware Updates purposes. The flow for creating a configuration file is the same as the flow for `xml2bin`. The user must provide the command with an XML file containing the required configurations and their values. The command can sign the configuration file, if the user provides a private key and UUID. The sign result will be appended to the end of the configuration file. If no private key and UUID are provided, the tool will compute an SHA256/SHA512 digest and append it to the file. The generated signature will be used by the firmware for authentication purposes.

Note

Currently the only supported NV configurations types are CS tokens, Debug tokens, BTC tokens, and MLNX ID which are used for Secure Firmware Updates. Additionally, it supports two RSA keys of 2048 or 4096 bits length for all tokens except BTC which supports only 4096 bits.

Note

The NV configurations files must have the applicable_to configuration.

Examples:

```
# mlxconfig create_conf --private_key privatekey.pem --key_uuid  
"29ee36ee-13b7-11e7-83de-0cc47a6d39d2" /tmp/template.xml /tmp/nvconf.bin  
Saving output...  
Done!
```

```
# mlxconfig create_conf --private_key privatekey.pem --key_uuid  
"29ee36ee-13b7-11e7-83de-0cc47a6d39d2" /tmp/template.xml /tmp/nvconf.bin --  
openssl_engine pkcs11 --openssl_key_id  
"pkcs11:serial=0123456789abcdef;token=My%20token%201;type=private;object=example_pkey;id=%12%34%  
--key_uuid "e0129552-13ba-11e7-a990-0cc47a6d39d2" /tmp/template.xml  
/tmp/nvconf.bin  
Saving output...  
Done!
```

mlxconfig apply Command

The apply command can be used to apply the NV configurations files to the firmware using the apply command. Only Firmware that supports applying configurations files can be used.

Example:

```
# mlxconfig -d /dev/mst/mt4115_pciconf0 apply /tmp/nvconf.bin  
Applying...  
Done!
```

MFT Supported Configurations and Parameters

Note

The list of MFT Supported Configurations and Parameters is available by running the `"mlxconfig -d <device> show_confs"` command.

Note

Before setting the number of VFs in SR-IOV, make sure your system can support that number of VFs. If your hardware and software cannot support that number, this may cause your system to cease working. Therefore, mlxconfig protects the user by making sure that when setting SR-IOV

parameters, for ConnectX-3 and ConnectX-3 Pro, the value of $\text{NUM_OF_VFS} \times \text{PCI_BAR_SIZE}^{(1)}$ must not exceed 512. For 5th generation devices (Group II devices), however, the value is dependent on the firmware. Also, NUM_OF_VFS must not exceed the limit defined by the firmware (127 VFs upper bound). The same calculation applies to BAR size settings.

⁽¹⁾. PCI_BAR_SIZE refers to the PCI BAR size per function, either physical or virtual.

Note

In case there were no server booting after enabling SR-IOV, please refer to [Troubleshooting](#).

Note

Support was added to set some of the parameters in `mlxconfig` in textual values in addition to the numerical values that are still supported. For example: `LINK_TYPE_P1` can be set as follows: `LINK_TYPE_P1=ETH`, instead of: `LINK_TYPE_P1=2`

Note that the textual values are case insensitive (either “True” or “true” are accepted).

flint – Firmware Burning Tool

The flint (Flash interface) utility performs the following functions:

- Burns a binary firmware image to the Flash device attached to an adapter or a switch device.
- Burns an Expansion ROM image to the Flash device attached to adapters.
- Queries for firmware attributes (version, GUIDs, UIDs, MACs, PSID, etc.)
- Enables executing various operations on the Flash memory from the command line (for debug/production).
- Disables/enables the access to the device’s hardware registers, and changes the key used for enabling. This feature is functional only if the burnt firmware supports it.

flint Synopsis

```
flint [OPTIONS] <command> [parameters...]
```

Tool Options

<code>--allow_rom_change</code>	Allows burning/removing a ROM to/from Firmware image when product version is present.
<code>-banks <banks></code>	Set the number of attached flash devices (banks)
<code>-blank_guids</code>	Burn the image with blank GUIDs and MACs (where applicable). These values can be set later using the "sg" command (see details below). Commands affected: burn
<code>-clear_semaphore</code>	Force clear the flash semaphore on the device. No command is allowed when this flag is used. NOTE: May result in system instability or flash corruption if the device or another application is currently using the flash. Exercise caution.
<code>--cpu_util <CPU_UTIL></code>	Use this flag to reduce CPU utilization while burning, Windows only. Legal values are from 1 (lowest CPU) to 5 (highest CPU)
<code>-d[evice] <device></code>	Device flash is connected to. Commands affected: all
<code>-dual_image</code>	Make the burn process burn two images on flash (previously default algorithm). Current default failsafe burn process burns a single image (in alternating locations). Commands affected: burn
<code>-flash_params <type,log2size,num_of_flashes></code>	Use the given parameters to access the flash instead of reading them from the flash. Supported parameters: - Type: The type of the flash, such as: M25Pxxx, M25Pxx, SST25VFxx, W25QxxBV, W25Xxx, AT25DFxxx, S25FLXXXP - log2size: The log2 of the flash size - num_of_flashes: the number of the flashes connected to the device
<code>--flashed_version</code>	When specified, only flashed fw version is fetched Commands affected: query
<code>-guid <GUID></code>	GUID base value. 4 GUIDs are automatically assigned to the following values:

	guid -> node GUID guid+1 -> port1guid+2 -> port2guid+3 -> system image GUID NOTE: port2 guid will be assigned even for a single port HCA - The HCA ignores this value. Commands affected: burn, sg
-guids <GUIDs...>	4 GUIDs must be specified here. The specified GUIDs are assigned to the following fields, respectively: node, port1, port2 and system image GUID. NOTE: port2 guid must be specified even for a single port HCA. The HCA ignores this value. It can be set to 0x0. Commands affected: burn, sg
-h[elp]	Prints this message and exits
-hh	Prints extended command help
--hmac_key <hmac_key>	Path to the file containing the HMAC key (For FS4 image only).
--hsm	Flag to use with sign command. Will use HSM HW for encryption operations.
-i[image] <image>	Binary image file. Commands affected: burn, verify
--ignore_dev_data	Do not attempt to take device data sections from device (sections will be taken from the image. FS3 image only). Commands affected: burn
--key_uuid <uuid_file>	UUID matching the given private key to be used by the sign command
--key_uuid2 <uuid_file>	UUID matching the given private key to be used by the sign command
-log <log_file>	Prints the burning status to the specified log file
--low_cpu	When specified, cpu usage will be reduced. Run time might be increased Commands affected: query
-mac <MAC>1	MAC address base value. 2 MACs are automatically assigned to the following values: mac -> port1 mac+1 -> port2 Commands affected: burn, sg

-macs <MACs...> 1	2 MACs must be specified here. The specified MACs are assigned to port1, port2, respectively. Commands affected: burn, sg NOTE: -mac/-macs flags are applicable only for NVIDIA Ethernet products.
-no	Non-interactive mode - assume answer "no" to all questions. Commands affected: all
-no_flash_verify	Do not verify each write on the flash.
--no_fw_ctrl	Do not attempt to work with the firmware Ctrl update commands.
-nofs	Burns image in a non failsafe manner.
--openssl_engine <engine name>	Name of the OpenSSL engine to be used by the sign/rsa_sign commands to work with the HSM hardware via OpenSSL API  Warning Please be aware that OpenSSL engine will be deprecated in the next release.
--openssl_key_id <key>	Key identification string to be used by the sign/rsa_sign commands to work with the HSM hardware via OpenSSL API
--output_file <string>	Output file name for exporting the public key from PEM/BIN.
-override_cache_replacement ²	Allow accessing the flash even if the cache replacement mode is enabled. NOTE: This flag is often referred to as -ocr NOTE: This flag is intended for advanced users only. Running in this mode may cause the firmware to hang.
--private_key <key_file>	Path to PEM formatted private key to be used by the sign command
--private_key_label <string>	Flag to use with sign/import_hsm_key commands.

<code>--private_key2 <key_file></code>	Path to PEM formatted private key to be used by the sign command
<code>-qq</code>	Run a quick query. When specified, flint will not perform full image integrity checks during the query operation. This may shorten execution time when running over slow interfaces (e.g., I2C, MTUSB-1). Commands affected: query
<code>-s[ilent]</code>	Do not print burn progress flyer. Commands affected: burn
<code>-striped_image</code>	Use this flag to indicate that the given image file is in a "striped image" format. Commands affected: query verify
<code>-uid <UID></code>	5th Generation (Group II) devices only. Derive and set the device's base UID. GUIDs and MACs are derived from the given base UID according to NVIDIA Methodologies. Commands affected: burn, sg
<code>-use_dev_rom</code>	Save the ROM which exists in the device (FS3 and FS4 image only). Commands affected: burn
<code>--use_fw</code>	Access to flash using FW (ConnectX-3/ConnectX-3 Pro device only). Commands affected: all
<code>-use_image_guids</code>	Burn (guids/uids/macs) as appears in the given image. Commands affected: burn
<code>-use_image_ps</code>	Burn vsd as appears in the given image - do not keep existing VSD on flash. Commands affected: burn
<code>-use_image_rom</code>	Do not save the ROM which exists in the device. Commands affected: burn
<code>--user_password <string></code>	Flag to use with HSM HW for encryption operations.
<code>-v</code>	Version info.
<code>-vsd <string></code>	Write this string, of up to 208 characters, to VSD when burn.
<code>-y[es]</code>	Non interactive mode - assume answer "yes" to all questions. Commands affected: all

<code>--linkx</code>	Burn or query the cable device connected to the host.
<code>--aws_hsm</code>	Flag for the <code>rsa_sign</code> command
<code>--cert_chain_index</code>	Use this flag to specify the certificate location. The acceptable values are 0-7 (default - 0).
<code>--i2c_secondary <address></code>	Change the I ² C secondary address.
<code>--run_module_image</code>	Use this flag to switch FW banks on the module. By default, the command is not performed.
<code>--commit_module_image</code>	Use this flag to switch committed bank on the module. By default, the command is not performed.

Note

The `-mac` and `-macs` options are applicable only to NVIDIA Ethernet adapter and switch devices.

Note

When accessing SwitchX via I²C or PCI, the `-override_cache_replacement` flag must be set.

Command Parameters

The flint utility commands are:

Common Firmware Update and Query

<code>b[urn]</code>	Burn flash
<code>q[uey] [full]</code>	Query misc. flash/firmware characteristics, use "full" to get more information.
<code>v[erify]</code>	Verify entire flash

swreset	SW reset the target unmanaged switch device. This command is supported only in the In-Band access method.
sign_with_hmac	Sign image with HMAC.
component_type	Queries components on a given device via FW
skip_if_same	Skip burning if the firmware version matches the current version on the device

Expansion ROM Update:

brom <ROM-file>	Burn the specified ROM file on the flash.
drom	Remove the ROM section from the flash.
rrom <out-file>	Read the ROM section from the flash.
qrom	Query ROM in a given image.

Initial Burn, Production:

bb	Burn Block - Burns the given image as is. No checks are done. Note: The MFT 'bb' option is an advanced flag used ONLY for production flows. It is NOT recommended to use it, as it can cause unrecoverable firmware burning failures. Note: FwBurnBlock is not supported any longer in FS3 and up images.
sg [guids_num=<num> step_size=<size>] [nocrc]	Set GUIDs.
set_vpd [vpd file]	Set read-only VPD (For FS3 image only).
smg [guids_num=<num> step_size=<size>]	Set manufacture GUIDs (For FS3 image only).
sv	Set the VSD.

Misc Firmware Image Operations

ri <out-file>	Read the fw image on the flash.
dc [out-file]	Dump Configuration: print fw configuration file for the

	given image.
dh [out-file]	Dump Hash: print hash file for the given image.
checksum cs	Perform MD5 checksum on firmware.
timestamp ts <set query reset> [timestamp] [FW version]	Set/query/reset firmware timestamp.
cache_image ci	Cache FW image (Windows only).
sign	Sign firmware image file
rsa_sign	Sign firmware image file with RSA
set_public_keys [public key binary file]	Set Public Keys (For FS3/FS4 image only).
set_forbidden_versions [forbidden versions]	Set Forbidden Versions (For FS3/FS4 image only).
import_hsm_key	This command allows to import the private and public key to the HSM HW.
export_public_key	This command extracts the public key from given BIN file or from PEM file.

Hardware Access Key:

set_key [key]	Set/Update the HW access key which is used to enable/disable access to HW. The key can be provided in the command line or interactively typed after the command is given. NOTE: The new key is activated only after the device is reset.
hw_access <enable disable> [key]	Enable/disable the access to the HW. The key can be provided in the command line or interactively typed after the command is given.

Low Level Flash Operations:

hw query	Query HW info and flash attributes.
e[rase] <addr>	Erase sector
rw <addr>	Read one dword from flash
ww <addr> < data>	Write one dword to flash

wwne <addr>	Write one dword to flash without sector erase
wb <data-file> <addr>	Write a data block to flash
wbne <addr> <size> <data ...>	Write a data block to flash without sector erase
rb <addr> <size> [out-file]	Read a data block from flash

Return Values:

Value	Description
0	Successful completion
1	An error has occurred
7	For the <code>burn</code> command - The option of burning new firmware was not chosen by the user when prompted. Thus, the firmware burning process was aborted.

Note

The following commands are non-failsafe when performed on a 5th generation (Group II) device: `sg`, `smg`, `sv` and `set_vpd`.

Note

Manufacture GUIDs are similar to GUIDs. However, they are located in the protected area of the flash and set during production. By default, firmware will use GUIDs unless specified otherwise during production.

Burning a Firmware Image

The flint utility enables you to burn the Flash from a binary image. To burn the entire Flash from a raw binary image, use the following command line:

```
# flint -d <device> -i <fw-file> [-guid <GUID> | -guids <4 GUIDS>
| -mac <MAC> | -macs <2 MACs>] burn
```

where:

device	Device on which the flash is burned.
fw-file	Binary firmware file.
GUID(s)	Optional, for InfiniBand adapters and 4th generation (Group I) switches. One or four GUIDs. • If 4 GUIDS are provided (-guids flag), they will be assigned as node, Port 1, Port 2 and system image GUIDs, respectively. • If only one GUID is provided (-guid flag), it will be assigned as node GUID. Its values +1, +2 and +3 will be assigned as Port 1, Port 2 and system image GUID, respectively. • If no -guid/-guids flag is provided, the current GUIDs will be preserved on the device. NOTE: For 4th generation (Group I), four GUIDs must be specified but Ports 1 and 2 GUIDs are ignored and should be set to 0. NOTE: A GUID is a 16-digit hexadecimal number. If less than 16 digits are provided, leading zeros will be inserted.
MAC(s)	Optional, for Ethernet and InfiniBand adapters and switches. • If 2 MACs are provided (-macs flag), they will be assigned to Port 1 and Port 2, respectively. • If only one MAC is provided (-mac flag), it will be assigned to Port 1; MAC+1 will be assigned to Port 2. • If no -mac/-macs flag is provided, the current LIDs will be preserved on the device. NOTE: A MAC is a 12-digit hexadecimal number. If less than 12 digits are provided, leading zeros will be inserted.

To burn a firmware image:

1. Update the firmware on the device, keeping the current GUIDs and VSD. (Note: This is the common way to use the tool.)

```
# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax~MT_0000001223.bin burn
```

2. Update the firmware on the device, specifying the GUIDs to burn.

```
# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax~MT_0000001223.bin -guid 1234567deadbeef burn
```

3. Update the firmware on the device, specifying the MACs to burn.

```
# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax~MT_0000001223.bin -mac 1234567deadbeef burn
```

4. Burn the image on a blank Flash device. This means that no GUIDs are currently burnt on the device, therefore they must be supplied (with -guid/-guids) by the burning command. Moreover, the burn process cannot be failsafe when burning a blank Flash, therefore the -nofs flag must be specified.

```
burn# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax~MT_0000001223.bin -nofs -guid 12345678 burn
```

5. Read FW from the device and save it as an image file.

```
# flint -d /dev/mst/mt4131_pciconf0 ri Flash_Image_Copy.bin
```

6. MT58100 SwitchX switch:

Burn the image on a blank Flash device. Meaning, no GUIDs/MACs are currently burnt on the device, therefore they must be supplied (with -guid/-guids and -mac/-

macs) by the burning command. Moreover, the burn process cannot be failsafe when burning a blank Flash, therefore the -nofs flag must be specified.

```
# flint -d /dev/mst/mtusb-1 -i /tmp/fw-sx.bin -nofs -guids  
000002c900002100 0 0 000002c900002100 -macs 0002c9002100  
0002c9002101 b
```

7. MT58100 SwitchX switch inband firmware update:

```
# flint -d lid-0x18 -i /tmp/fw-sx.bin b
```

Burning the MFA2 Images

Burning the MFA2 images enables the user to extract (i.e. unzip) 4MB images from MFA2 archive that matches the device type and device PSID. If there are more than one matching images, the user may use the `--latest_fw` flag and burn the latest firmware, or choose the required image from the user menu.

Note

The device flash **MUST** have all relevant device information (signatures, PSID, VPD, DEV_INFO, MFG_INFO, etc.) valid since MFA2 format does not have that information and without the burn process will fail.

```
flint -d <device> -i <mfa2 file> --psid <PSID string>  
(optionally) --latest_fw (optionally) -silent  
(optionally) b (or burn)
```

- **Burning the MFA2 Images when the Device Includes a Valid Image**

In this scenario, the user **may** (optional) provide a `"-psid"` flag and extract from the MFA2 archive the image that matches this flag, and this way actually change the PSID on the device.

- **Burning the MFA2 Images when in Live Fish Mode**

In this scenario, the user **must** provide a `"-psid"` flag and extract from the MFA2 archive the image that matches this flag, and this way actually change the PSID on the device.

Burning PLDM Images

```
flint -d <device> -i <pldm_package> --component_type FW -y b
```

Options:

<code>--component_type</code>	Component type to burn from the package of the supported components (currently only FW)
-------------------------------	---

Cable Firmware Update (In-Field-Firmware-Update)

Note

This capability is supported only in NVIDIA Quantum switch systems and hosts with NVIDIA ConnectX-6 adapter cards.

The In-Field-Firmware-Update (IFFU) tool works via the switches/NICs in the datacenters and is intended for remote control. The tool is used to update cables transceivers' firmware.


Optical Cables and Transceivers are active network components which run firmware, and as any component running firmware, the ability to update firmware is mandatory. Transceiver firmware update is a system flow which requires the following elements:

- Tool/Manager which will perform the firmware update
- Switch/NIC firmware management used as a middleman between the Manager and the cable transceiver

- Transceiver firmware: target for upgrade

The figure below shows the tool/manager which runs on a remotely controlled host or (in case of managed switches) on a switch, shown as 'Device'.

The manager can query the transceivers type and the current running firmware to understand if an update is required. When an update is required, the manager can apply set of commands that will send the remote host device a new firmware images for the specific transceiver(s) and activate a firmware update flow. The set of commands is defined with low level primitives to support full flexibility for the user. High level script can be applied on top of the manager and allow system wide update.



Note

The update of modules/AOCs connected to switches is done over InfiniBand (inband) PRM registries. Whereas, the update of modules connected to NICs is done over MCC (RegAccess) on the host.

Inband connection implies that unmanaged switches like QM8790 support IFFU.

Each device (NIC, Switch) can update only the modules connected directly to it, not the far end. Updating the far end transceiver/end of the AOC requires the same operation to be done at the far end switch(es).

The Tool/Manager host must have MST rev. 4.16.00 or later installed.

Remote control from outside the cluster (data center) requires access to the host being used as Tool/Manager. When the cluster has many switches, multiple hosts may be engaged in the upgrade process. The host(s) can be remotely controlled via VNC access.

Firmware Burning Across a Cluster (Data Center)

The IFFU function described below works on one switch. Cluster-wide firmware updating is done by use of a script which initiates the update procedure in multiple switches in parallel by initiating an instance of the flint command for each switch. In large clusters the script can be executed on multiple hosts, each handling a different part of the cluster.

Cable Burn Command

```
# flint -d <device> --linkx <flags> <commands>
```

where:

Flags:

<device>	The name of the target switch (one only).
--downstream_device_id_start_index <downstream_device_id_start_index>	The port number of the first LinkX cable/transceiver. (min. port number = 1)
--num_of_downstream_devices <num_of_downstream_devices>	the number of cables/transceivers to burn. They are burnt sequentially.
--linkx_auto_update	Use this flag to burn all supported cables/transceivers connected to the switch.
--download_transfer	Use this flag to perform download and transfer of all cable data for cables. Download and transfer are not performed by default. This flag is only relevant for cable components.
--activate	Use this flag to apply the activation of the new firmware in the updated devices. Activation is not performed by default.

<code>--activate_delay_sec <timeout in seconds></code>	Use this flag to activate all cable devices connected to host with delay, acceptable values are between 0 and 255 (default - 1, immediately). Important: 'activate' flag must be set. This flag is relevant only for cable components.
<code>--i <image></code>	'i' indicates 'binary Image' followed by the path and file name of the bin file to download into the cable/transceiver.
<code>--downstream_device_ids <list of ports></code>	Use this flag to specify the LNKX ports to perform query. List must be only comma-separated numbers, without spaces

Commands:

b[urn]	Burn flash
q[uary]	Query misc. flash/firmware characteristics.

Updating the Firmware

Burning a firmware cable transceiver connected to the host (NIC or switch) is done using the "flint" tool. To do so, the user should use the "--linkx" flag.

Firmware can be burnt in follow one of the methods:

- **Burn with Auto-update:**

1. Transfer the data from the host.

```
# flint -d <device> --linkx --linkx_auto_update --
download_transfer -i <image> b
```

Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --  
download_transfer -i image.bin b
```

2. Activate the firmware.

```
# flint -d <device> --linkx --linkx_auto_update --activate b
```

Note

The flint "--activate" flag behavior is changed to include a minimal delay of 1 second to avoid disconnections if the connected port is being activated. To use the "legacy" activation flow, use the "--activate_delay_sec 0" command.

Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --activate b
```

Activate with delay Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --activate --  
activate_delay_sec 10 b
```

Transfer and Activate Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --  
download_transfer --activate -i image.bin b
```

Warning

Burning all cables in an unmanaged switch in one operation is risky. If the cables do not link up after the update, you lose connection to the switch – permanently.

Burn half of the cables, check that they come up after burning, then burn the other half.

- **Burning multiple cables in the switch using the 'Range':**

1. Transfer the data from the host.

```
# flint -d <device> --linkx --  
downstream_device_id_start_index <index> --  
num_of_downstream_devices <number> --download_transfer -i  
<image> b
```

2. Activate the firmware.

```
# flint -d <device> --linkx --  
downstream_device_id_start_index <index> --  
num_of_downstream_devices <number> --activate b
```

Example of Download Transfer with Activation, range indices is 10 to 16:

```
# flint -d lid-2 --linkx --downstream_device_id_start_index  
10 --num_of_downstream_devices 6 download_transfer --activate  
-i image.bin b
```

This will update 6 AOCs/Transceivers starting from port 10, i.e. all ports in the range 10...15.

Note

You cannot 'overburn' the same firmware version into a transceiver/AOC as the one already installed. This is to prevent wasting time re-burning transceivers in a large cluster. If you try to burn the existing FW version, the command responds:

```
Cable burn failed, error is LinkX downstream  
transfer failed for device index i
```

Example of successful update of 1 AOC:

```
-I- Downloading FW ...  
FSMST_INITIALIZE -    OK  
Writing COMPID_LINKX component -    OK  
FSMST_LOCKED -    OK  
FSMST_DOWNSTREAM_DEVICE_TRANSFER -    OK  
FSMST_LOCKED -    OK  
Please wait while activating the transceiver(s) FW ...  
FSMST_ACTIVATE -    OK..]  
-I- Cable burn finished successfully.
```

Note

Downloading and burning takes approx. 1½ minute + activation
½ minute for one cable. The time for multiple cables depends on
which ports they are plugged into.

Cable Burn Command Running CMIS Firmware Upgrade Flow for Supported Cables

The flint tool is able to burn firmware packages on CMIS compliant cables that support the CDB firmware update procedure.

```
# flint --device <mst cable device> [--image <image>] [flags]  
burn
```

Where:

Where:

--module_password	Optional, module password to enable locked operations.
-- module_vendor_data	Optional, path to vendor data file in case it is not a part of the firmware image file.
--activate	Optional, run and commit the burned image. Use without the "--image" flag to try to perform run and commit commands if possible.

Querying Firmware Version from an Image

Querying a cable image for firmware version is done using the "flint" tool.

```
# flint -i <fw file> q
```

Querying Vendor Specific Firmware Information from a NVIDIA AOC / Transceiver

Querying a firmware cable transceiver is done using the "flint" tool.

Note

In case the Vendor Specific query command is not support by the firmware, it will run the CMIS standard query implemented by the firmware.

```
# flint -d <cable device> q
```

Querying Firmware Information from an AOC / Transceiver

Querying a firmware cable transceiver connected to the host (NIC or switch) is done using the "flint" tool. To do so, the user should use the `"-linkx"` flag.

```
# flint -d <device> --linkx --downstream_device_ids <ids> [--  
output_file <file_name>] q
```

Query ports 1,2,5 Example:

```
# flint -d <device> --linkx --downstream_device_ids 1,2,5 q
```

The system responds with information about the firmware version loaded into the transceivers.

The firmware version of all cables plugged into ports 1...40 of a switch with lid #nn can alternatively be checked with the mlxlink command:

```
# for i in {1..40}; do echo $i; mlxlink -d lid-nn -p $i -m | grep 'Part\FW'; done
```

Checking successful burning and operation - Example:

It is essential to check that the links come up AFTER the cable FW is updated and reactivated. This can be done as follows:

```
# for i in {36..40}; do echo $i; mlxlink -d lid-nn -p $i -m | grep 'Part\FW|State'; done
```

The 'State' parameter was added to the query. The response has the following format (example):

```
# 36

State                               : Active

Vendor Part Number                  : MFS1S00-H010

FW Version                          : 38.100.59

37

State                               : Active

Vendor Part Number                  : MFS1S00-H010

FW Version                          : 38.100.59
```

38

```
State : Active
Vendor Part Number : MFS1S00-H010
FW Version : 38.100.59
```

39

```
State : Active
Vendor Part Number : MFS1S00-H010
FW Version : 38.100.59
```

40

```
State : Active
Vendor Part Number : MFS1S00-H010
FW Version : 38.100.59
```

Querying the Firmware Image

To query the FW image on a device, use the following command line:

```
# flint -d <device> q
```

To query the FW image in a file, use the following command line:

```
# flint -i <image file> q
```

where:

device	Device on which the query is run.
image file	Image file on which the query is run.

Examples:

- Query the FW on the device.

```
# flint -d /dev/mst/mt4133_pciconf0 query
```

- Query the FW image file.

```
# flint -i 25408-2_42_5000-MCX354A-FCB_A2.bin query
```

- Security Attributes field in Query output:

This field lists the security attributes of the device's firmware, where:

- Secure-fw: This attribute indicates that this binary/device supports secure-firmware-updates. It means that only officially signed binaries can be loaded to the device from the host, and that the current binary is signed.
- Signed-fw: This attribute indicates that that this binary is signed and that the device can verify digital signatures of new updates. However, unlike, secure-fw, there might still be methods to upload unsigned binaries to the device from the host.
- debug: This attribute indicate that this binary is (or this device runs) a debug-version. Debug versions are custom made for specific data-centers or labs, and can only be installed after a corresponding debug-fw token is pushed to the device. The debug-fw-token, which is digitally signed, includes a list of the target devices MAC addresses.
- dev: This attribute indicates that the firmware is signed with development (test) key.
- Default Update Method" field in Query Full output:{This field reflect the method which flint will use in order to update the device. The user can enforce a different method using the `-no_fw_ctrl` or the `-ocr` flags.The default methods are:
 - Legacy: flint will use the low level flash access registers.
 - fw_ctrl: flint will operate the 'firmware component update' state machine.
- Secure-boot attributes

- Secure-boot : This attribute indicates if the device supports secure-boot
- Life-cycle : This attribute indicates the current status of secure-boot
- Security-version:
 - For query on image: This attribute indicates the security-version of the image.
 - For query on device:
 - “EFUSE security version”: Indicates the security version of the device
 - “Image security version”: Indicates the security version of the image on the flash
 - Programming method: Indicates when the boot will program the “EFUSE security version” to be aligned with the “image security version”.

Verifying the Firmware Image

To verify the FW image on the Flash, use the following command line:

```
# flint -d <device> verify
```

To verify the FW image in a file, use the following command line:

```
# flint -i <image file> v
```

where:

device	Flash device to verify.
image file	Image file to verify.

Examples:

```
# flint -d /dev/mst/mt4115_pciconf0 v
```

```
# flint -i ./image_file.bin verify
```

Comparing the Binary Image

Binary comparison of the firmware image enables the user to verify that a given firmware image contains the image that matches the given device.

Note

Since ConnectX-4/ConnectX-4 Lx devices have iTOC (image specific) and dTOC (device specific) sections at the beginning of the device flash, and the MFA2 archive does not have the dTOC information by its definition, the binary comparison will ignore the device specific sections on the device.

```
#flint -d <device> -i <fw image> --silent (optional)
bc (or binary_compare)
```

The Verify Command on Encrypted Flash/Image

Note

The `verify` command on encrypted flash/image is applicable on adapter cards starting from ConnectX-7.

The flint tool supports the `verify` command on encrypted flash/image, as follows:

- When both the device and the image are given the verify command: verifying encrypted flash, the flint tool will execute binary-compare between the flash and the given image (the image is expected to be the one burnt on the device). In case of a device in recovery mode, the verify action is applicable before transcoding.
- When an encrypted device/image is given the verify command: only DTOC CRCs will be verified. In case a device is given, the verify is applicable in recovery mode only.

Performing Checksum Calculation on Image/Device

The flint utility allows performing an MD5 checksum on the non-persistent sections of the firmware image. For example: the sections that are changed when performing a firmware upgrade.

To perform a checksum on the flash, run the following command line:

flint -d <mst device> checksumTo perform a checksum on a firmware image, run the following command line:

flint -i <image file> checksumwhere:

device	Flash device to verify.
image file	Image file to verify.

Examples:

```
flint -i fw-ConnectX4Lx.bin checksum -l- Calculating Checksum ... Checksum:
68ddae6bfe42f87f09084f3f468a35c6
```

```
flint -d /dev/mst/mt4117_pciconf0 cs
```

```
-l- Calculating Checksum ...
```

```
Checksum: 68ddae6bfe42f87f09084f3f468a35c6
```

Managing an Expansion ROM Image

To burn an Expansion ROM image, run the following command:

```
# flint -d <mst device> brom <image name>.mrom
```

The “brom” command installs the ROM image on the flash device or replaces an already existing one.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 brom example.mrom
```

Current ROM info on flash: N/A

New ROM info: type=PXE version=3.5.305 cpu=AMD64

Burning ROM image - OK

Restoring signature - OK

#

To read an expansion ROM image to a file, run the following command:

```
# flint -d <mst device> rrom <image name>.rom
```

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 rromexample.mrom
```

```
# flint -d /dev/mst/mt4099_pci_cr0 q
```

Image type: FS2

FW Version: 2.42.5000

FW Release Date: 4.5.2017

Rom Info: type=PXE version=3.5.305 cpu=AMD64

Device ID: 4099

Description:	Node	Port1	Port2	Sys image
--------------	------	-------	-------	-----------

GUIDs:	f45214030001b8a0	f45214030001b8a1	f45214030001b8a2	f45214030001b8a3
--------	------------------	------------------	------------------	------------------

MACs:	f4521401b8a1	f4521401b8a2
-------	--------------	--------------

VSD:

PSID: MT_1090120019

#

To remove the expansion ROM, run the following command:

```
# flint -d <mst device> drom
```

Examples:

```
# flint -d /dev/mst/mt4099_pci_cr0 drom
```

Removing ROM image - OK

Restoring signature - OK

Setting GUIDs and MACs

To set GUIDs/MACs/UID for the given device, use the 'sg' (set guides) command with the -guid(s), -uid and/or -mac(s) flags.

4th Generation (Group I) Devices

On 4th generation/Group I devices, the "sg" command can operate on both the image file and the image on the flash. When running the "sg" command on an image on the flash, if the GUIDs/MACs/UIDs in the image are non-blank, the flint will re-burn the current image using the given GUIDs/MACs/UIDs.

1. Change the GUIDs/MACs on a device:

```
# flint -d /dev/mst/mt4099_pci_cr0 q
```

-W- Running quick query - Skipping full image integrity checks.

Image type: FS2

FW Version: 2.42.5000

FW Release Date: 4.5.2017

Device ID: 4099

Description:	Node	Port1	Port2	Sys image
--------------	------	-------	-------	-----------

GUIDs:	f45214030001b8a0	f45214030001b8a1	f45214030001b8a2	f45214030001b8a3
--------	------------------	------------------	------------------	------------------

MACs:	f4521401b8a1	f4521401b8a2
-------	--------------	--------------

VSD:

PSID: MT_1090120019

```
# flint -d /dev/mst/mt4099_pci_cr0 -guid 0x452140300abadaba -mac 0x300abadaba sg
```


-W- GUIDs are already set, re-burning image with the new GUIDs ...

You are about to change the Guids/Macs/Uids on the device:

	New Values	Current Values
Node GUID:	452140300abadaba	f45214030001b8a0
Port1 GUID:	452140300abadabb	f45214030001b8a1
Port2 GUID:	452140300abadabc	f45214030001b8a2
Sys.Image GUID:	452140300abadabd	f45214030001b8a3
Port1 MAC:	00300abadaba	f4521401b8a1
Port2 MAC:	00300abadabb	f4521401b8a2

Do you want to continue ? (y/n) [n] : y

Burning FS2 FW image without signatures - OK

Restoring signature - OK

```
# flint -d /dev/mst/mt4099_pci_cr0 q
```

Image type: FS2

FW Version: 2.31.5050

FW Release Date: 4.5.2014

Device ID: 4099

Description:	Node	Port1	Port2	Sys image
--------------	------	-------	-------	-----------

GUIDs:	452140300abadaba	452140300abadabb	452140300abadabc	452140300abadabd
--------	------------------	------------------	------------------	------------------

MACs:	00300abadaba	00300abadabb
-------	--------------	--------------

VSD:

PSID: MT_1090120019

2. Change the GUIDs/MACs on an image file:

```
# flint -i /tmp/image.bin q
```

Image type: fs2

FW Version: 2.31.5050

FW Release Date: 4.5.2014

Device ID: 4099

Description: Node Port1 Port2 Sys image

GUIDs: f45214030001b8a0 f45214030001b8a1 f45214030001b8a2 f45214030001b8a3

MACs: 00300abadaba 00300abadabb

VSD:

PSID: MT_1090120019

flint -i /tmp/image.bin -guid 0002c9000abcdef0 -mac 02c90abcdef0 sg

You are about to change the Guids/Macs/Uids on the device:

New Values	Current Values
------------	----------------

Node GUID:	0002c9000abcdef0	f45214030001b8a0
------------	------------------	------------------

Port1 GUID:	0002c9000abcdef1	f45214030001b8a1
-------------	------------------	------------------

Port2 GUID:	0002c9000abcdef2	f45214030001b8a2
-------------	------------------	------------------

Sys.Image GUID:	0002c9000abcdef3	f45214030001b8a3
-----------------	------------------	------------------

Port1 MAC:	02c90abcdef0	00300abadaba
------------	--------------	--------------

Port2 MAC:	02c90abcdef1	00300abadabb
------------	--------------	--------------

Do you want to continue ? (y/n) [n] : y

Restoring signature - OK# flint -i /tmp/image.bin q

Image type: FS2

FW Version: 2.31.5050

FW Release Date: 4.5.2014

Device ID: 4099

Description: Node Port1 Port2 Sys image

GUIDs: 0002c9000abcdef0 0002c9000abcdef1 0002c9000abcdef2 0002c9000abcdef3

MACs: 02c90abcdef0 02c90abcdef1

VSD:

PSID: MT_1090120019

5th Generation (Group II) Devices

On 5th Generation (Group II) devices, the “sg” command can operate on both the image file and the image on the flash. When running the “sg” command on an image on the flash, -uid flag must be specified. For ConnectX-4, -guid/-mac flags can be specified. By default, 8 GUIDs will be assigned for each port starting from base, base+1 up until base+7 for port 1 and base+8 up until base+15 for port 2.

To change the step size and the number of GUIDs per port, specify `guids_num=<num>` `step_size=<size>` to the sg command.

1. Change GUIDs for device:

```
# flint -d /dev/mst/mt4113_pciconf0 q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description: UID GuidsNumber Step

Base GUID1: 0002c903002ef500 8 1

Base GUID2: 0002c903002ef508 8 1

Base MAC1: 0002c92ef500 8 1

Base MAC2: 0002c92ef508 8 1

Image VSD:

Device VSD: VSD

PSID: MT_1240110019

```
# flint -d /dev/mst/mt4113_pciconf0 -uid 0002c123456abcd -ocr sg
```

-W- Firmware flash cache access is enabled. Running in this mode may cause the firmware to hang.

Updating GUID section - OK

Updating ITOC section - OK

Restoring signature - OK

```
# flint -d /dev/mst/mt4113_pciconf0 q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description:	UID	GuidsNumber	Step
--------------	-----	-------------	------

Base GUID1:	00002c123456abcd	8	1
-------------	------------------	---	---

Orig Base GUID1:	0002c903002ef500	8	1
------------------	------------------	---	---

Base GUID2:	00002c123456abd5	8	1
-------------	------------------	---	---

Orig Base GUID2:	0002c903002ef508	8	1
------------------	------------------	---	---

Base MAC1:	00002c56abcd	8	1
------------	--------------	---	---

Orig Base MAC1:	0002c92ef500	8	1
-----------------	--------------	---	---


Base MAC2:	00002c56abd5	8	1
------------	--------------	---	---

Orig Base MAC2:	0002c92ef508	8	1
-----------------	--------------	---	---

Image VSD:

Device VSD: VSD

PSID: MT_1240110019



Orig Base GUID/MAC refers to the GUIDs/MACs located in the MFG(manufacture guides) section of the flash/image.

2. Change GUIDS for device (specifying guides_num and step_size):

```
# flint -d /dev/mst/mt4113_pciconf0 q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description: UID GuidsNumber Step

Base GUID1: 0002c903002ef500 8 1

Base GUID2: 0002c903002ef508 8 1

Base MAC1: 0002c92ef500 8 1

Base MAC2: 0002c92ef508 8 1

Image VSD:

Device VSD: VSD

PSID: MT_1240110019

```
# flint -d /dev/mst/mt4113_pciconf0 -uid 0000000000000001 -ocr sg guides_num=2 step_size=1
```

-W- Firmware flash cache access is enabled. Running in this mode may cause the firmware to hang.

Updating GUID section - OK

Updating ITOC section - OK

Restoring signature - OK

```
# flint -d /dev/mst/mt4113_pciconf0 q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description:	UID	GuidsNumber	Step
--------------	-----	-------------	------

Base GUID1:	0000000000000001	2	1
-------------	------------------	---	---

Orig Base GUID1:	0002c903002ef500	8	1
------------------	------------------	---	---

Base GUID2:	0000000000000003	2	1
-------------	------------------	---	---

Orig Base GUID2:	0002c903002ef508	8	1
------------------	------------------	---	---

Base MAC1:	000000000001	2	1
------------	--------------	---	---

Orig Base MAC1:	0002c92ef500	8	1
-----------------	--------------	---	---

Base MAC2:	000000000003	2	1
------------	--------------	---	---

Orig Base MAC2:	0002c92ef508	8	1
-----------------	--------------	---	---

Image VSD:

Device VSD: VSD

PSID: MT_1240110019

3. Change GUIDs for image:

```
# flint -i /tmp/connect-ib.bin q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description:	UID	GuidsNumber	Step
--------------	-----	-------------	------

Base GUID1:	0002c903002ef500	8	1
-------------	------------------	---	---

Base GUID2:	0002c903002ef508	8	1
-------------	------------------	---	---

Base MAC1:	0002c92ef500	8	1
------------	--------------	---	---

Base MAC2:	0002c92ef508	8	1
------------	--------------	---	---

Image VSD:

Device VSD: VSD

PSID: MT_1240110019

```
# flint -i /tmp/connect-ib.bin -uid 000123456abcd sg
```

Updating GUID section - OK

Updating ITOC section - OK

Restoring signature - OK

```
# flint -i /tmp/connect-ib.bin q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description:	UID	GuidsNumber	Step
--------------	-----	-------------	------

Base GUID1:	000000123456abcd	8	1
-------------	------------------	---	---

Orig Base GUID1:	0002c903002ef500	8	1
------------------	------------------	---	---

Base GUID2:	000000123456abd5	8	1
-------------	------------------	---	---

Orig Base GUID2:	0002c903002ef508	8	1
------------------	------------------	---	---

Base MAC1:	00000056abcd	8	1
------------	--------------	---	---

Orig Base MAC1:	0002c92ef500	8	1
-----------------	--------------	---	---

Base MAC2:	00000056abd5	8	1
------------	--------------	---	---

Orig Base MAC2:	0002c92ef508	8	1
-----------------	--------------	---	---

Image VSD:

Device VSD: VSD

PSID: MT_1240110019

4. Change GUIDs and MACs for the ConnectX-4 device:

```
# flint -d /dev/mst/mt4115_pciconf0 -guid e41d2d0300570fc0 -mac 0000e41d2d570fc0 -ocr sg
```

-W- Firmware flash cache access is enabled. Running in this mode may cause the firmware to hang.

Updating GUID section - OK

Updating ITOC section - OK

Restoring signature - OK

```
# flint -d /dev/mst/mt4115_pciconf0 q
```

Image type: FS3

FW Version: 12.0100.5630

FW Release Date: 23.3.2015

Description: UID GuidsNumber

Base GUID: e41d2d0300570fc0 4

Base MAC: e41d2d570fc0 4

Image VSD:

Device VSD:

PSID: MT_2190110032

add note:

GUIDs and MACs can be changed separately on ConnectX4

Preparing a Binary Firmware Image for Pre-assembly Burning

In some cases, OEMs may prefer to pre-burn the flash before it is assembled on board. To generate an image for pre-burning for 4th generation (Group I) devices, use the `mlxburn "-striped_image"` flag. The "striped image" file layout is identical to the image layout on the flash, hence making it suitable for burning verbatim. When pre-burning, the GUIDs/MACs inside the image should be unique per device. The following are two methods to pre-burn an image. You can choose the best method suitable for your needs.

Method 1: Pre-burn an Image with Blank GUIDs/MACs

In this method, the image is generated with blank GUIDs and CRCs. The GUIDs are set after the device is assembled using the flint "sg" command. To set GUIDs take less than 1 second when running on an image with blank GUIDs (through a PCI device).

Note

A device that is burnt with blank GUIDs/MACs will not boot as a functional network device as long as the GUIDs/MACs are not set.

To pre-burn an image with blank GUIDs/MACs:

1. Generate a striped image with blank GUIDs.

```
# mlxburn -fw ./fw-ConnectX3-rel.mlx -./MCX354A-FCB_A2-A5.ini
-wrimage ./fw-ConnectX3-rel.bin -striped_image -blank_guids
-I- Generating image ...
-I- Image generation completed successfully.
```

2. Burn the image to a flash using an external burner.
3. (Optional) After assembly, query the image on flash to verify there are no GUIDs on the device.

```
# flint -d /dev/mst/mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description: Node          Port1          Port2
Sys image
GUIDs:          ffffffff ffffffff ffffffff ffffffff
                ffffffff ffffffff ffffffff ffffffff
```

```
MACs:                                ffffffffffffffff
fffffffffffffffffffff
VSD:      n/a
PSID:      MT_1090120019
```

-W- GUIDs/MACs values and their CRC are not set.

4. Set the correct GUIDs. Since the image is with blank GUIDs, this operation takes less than 1 second.

```
# flint -d /dev/mst/mt4099_pci_cr0 -guid 0x0002c9030abcdef0 -mac
0x0002c9bcdef1 sg
```

5. Query the image on flash to verify that the GUIDs are set correctly.

```
sg# flint -d /dev/mst/mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description:      Node                Port1                Port2
Sys image
GUIDs:           0002c9030abcdef0 0002c9030abcdef1
0002c9030abcdef2 0002c9030abcdef3
MACs:           0002c9bcdef1
0002c9bcdef2
VSD:            n/a
PSID:           MT_1090120019
```

Method 2: Pre-burn an Image with Specific GUIDs/MACs for Each Device

In this method, a “base” image is generated with arbitrary default GUIDs and then updated with the correct GUIDs for each device.

To pre-burn an image with specific GUIDs/MACs for each device:

1. Generate the base image with arbitrary default GUIDs.

```
# mlxburn -fw./fw-ConnectX3-rel.mlx -c ./MCX354A-FCB_A2-A5.ini -wrimage ./fw-ConnectX3-rel.bin -striped_image
```

2. Per device, set the device specific GUIDs in the image.

```
flint -i ./fw-ConnectX3-rel.bin -guid 0x0002c9030abcdef0 -mac 0x0002c9bcdef1 -striped_image sg
```

3. (Optional) After assembly, query the image on flash to verify there are no GUIDs on the device.

```
sg# flint -i ./fw-ConnectX3-rel.bin -striped_image q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description:      Node                Port1                Port2
Sys image
GUIDs:           0002c9030abcdef0 0002c9030abcdef1
0002c9030abcdef2 0002c9030abcdef3
MACs:                                0002c9bcdef1
0002c9bcdef2
VSD:             n/a
```

PSID: MT_1090120019

Now the fw-ConnectX3-rel.bin image can be pre-burned to the flash. After the assembly, the device would be fully functional.

Setting the VSD

To set the vsd for the given image/device (4th generation/Group I), use the sv command with -vsd flag.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 -vsd "MELLANOX" sv
Setting the VSD      - OK
Restoring signature - OK

# flint -d /dev/mst/mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description:      Node                Port1                Port2
Sys image
GUIDs:           f45214030001b8a0 f45214030001b8a1
f45214030001b8a2 f45214030001b8a3
MACs:           00300abadaba
00300abadabb
VSD:             MELLANOX
PSID:            MT_1090120019
```

Disabling/Enabling Access to the Hardware

The secure host feature enables ConnectX family devices to block access to its internal hardware registers. The hardware access in this mode is allowed only if a correct 64 bits key is provided.

Note

The secure host feature requires a DOCA_OFED driver installed on the machine.

5th Generation Devices

Secure Host can be enabled on 5th generation devices in one of the following manners:

1. Set the key:

```
# flint -d /dev/mst/mt4115_pciconf0 set_key 18022018  
-I- Secure Host was enabled successfully on the device.
```

2. Disable HW access:

```
# flint -d /dev/mst/mt4115_pciconf0 hw_access disable 18022018  
-I- Secure Host was enabled successfully on the device.
```

If the key was not provided in the command line, an interactive shell will ask for it, and verifying it:

```
# flint -d /dev/mst/mt4115_pciconf0 set_key
Enter Key : *****
Verify Key : *****
-I- Secure Host was enabled successfully on the device.
```

Or

1. Disable the Secure Host (Enable HW access):

```
# flint -d /dev/mst/mt4115_pciconf0 hw_access enable 18022018
-I- The Secure Host was disabled successfully on the device.
And the same as previous, providing the key can be done in
interactive shell:
# flint -d /dev/mst/mt4115_pciconf0 hw_access enable
Enter Key : *****
-I- The Secure Host was disabled successfully on the device.
```

Flash Operations

Reading a Word from Flash

To read one dword from Flash memory, use the following command line:

```
# flint -d <device> rw addr
```

where:

device	The device the dword is read from.
addr	The address of the word to read.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 rw 0x20
```

Writing a dword to Flash

To write one dword to Flash memory, use the following command line:

```
# flint -d <device> ww addr data
```

where:

device	The device the dword is written to.
addr	The address of the word to write.
data	The value of the word.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 ww 0x10008 0x5a445a44
```

Writing a dword to Flash Without Sector Erase

To write one dword to Flash memory without sector erase , use the following command line:

```
# flint -d <device> wwne addr data
```

where:

device	The device the dword is written to..
--------	--------------------------------------

addr	The address of the word to write.
data	The value of the word.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 wwne 0x10008 0x5a445a44
```

Note that the result may be dependent on the Flash type. Usually, bitwise and between the specified word and the previous Flash contents will be written to the specified address.

Erasing a Sector

To erase a sector that contains a specified address, use the following command line:

```
# flint -d <device> e addr
```

where:

device	The device the dword is erased from.
addr	The address of a word in the sector that you want to erase.

Example:

```
# flint -d /dev/mst/mtusb-1 e 0x1000
```

Querying Flash Parameters

To query flash parameters use the following command line:


```
# flint -d <device> [-ocr] hw query
```

where:

device	The device to query.
--------	----------------------

Example:

```
# flint -d /dev/mst/mt4115_pciconf0 hw query
```

Firmware Timestamping for Multi-Host Environment

In a multi-host environment, every host can upgrade the NIC firmware. All hosts are treated equally and there is no designated host. Hence, there can be situations where one host will try to upgrade the firmware and another will try to downgrade; which may lead to two or more unnecessary server reboots. In order to avoid such situations, the administrator can add a timestamp to the firmware they want to upgrade to. Attempts to burn a firmware image with a timestamp value that is lower than the current firmware timestamp will fail.

Note

Firmware timestamping can be used on Connect-IB/ConnectX-4/ConnectX-4 Lx HCAs for controlling the firmware upgrade/downgrade flow.

Setting a Timestamp on Image

In order to set a timestamp on an image, run:

```
# flint -i ./fw-4115.bin timestamp set [UTC time]
```

Note

The user can either specify a combined date and time timestamp in UTC which conforms to ISO 8601, or let the tool use the machine's time for the timestamp.

Querying a Timestamp on Image

To view the timestamp that was set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp query
Current timestamp      : N/A. No valid timestamp found
Next timestamp         : 2015-12-21T10:58:23Z      12.15.0005
```

- “Current timestamp” represents the current running firmware timestamp. If “N/A” is visible, then the timestamp entry is invalid (example: first use of the feature or after resetting the timestamp).
- “Next timestamp” represents the next firmware that is allowed to be burnt on the HCA. Updating the “Next timestamp” requires an equal or newer timestamp to be provided.

Resetting a Timestamp on Device

To reset the timestamp that was set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp reset
```

Resetting the timestamp on device causes invalidation of both “Current timestamp” and “Next timestamp” fields.

Setting a Timestamp on Device

In case it is not possible to modify the firmware image, it is possible to set the timestamp directly on the device by specifying the timestamp and firmware version tied to it.

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp set <UTC time>  
<Firmware version>
```

Querying a Timestamp on Device

To view the timestamp that was set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp query  
Current timestamp : N/A. No valid timestamp found  
Next timestamp : 2015-12-21T10:58:23Z 12.15.0005
```

- “Current timestamp” represents the current running firmware timestamp. If N/A is visible, then the timestamp entry is invalid (example: first use of the feature or after resetting the timestamp).
- “Next timestamp” represents the next firmware that is allowed to be burnt on the HCA. Updating the “Next timestamp” requires an equal or newer timestamp to be provided.

Resetting a Timestamp on Device

To reset the timestamp that were set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp reset
```

Resetting the timestamp on device causes invalidation of both “Current timestamp” and “Next timestamp” fields.

Important Notes

Please note the following:

- If a firmware image contains a timestamp, the burning tool will automatically attempt to set it on the device. If the operation succeeds, the firmware will be burnt.
- If a timestamp was only set on the device, the burning tool will prevent the burning of any firmware version different than the one set in the timestamp set operation.
- Lack of timestamp in both image and device will cause no checks to be performed.

flint/mlxburn Limitations

- When running flint/mlxburn via an MTUSB-1 device, a burn/query command may take up to 45 minutes to complete.
 - To accelerate the burn process add the flag `-no_flash_verify` to the command line which skips the flash verification step. This flag, however, does not verify if the image is burnt correctly.
- Burning an image to a ConnectX-3 adapter in Flash recovery mode may fail on some server types (that use PCIe spread spectrum). The tool may not be able to recognize the device's PCI CONFO or the image burn may not complete successfully.
 - To burn the device, use the MTUSB-1 connection.
- To load the newly burnt firmware image, a driver restart is required for ConnectX-3/ConnectX-3 Pro cards.
 - For fifth generation (Group II) devices, run the `mlxfwreset` tool or reboot the system.

Secure Host

Secure host is the general term for the capability of a device to protect itself and the subnet from malicious software through mechanisms such as blocking access of

untrusted entities to the device configuration registers, directly (through pci_cr or pci_conf) and indirectly (through MADs).

When Secure Host is enabled, host is blocked from performing firmware updates and setting non-volatile configurations.

Note

The supported opcodes of secure_host register by flint tool is setting/unsetting the lock.

Warning

WARNING:

- Once a hardware access key is set, the hardware can be accessed only after the correct key is provided.
- If a key is lost, please refer to [Key Loss Recovery](#).

Note

- The hardware access in this mode is allowed only if a correct 64 bits key is provided.
- The secure host feature for ConnectX-3/ConnectX-3 Pro HCAs requires a MLNX_OFED driver installed on the machine.

Using Secure Host

Secure Host feature is supported for all NVIDIA® network adapters (listed in Group 1 and group 2). For group 1 network adapters, the user is required to generate and burn a

firmware image that supports the feature (see “Generating/Burning a Firmware Supporting Secure Host” below).

For Group 2 network adapters, the feature is supported on firmware version 1x.22.1002 or newer.

Generating/Burning a Firmware Supporting Secure Host

Note

This is not applicable for ConnectX-4 devices and above. No burning of a specific firmware is needed.

1. Make sure you have INI and mlx files suitable for the device.

1. Add `cr_protection_en=true` under [HCA] section in the INI file.

2. Generate an image using `mlxburn`, for example run:

```
# mlxburn -fw ./fw-4099-rel.mlx -conf ./edited_conf.ini -  
wrmage fw-4099.bin
```

2. Burn the image on the device using `flint`:

```
# flint -d /dev/mst/mt4099_pci_cr0 -i fw-4099.secure.bin b
```

3. For changes to take effect, reboot is required.

Setting the Secure Host Key (for all NIC cards)

To set the key, run:

```
# flint -d <dev> set_key 22062011
Setting the HW Key - OK
Restoring signature - OK
```

Note

A driver restart is required to activate the new key.

Accessing the device after hardware access is disabled should show the following:

```
# flint -d <dev> q
E- Cannot open <dev>: HW access is disabled on the device.
E- Run "flint -d <dev> hw_access enable" in order to enable HW access.
```

Enabling Hardware Access

Back user should run the following:

For ConnectX-4 and above devices:

run:

```
# flint -d <device> hw_access enable
Enter Key: *****
```

For ConnectX-3 and ConnectX-3 Pro devices:

1. Make sure you have INI and MLX file suitable for the device.

1. Remove `cr_protection_en=true` from the INI (if present)
2. Generate the image using `mlxburn`, for example run:

```
# mlxburn -fw ./fw-4099-rel.mlx -conf ./unsecure_host.ini  
-wimage fw-4099.unsecure.bin
```

2. Burn the firmware on the device (make sure hardware access is enabled prior to burning):

```
# flint -d /dev/mst/mt4099_pci_cr0 -i fw-4099.unsecure.bin b
```

3. Execute a driver restart in order to load the unsecure firmware:

```
# service openibd restart
```

Key Loss Recovery

If a key is lost, there is no way to recover it using the tool. The only way to recover is to:

1. Connect the flash-not-present jumper on the card.
2. Reboot the machine.
3. Re-burn firmware(for Group 2 network adapters re-burn the firmware following the process in [Burning a New Device](#).)
4. Remove the flash-not-present jumper.
5. Reboot the machine
6. Re-set the hardware access key

Secure Firmware Update

Note

Secure Firmware Update is supported only on ConnectX-4 onwards adapter cards.

A “Secure firmware update” is the ability of a device to verify digital signatures of new firmware binaries, in order to assure that only officially approved versions can be installed from the host, the network[1] or a Board Management Controller (BMC).

The firmware of devices with “secure firmware up date” functionality (secure FW), restricts access to specific commands and registers that can be used to modify the firmware binary image on the flash, as well as commands that can jeopardize security in general. Most notably, the commands and registers for random flash access are disabled.

Secure FW verifies new binaries before activating them, compared to legacy devices where this task is done by the update tool using direct flash access commands. In addition to signature verification, secure FW also checks that the binary is designated to the same device model, that the new firmware is also secured, and that the new FW version is not included in a forbidden versions blacklist. The firmware rejects binaries that do not match the verification criteria.

Secure FW utilizes the same ‘fail safe’ upgrade procedures, so events like power failure during update should not leave the device in an unstable state. The table below lists the impact of secure FW update on MFT tools.

Tool	Flow	Secure FW	With CS Token	Blocked Commands
flint / mlxburn	Burn FW	Working with controlled fw update	Working with controlled fw update	
	Query	Working with controlled fw update	Working with controlled fw update	
	Set GUIDs	Working with controlled fw update	Working with controlled fw update	

Tool	Flow	Secure FW	With CS Token	Blocked Commands
	Verify	Working partially (BOOT image)	Working partially (BOOT image)	
	Set DV INFO: SET MFG, SET VSD, VPD	Not supported in Secure FW	Not supported in Secure FW	MFBA
	ROM OPS: BROM, DROM	Not supported, BOOT image modification is not supported (MFBA)	Not supported, BOOT image modification is not supported (MFBA)	MFBA
	"-ocr" override cache replacement (Direct flash GW access)	Not supported in Secure FW	Not supported in Secure FW	Flash GW is blocked
	HW SET (Set flash parameters)	Flash GW is blocked	Flash GW is blocked	Flash GW is blocked
	"--no_fw_ctrl" (Legacy Flow)	Not supported in Secure FW	Not supported in Secure FW	MFBA
mlxfwmanager / mlxup	Burn FW	Working with controlled fw update	Working with controlled fw update	
mlxfwmanager	with --no_fw_ctrl	Not supported in Secure FW	Not supported in Secure FW	MFBA

Tool	Flow	Secure FW	With CS Token	Blocked Commands
mlxdump	fsdump	Blocked icmds	Working	gcif_get_ft_info, gcif_get_ft_list, gcif_get_fg, gcif_get_fg_list, gcif_get_fte, gcif_get_fte_list
	phyUc	Blocked icmds	working	gcif_phy_uc_get_array_prop_pos, gcif_phy_uc_set_get_data, gcif_phy_uc_get_array_prop_EI, gcif_phy_uc_get_array_prop_H
	rxdump	CR-Space is locked & Blocked icmds	working	gcif_read_rx_slice_desc, gcif_read_rx_slice_packet
	sxdump	CR-Space is locked & Blocked icmds	working	gcif_read_wq_buffer
wqdump	Dump QP contexts	Blocked icmds	working	gcif_read_context
	Dump WQs	Blocked icmds	working	gcif_read_host_memory, gcif_read_q_entry, gcif_qp_get_pi_ci
	ICM	Blocked icmds	working	gcif_read_icm
	WRITE QP (Devmon)		working	gcif_write_context
mget_temp	hw_access	Read Only CR- Space	working	Read Only CR- Space
mcra	Read	working	working	working
	Write	Read Only CR- Space	working	Read Only CR- Space
mstdump	Read	working	working	working
mlxtrace / fwtrace	MEM & FIFO	Only fwtrace is supported and only in Linux	working	Read Only CR- Space

Tool	Flow	Secure FW	With CS Token	Blocked Commands
pckt_drop	uses write to CR- Space to work	Read Only CR- Space	working	Read Only CR- Space
mlxlink	working	working	working	working
mlxreg	working	working	working	working
mlxcables	working	working	working	working
mlxconfig	working	working	working	working
mlxfwreset	working	working	working	working
i2c/mlxi2c	Not relevant when not in livefish			
	With Force flag (ENV VAR)	Read Only CR- Space	working	Read Only CR- Space

Secure Firmware Implications on Burning Tools

When Secure Firmware is enabled, the flint output slightly changes due to the differences in the underlying NIC accessing methods. Some functionalities may be restricted according to the device security level.

flint query under secure mode:

```
# flint -d /dev/mst/mt4115_pciconf0 q
Image type:      FS3
FW Version:      12.19.2278
FW Release Date: 7.6.2017
Description:     UID                               GuidNumber
Base GUID:       7cfe90030029205e 4
Base MAC:        00007cfe9029205e 4
Image VSD:
Device VSD:
PSID:            MT_2190110032
```

Security Attributes: secure-fw, dev

Note

Unavailable information is reported as N/A.

Burning/Querying a Component

Burning a Component Firmware Image

Clock Synchronizer Images

The flint utility enables the user to burn the Clock Synchronizer firmware from a binary image.

```
# flint --device <mst device> --image <clock synchronizer image>  
burn
```

Where:

-d --device	mst device
-i --image	Specified component firmware image file to use.

Querying the Component Firmware Image

Clock Synchronizer Images

To query the Clock Synchronizer image on a device, use the following command line:

```
# flint --device <mst device> --component_type sync_clock
query_components
```

To query the Clock Synchronizer image in a file, use the following command line:

```
# flint --image <image file> query
```

mlxburn – Firmware Image Generator and Burner

mlxburn is a tool for firmware (FW) image burning to the Flash/EEPROM attached to an NVIDIA device. It can also query for firmware attributes (e.g., firmware version, GUIDs, etc.) and VPD info of adapter cards and switch systems.

mlxburn Synopsis

```
#mlxburn [-h][-v] <-dev mst-device> <-img_dir img_direcory> [-
force][-fwver][-vpd][-vpd_rw][-vpd_prog_rw [-query]
```

where:

-dev <mst-dev>	Burn the image using the given mst device
-fwver	When a device is given: Display current loaded firmware version. When a FW file is given (-fw flag): Display the file FW version.Note: The “-fwver” flag is not supported in Connect-IB devices.
-h	Display a short help text
-image <fw-image-file>	Do not generate image. Use the given fw image instead

-striped_image	When specified, generated image will be in striped format, and will indicate that the image is in striped format when queried.
-query	Query the HCA/Switch device for firmware details, e.g. Firmware Version, GUIDs, etc. In addition to the above flags, Mlxburn can also accept the following flags/options, which are passed to the underlying burning tool: -banks -use_image_ps -skip_is-mac(s) -guid(s) -sysguid-vsd -ndesc -bsn-pe_i2c -se_i2c -is3_i2c-no -uid(s)-log -blank_guids -flash_params-allow_psid_change -no_flash_verify-use_image_rom -override_cache_replacement-use_image_guids See the flint tool documentation for HCA/4th gen switches/Bridge burning options.
-v	Print version info and exit
-V <INFORM WARNING DEBUG>	Set verbosity level. Default is WARNING
-vpd 1,2	Display the read only section of the PCI VPD (Vital Product Data) of the given device
-vpd_rw 1,2	(on Linux only): Display also the read/write section of the PCI VPD of the given device.

Note 1. The VPD query may not be enabled on certain board types. Also, VPD operations are available only for devices with a PCI interface.

Note 2. Running multiple VPD access commands in parallel on the same device, by mlxburn or any other VPD access tool, may cause the commands to fail. VPD access commands should be run one at a time.

Connect-IB, Switch-IB, Switch-IB 2, NVIDIA Spectrum, ConnectX-4, and ConnectX-4 Lx Initial Burning Options

The following options are relevant when generating an image for initial burning. The image contains the VPD and the GUIDs that are in a read-only area on flash.

```
[ -vpd_r_file <vpd_r_file>] [ -base_guid <GUID>]
```

where:

-vpd_r_file <vpd_r_file>	Embed the given VPD Read-Only section in the generated image. The vpd_r_file should contain the vpd read only section and the first dword of the vpd writeable section. The file is in binary format, and its size must be a multiple of 4 bytes. Please refer to PCI base spec for VPD structure info.
-base_guid <GUID>	Set the given GUID as the image base GUID. The base GUID is used to derive GUIDs and MACs for the HCA ports. It is assumed that 16 GUIDs (base_guid to base_guid + 15) are reserved for the card. Note: On ConnectX-4/ConnectX-4 Lx/ConnectX-5/ConnectX-5 Ex, only GUIDs will be derived according to the HCA configuration.
-base_mac <MAC>	Set the given MAC as the image base MAC. The base MAC is used to derive MACs for the HCA ports according to the device configuration (ConnectX-4/ConnectX-4 Lx/ConnectX-5/ConnectX-5 Ex).
-vsd <string>	Write this string, of up to 208 characters, to VSD section.

Additional mlxburn Options

The following is a list of additional options. Please see [mlxfwmanager – Firmware Update and Query Tool](#) for the HCA options.

```
-banks -use_image_ps -skip_is -mac(s) -guid(s) -sysguid -  
ndesc -bsn -use_image_guids -pe_i2c -se_i2c -is3_i2c -no -  
qq -uid(s) -log -blank_guids -flash_params -  
allow_psid_change -no_flash_verify -use_image_rom  
-override_cache_replacement -ocr -ignore_dev_data -use_dev_rom  
-no_fw_ctrl
```

Note

The arguments of the -guids and -macs flags must be provided within quotation marks; for example, mlxburn -macs "0002c900001 0002c900002".

Examples of mlxburn Usage

Query for firmware attributes (e.g., firmware version, GUIDs, etc.):

```
# mlxburn -d /dev/mst/mt4129_pciconf0 query
-I- Image type: FS4
-I- FW Version: 28.45.0376
-I- FW Release Date: 15.4.2025
-I- Product Version: 28.45.0376
-I- Rom Info: type=UEFI version=14.38.14
cpu=AMD64, AARCH64
-I- type=PXE version=3.7.500 cpu=AMD64
-I- Description: UID GuidNumber
-I- Base GUID: N/A 8
-I- Base MAC: N/A 8
-I- Image VSD: N/A
-I- Device VSD: N/A
-I- PSID: MT_00000000851
-I- Security Attributes: secure-fw
```

VPD read:

```
# mlxburn -d /dev/mst/mt4123_pciconf0 -vpd_rw
```

VPD-KEYWORD	DESCRIPTION	VALUE
-----	-----	-----
Read Only Section:		
PN	Part Number	MCX653106A-HDAT
EC	Revision	A1
V2	N/A	MCX653106A-HDAT
SN	Serial Number	MT1836X04719
V3	N/A	0
VA	N/A	
MLX:MN=MLNX:CSKU=V2:UUID=V3:PCI=V0:MODL=CX653106A		
V0	Misc Info	PCIeGen4 x16
VU	N/A	MT1836X04719MLNXS0D0F0
RV	Checksum Complement	0xc0
IDTAG	Board Id	CX653106A - ConnectX-6
QSFP56		

Read Write Section:

```
# mlxburn vpd -d /dev/mst/mt4123_pciconf0
```

VPD-KEYWORD	DESCRIPTION	VALUE
-----	-----	-----
Read Only Section:		
PN	Part Number	MCX653106A-HDAT
EC	Revision	A1
V2	N/A	MCX653106A-HDAT
SN	Serial Number	MT1836X04719
V3	N/A	0
VA	N/A	
MLX:MN=MLNX:CSKU=V2:UUID=V3:PCI=V0:MODL=CX653106A		
V0	Misc Info	PCIeGen4 x16

VU	N/A	MT1836X04719MLNXS0D0F0
RV	Checksum Complement	0xc0
IDTAG	Board Id	CX653106A - ConnectX-6
QSFP56		

Burning bin file using mlxburn:

```
# mlxburn -d /dev/mst/mt4131_pciconf0 -i cx8.bin -y
```

Detecting and burning the suitable bin file from a dir of several bin files:

```
# mlxburn -d /dev/mst/mt4131_pciconf0 -img_dir /tmp/s -y
```

To Query fw version of the given device:

```
# mlxburn -d /dev/mst/mt4115_pciconf0 -fwver
-I- FW Version: 12.28.2006
```

Exit Return Values

The following exit values are returned:

- 0 - successful completion
- >0 - an error occurred

mlxfwreset – Loading Firmware on 5th Generation Devices Tool

- The mlxfwreset tool enables the user to load updated firmware on a NIC/switch without having to reboot the machine. The mlxfwreset tool supports 5th Generation (Group II) HCAs and allows a smooth firmware upgrade.

Note

This feature is supported if either reset type 3 (ARM RESET), which is the default starting from this version, or 4 (ARM SHUT DOWN), and reset level 1 (IMMEDIATE RESET) are supported.

Tool Requirements

- Access to device through PCI configuration cycles
- Supported OSs: FreeBSD, Linux, Windows

Query Command

```
mlxfwreset -d <device> query
```

Reset Command

```
mlxfwreset -d <device> reset-[y] [--level <0,3,4>] [--type  
<0..2>] [--sync <0,1,2>] [-s] [-m] [--method <0,1>
```

mlxfwreset Synopsis

Where:

q query	Query supported reset level/type/sync.	N/A for switch devices.
r reset	Execute reset.	-
reset_fsm_register	Reset the multi-host synchronization register.	-
-d --device <device>	Device to work with.	-
-l --level <0,1,3,4>	Run reset with the specified reset-level.	N/A for switch devices.
-t --type <0..4>	Run reset with the specified reset-type.	N/A for switch devices.
--sync <0,1,2>	Run reset with the specified reset-sync.	N/A for switch devices.
--method <0,1>	Run reset with the specified request method (relevant only for reset-level 3)	-
-y --yes	Answer “yes” on prompt.	-
-m --mst_flags MST_FLAGS	Provide mst flags to be used when invoking mst restart step. For example: --mst_flags="--with_fpga".	◦ This option is supported in Linux OSes only. ◦ N/A for switch devices.
-s --skip_driver	Skip driver start/stop stage (driver must be stopped manually).	N/A for switch devices.
-v --version	Print tool version.	-
-h --help	Show help message and exit.	-

Reset Levels and Types

Reset levels and types depend on the extent of the changes introduced when updating the device's firmware. The tool will display the supported reset levels and types that will ensure the loading of the new firmware. Those reset levels and types are:

- Reset-levels:

- 0: Driver, PCI link, network link will remain up ("live-Patch")
 - 1: Only ARM side will not remain up ("Immediate reset")
 - 3: Driver restart and PCI reset
 - 4: Warm Reboot
- Reset-types (relevant only for reset-levels 1, 3, 4):
 - 0: Full chip reset
 - 1: Phy-less reset ("port-alive" - network link will remain up) – Not Supported
 - 2: NIC only reset (for SoC devices)
 - 3: ARM only reset
 - 4: ARM OS shut down

Note

The exact reset-level and reset-types needed to load new the firmware may differ as they depend on the difference between the running firmware and the firmware we are upgrading to.

Reset Sync

- Reset-sync indicates who is responsible for the synchronization mechanism between the hosts on the Multi-Host setup (relevant only for reset-level 3):
 - 0: Tool is the owner
 - 1: Driver is the owner
 - 2: FW is the owner

Reset Method

- Reset request method (relevant only for reset-level 3):
 - 0: Link Disable method
 - 1: Hot reset (SBR)

PCIe Switch Reset via Hot Reset

- We provide a mechanism to reset a PCIe switch using a hot reset, eliminating the need to reboot the entire setup.

This is achieved using sync 2 and method 1 arguments, which together define the hot reset flow.

This feature currently supports ConnectX-7 and BlueField devices.

To trigger the reset, users can either run the tool with: `--sync 2 --method 1` arguments or simply run it without any parameters and the tool will apply the default values automatically.

- **Important:**

Before executing the reset, **the user should stop any driver bound or associated with devices downstream to the PCIe Switch**. The tool may also prompt the user to unload specific drivers or terminate some processes that it is aware of, **but it is not necessarily aware of all the bounded drivers**.

It is the user responsibility to ensure these steps are completed to guarantee a successful reset.

mlxfwreset for Switch Devices

Running `mlxfwreset` on a switch device is done in the same form as running `mlxfwreset` on a NIC. The only difference is that there are no level, types or sync parameters.

mlxfwreset for Multi-Host NICs

Running `mlxfwreset` on a Multi-Host setup enables you to choose one of the supported reset-sync. To check which reset-sync are supported on your device, run the query command prior to the reset command.

- When running reset with reset-sync "0" ("tool is the owner"), the tool must be ran simultaneously on all the hosts. Note that a time-out of 3 minutes is

expected for all the hosts until they join the reset process.

- When running reset with reset-sync "1" ("driver is the owner"), the tool must be ran on a single host.

Note

reset-sync "1" ("driver is the owner") is supported only when the firmware and all the drivers on all the hosts support it.

mlxfwreset for SmartNICs (Bluefield)

After upgrading the FW , you can run mlxfwreset with level 3 and sync 1.

If you use Level 4 standalone (without shutting down the ARM), you need to execute mlxfwreset on both the integrated ARM and the host.

To update the FW using Level 4, the ARM must be shut down first.

Note

Depending on the reset-type, the integrated Arm might get reset. In case Arm is reset, the mlxfwreset on the host will wait for the Arm to complete the reboot process.

mlxfwreset after Changing Configurations using mlxconfig

Some configuration changes require PCI rescan by the user, in this case, mlxfwreset will print the following warning message:

```
"-W- PCI rescan is required after device reset."
```

Examples of mlxfwreset Usage

To query the default and supported options to reset a device, run:


```
# mlxfwreset -d /dev/mst/mt4113_pciconf0 query
```

Example:

Reset-levels:

```
0: Driver, PCI link, network link will remain up ("live-Patch") -  
Not Supported  
1: Only ARM side will not remain up ("Immediate reset"). -  
Not Supported  
3: Driver restart and PCI reset  
-Supported (default)  
4: Warm Reboot  
-Supported
```

Reset-types (relevant only for reset-levels 1,3,4):

```
0: Full chip reset  
-Supported (default)  
1: Phy-less reset ("port-alive" - network link will remain up) -  
Not Supported  
2: NIC only reset (for SoC devices)  
-Not Supported  
3: ARM only reset  
-Not Supported  
4: ARM OS shut down  
-Not Supported
```

Reset-sync (relevant only for reset-level 3):

```
0: Tool is the owner  
-Supported (default)  
1: Driver is the owner  
-Supported
```

In the [new](#) `mlxfwreset` [for](#) BF2 and BF3, `sync1` is the [default](#). `Sync0` is not supported.

To reset the device in order to load the new firmware, run:

```
# mlxfwreset -d /dev/mst/mt4113_pciconf0 reset
```

Or:

```
mlxfwreset -d /dev/mst/mt53100_pciconf0 reset -y
```

Example

```
3: Driver restart and PCI reset
Continue with reset?[y/N] y
-I- Stopping Driver           -Done
-I- Sending Reset Command To Fw -Done
-I- Resetting PCI            -Done
-I- Starting Driver          -Done
-I- Restarting MST           -Done
-I- FW was loaded successfully.
```

To reset a device with a specific reset level to load new firmware, run:

```
# mlxfwreset -d /dev/mst/mt4113_pciconf0 -l 4 reset
```

Example

```
Requested reset level for device, /dev/mst/mt4113_pciconf0:
4: Warm Reboot
Continue with reset?[y/N] y
-I- Sending reboot command to machine
```

mlxfwreset Limitations

The following are the limitations of mlxfwreset:

- Executing a reset-level or reset-type or reset-sync that is not supported (as shown in the query command) will yield an error
- When burning firmware with flint/mlxburn at the end of the burn the following message is displayed:

-I- To load new FW run mlxfwreset or reboot machine

If this message is not displayed, a reboot is required to load a new firmware
- On an old firmware, after a successful reset execution, attempting to query or reset again will yield an error as the load new firmware command was already sent to the firmware
- In case mlxfwreset exits with error after the “Stopping driver” step and before the “Starting driver” step, the driver will remain down. The user should start the driver manually in this case
- mlxfwreset for switch devices does not work over InfiniBand or remote connection

mlxphyburn – Burning Tool for Externally Managed PHY

Mlxphyburn tool allows the user to burn firmware of an externally managed PHY. The tool burns and verifies a pre-compiled binary PHY firmware image on the PHY's flash. It is supported only on Linux.

Tool Requirements

- ConnectX-3/ConnectX-3 Pro with an externally managed PHY
- A device that has access to the PHY flash module
- MLNX_OFED driver (if installed) must be down
- Access to the device through the PCI interface (pciconf/pci_cr)
- Firmware version that supports access to an externally managed PHY
 - Version 2_33_5000 and above

mlxphyburn Synopsis

```
# mlxphyburn [-d <device>] [-i Phy_fw_image] b[urn]|q[query]
```

where:

-d --dev <device>	Device which has access to the PHY.
-i --img <PHY_fw_image>	PHY firmware image.
-v --version	Display version info.
-h --help	Display help message.
b[urn]	Burn given PHY image on the device's PHY.
q[query]	Query PHY FW on device.

Note

If no device is specified, mlxphyburn will attempt to burn the PHY firmware image on all mst devices on the machine.

Examples of mlxphyburn Usage

Burn Example

```
# mlxphyburn -d /dev/mst/mt4099_pciconf0 -i
Firmware_1.37.10_N32722.cld burn
-I- attempting to burn PHY Fw on device: /dev/mst/mt4099_pciconf0
-I- Burning...(Process might take a few minutes)
-I- Device burned and verified.
```

Query Example

```
# mlxphyburn -d /dev/mst/mt4099_pciconf0 q
-I- Querying device: /dev/mst/mt4099_pciconf0
Flash Type      : Atmel AT25DF041A
FW version      : 1.37
Image ID        : 1.37.10 InterfaceMasters N32722 Apr 14, 2014 12:21:00
Image ROM ID    : 0
```

mlx_fpga – Burning and Debugging Tool for NVIDIA Devices with FPGA

Note

The mlx_fpga utility will be deprecated as of MFT v4.18.0.

mlx_fpga tool allows the user to burn and update a new FPGA image on NVIDIA Innova™ adapter cards. For instructions on how to burn, please refer to [Burning the FPGA's Flash Device using the mlx_fpga Burning Tool](#).

The tool also enables the user to read/write individual registers in the FPGA configuration space.

Tool Requirements

- An Innova IPsec 4 Lx EN / Innova Flex 4 Lx EN adapter card with an FPGA device
- For Innova IPsec 4 Lx EN: Load the mlx5_fpga_tools module
- For Innova Flex 4 Lx EN: Load the mlx_accel_tools module

Note: The module is included in the Innova driver which is supplied for this product line only, and available through the [Support](#).

- Start mst service with the fpga lookup flag (mst start --with_fpga)

mlx_fpga Synopsis

where:

-d --device <device>	FPGA mst device interface
-v --version	Display version info
-h --help	Display help message
-f --force	Non-interactive mode, answer yes to all questions
r read <addr>	Read debug register in address
w write <addr> <data>	Write data to debug register in address
b burn <image file/s>	Burn the image on the flash
l load	Load image from flash (--factory - load image from factory flash)
clear_semaphore	Unlock flash controller semaphore
reset	Reset flash controller (--gw) or FPGA (--fpga)
q query	Query general FPGA information
set_fw_mgmt <disable enable>	Disable/Enable FPGA management by the Firmware

Examples of mlx_fpga Usage

Adding FPGA mst Device Interface

For Innova IPsec 4 Lx EN: Load the mlx5_fpga_tools module.

```
# modprobe mlx5_fpga_tools
# mst start --with_fpga
# mst status
MST modules:
-----
MST PCI module is not loaded
MST PCI configuration module is not loaded
MST devices:
-----
No MST devices were found nor MST modules were loaded.
You may need to run 'mst start' to load MST modules.
FPGA devices:
-----
/dev/mst/mt4117_pciconf0_fpga_i2c
/dev/mst/mt4117_pciconf1_fpga_rdma1
```

Note: In the last line, it is recommended to use the RDMA device as it is faster. I2C is used for recovery purposes when RDMA is not functional.

For Innova Flex 4 Lx EN: Load the mlx_accel_tools module.

```
# modprobe mlx_accel_tools
# mst start --with_fpga
# mst status
MST modules:
-----
MST PCI module is not loaded
MST PCI configuration module is not loaded
MST devices:
-----
No MST devices were found nor MST modules were loaded.
You may need to run 'mst start' to load MST modules.
```

FPGA devices:

```
-----  
/dev/mst/mt4117_pciconf0_fpga_i2c  
/dev/mst/mt4117_pciconf1_fpga_rdma
```

Note: In the last line, it is recommended to use the RDMA device as it is faster. I2C is used for recovery purposes when RDMA is not functional.

For recovery only, where modules are broken or missing.

```
# mst start --with_fpga_fw_access  
Starting MST (Mellanox Software Tools) driver set  
Loading MST PCI module - Success  
Loading MST PCI configuration module - Success  
Create devices  
Unloading MST PCI module (unused) - Success  
# mst status  
MST modules:  
-----  
MST PCI module is not loaded  
MST PCI configuration module loaded  
MST devices:  
-----  
/dev/mst/mt4117_pciconf0          - PCI configuration cycles  
access.  
                                domain:bus:dev.fn=0000:01:00.0  
addr.reg=88 data.reg=92  
                                Chip revision is: 00  
FPGA devices:  
-----  
/dev/mst/mt4117_pciconf0_fpga
```

Note

The `mlx5_fpga_tools` and the `mlx_accel_tools` modules must be down before trying to recover the FPGA mst Device Interface.

Burning the FPGA's Flash Device using the `mlx_fpga Burning Tool`

`mlx_fpga` tool burns a `.bin` file onto the FPGA flash device.

The Innova Flex `.bin` file must be generated according to the instructions listed in the *Innova Flex Adapter Card User Manual*.

Note

It is recommended to burn the FPGA device using an RDMA device as it faster and it shortens the burning time.

1. Burn the image.

```
# mlx_fpga -d <device> burn image.bin
```

2. Load the FPGA image from flash according to “Loading the Tool” below or power cycle the machine for change to take effect.

Loading the Tool

Load an FPGA image from user configurable flash:

```
# mlx_fpga -d <device> l/load <optional: load options>
```

where <optional: load options> is:

--factory	Load FPGA image from factory flash
--user	Load FPGA image from user flash [Default option]

Debugging the Tool

Reading One Debug Register:

```
# mlx_fpga -d <device> read 0x0
```

Writing One Debug Register:

```
# mlx_fpga -d <device> write 0x0 0x0
```

Updating the FPGA Image

In order to verify the new image burned to the FPGA, the user can use mlx_fpga tool and read the following registers:

Name	Address	Range	Default	RW	Description
image_version	0x900000	31:00:00	0x0	RO	Version of the image increased on every synthesis.
image_date	0x900004	31:00:00	0x0	RO	Image date of creation. The hex number is actually the decimal value, i.e. 0x12011995 means 12/01/ 1995 in DD/MM/YY:

Name	Address	Range	Default	RW	Description
					bits [31:24] = day of creation bits [23:16] = month of creation bits [15:0] = year of creation
image_time	0x900008	31:00:00	0x0	RO	Image time of creation. The hex number is actually the decimal value, i.e. 0x00015324 means 01:53:24 in HH:MM:SS: bits [23:16] = hour (00..23)bits [15:8] = minutes (00..59)bits [7:0] = seconds (00..59)

Note

Innova Flex users should refer to the Innova User Manual for more information.

cpldupdate – Tool for Programming On-Board CPLDs on NVIDIA Devices

cpldupdate tool allows the user to program on-board CPLDs on supporting NVIDIA products. The on-board CPLDs, as well as the core engine for programming them, are provided by Lattice Semiconductors.

cpldupdate accepts VME files as input and programs the appropriate CPLD on the device. The CPLD ID is embedded in the VME file. The user need not be aware of the board composition.

A VME file is the data file for use with the ispVM Embedded programming software. The file is essentially a binary version of an SVF file. SVF commands and data are stored in a binary format (with optional compression) for efficient storage and processing by embedded microprocessors. The ispVM Embedded software, provided as source code in C, interprets the VME data to manipulate the JTAG signals of connected target devices.

cpldupdate tool was provided by Lattice Semiconductors and was modified to fit NVIDIA needs.

For NVIDIA Quantum and Spectrum-2 switches, the CPLD update can be performed via GPIO instead using the firmware interface. By default, cpldupdate will use GPIO for Quantum and Spectrum-2 switches (if `--dev` option is specified), However, the user can use the `--fw` option to run cpldupdate via the firmware. Alternatively, the user can dismiss the `--dev` flag and use the `--gpio`.

For NVIDIA Spectrum-1 switches (SN2201) , the CPLD update must be performed via GPIO. The user must use the `--uncustomized` option in addition to the `--gpio` option in this case.

Tool Requirements

- CPLD bearing board

cpldupdate Synopsis

```
# cpldupdate [option] vme_file [vme_file]
```

where:

<code>--dev <device></code>	<code><device></code> (e.g. lid-N, /dev/mst/mt4115_pciconf0).
<code>--gpio</code>	Update CPLD using GPIO.
<code>--fw</code>	Update CPLD using FW.
<code>--idcode <num_of_bits></code>	Run IDCODE command and exits.
<code>--print-progress</code>	Print progress indication.
<code>--uncustomized</code>	Update CPLD via GPIO on NVIDIA Spectrum-1 (SN2201) switches.
<code>--cpld_chain</code>	Provides an option to select which chain to burn, possible chains are CPLD, FPGA and full chain.

Burn Example

```
# cpldupdate --dev /dev/mst/mt52000_pciconf0
./cpld000039_v0100.vme
Lattice Semiconductor Corp.
ispVME(tm) V12.2 Copyright 1998-2012.
Customized for Mellanox products.
Processing virtual machine file (./cpld000039_v0100.vme).....
+=====+
| PASS! |
+=====+
```

mlxprivhost - NIC Configuration by the Host Restriction Tool (Zero Trust Mode)

mlxprivhost enables the user to restrict the hosts from managing the device in case the BlueField DPU is in a Zero Trust environment, and the host cannot be considered “trusted”.

Note

mlxprivhost is supported in Linux only.

Note

mlxprivhost is not supported in ESXi 7.0.

Note

This utility is supported in BlueField devices only.

mlxprivhost Synopsis

```
mlxprivhost [OPTIONS] <command> [parameters...]
```

- Restrict configuration takes effect immediately, but **disabling/enabling RShim** requires power cycle
- A zero-trust (restricted) host will not be able to perform operations that can compromise the DPU, such as:
- Port ownership – the host cannot assign itself as port owner
- Hardware counters – the host does not have access to hardware counters
- Tracer functionality is blocked
- RShim interface is blocked
- FW flash is restricted
- For Multi-host systems, the tool is compatible with firmware versions starting from xx.31.10xx and later

where:

-h, --help	Shows this help message and exit
-v, --version	Shows program's version number and exit
-d <dev>, --device <dev>	Device to work with.
--disable_rshim	When TRUE, the host does not have an RSHIM function to access the embedded CPU registers (power cycle is required to apply changes)
--disable_tracer	When TRUE, the host will not be allowed to own the Tracer (requires FW reset to be applied)

<code>--disable_counter_rd</code>	When TRUE, the host will not be allowed to read Physical port counters (requires FW reset to be applied)
<code>--disable_port_owner</code>	When TRUE, the host will not be allowed to be Port Owner (requires FW reset to be applied)
<code>r,restrict</code>	Set all external hosts as zero-trust (restricted) except of the one that called the command
<code>p,privilege</code>	Set all external hosts privileged except the one that called the command
<code>q,query</code>	From external HOST: query the status of the host From Embedded ARM CPU: query the status of all external hosts.
<code>-f, --full</code>	Run with query command for high verbosity level - valid from embedded ARM CPU only.

Example of `mlxprivhost`:

- Enabling Zero-Trust host (Full Host Restriction - Embedded ARM CPU Only):

```
mlxprivhost -d /dev/mst/mt41682_pciconf0 r --disable_rshim --
disable_tracer --disable_counter_rd --disable_port_owner
```

- Disabling Zero-Trust host restriction (Embedded ARM CPU Only):

```
mlxprivhost -d /dev/mst/mt41682_pciconf0 p
```

- Query the status of the host\hosts (the full flag valid for embedded ARM CPU Only):

```
mlxprivhost -d /dev/mst/mt41682_pciconf0 q --full
Host configurations
-----
host index                : 0
1                          2                          3
```

```

level                                     : PRIVILEGED      PRIVILEGED
PRIVILEGED          PRIVILEGED

Port functions status:
-----
disable_rshim          : FALSE          FALSE
FALSE          FALSE
disable_tracer          : FALSE          FALSE
FALSE          FALSE
disable_port_owner      : FALSE          FALSE
FALSE          FALSE
disable_counter_rd      : FALSE          FALSE
FALSE          FALSE

```

mlxtokengenerator - Token Creation Tool

The mlxtokengenerator tool allows the user to create Token XML files automatically. The Token XML file will be filled with all the required data. The generated Token XML file is ready to be used for sign and installation commands.

mlxtokengenerator Synopsis

```
# mlxtokengenerator [Options] <commands>
```

where:

-d --dev <device>	Performs operation for a specified mst device
-t --device_type <Switch/HCA/LinkX>	Mst device type
-k --token_type <CS/DBG/CRCS/CRDT/RMCS/RMDT>	Token type

-o --output_file <Path>	Path to output Token XML file
-f --debug_fw <Path>	Path to debug fw file
-n --nested_token	Get nested token for Retimer
-e --nested_debug_fw	Path to debug fw file for Retimer nested token
-p --tokens_dir <Path>	Path to a directory of tokens for aggregation
-v --version	Displays version info
-h --help	Displays help message
-s --i2c_secondary <i2c_secondary>	I2C secondary address
--b --blob	Path to challenge blob file (relevant for CRCS/CRDT token types)

Examples:

To create a CS token:

```
# mlxtokengenerator -d /dev/mst/mt4123_pciconf0 -k CS -t HCA -o /tmp/cs_token.xml generate_token
```

To create a DBG token:

```
# mlxtokengenerator -d /dev/mst/mt4123_pciconf0 -k DBG -t HCA -f /tmp/dbg_fw.bin -o /tmp/dbg_token.xml generate_token
```

To create a CRDT token with nested Retimer:

```
# mlxtokengenerator -d mt54004_pciconf0_cable_1 -k CRDT -t LinkX -debug_fw /tmp/dbg_fw.bin --nested_debug_fw /tmp/retimer_dbg_fw.bin --nested_token -o /tmp/dbg_token.xml generate_token
```

To create challenge based tokens with blob option

```
# mlxtokengenerator -b <blob_file> -k CRCS -t HCA -o <out.xml>  
generate_token
```

mlxdpa – DPA Applications Sign Tool

The mlxdpa tool allows the user to sign DPA applications, which are given to the tool as part of a Host ELF file.

It also supports creation, signing, and removal of single applications.

In addition, mlxdpa allows the user to add or remove certificates from the DPA device — this is done by creating certificate containers and signing them.

The tool generates the signatures using a provided private key PEM file.

Tool Requirements:

- Supported operating systems: Linux
- Supported platforms: x86-64, arm64

mlxdpa Synopsis

Sign Host ELF using PEM file

```
# mlxdpa --host_elf <ELF file> --cert_chain <certificate chain> -  
-private_key <key .pem file> --output_file <output file path>  
sign_dpa_apps
```

Create upload container for single app

```
mlxdpa -s /tmp/singleApp.elf --life_cycle_priority OEM -m  
/tmp/appmetadata.yaml --manifest /tmp/manifest.bin -o
```

```
/tmp/single_app.bin create_single_dpa_app
```

Sign upload container for single app using PEM file

```
mlxdpa -s /tmp/single_app.bin -c /tmp/chain.cert -p  
/tmp/p_key.pem [--cert_chain_count 5] --life_cycle_priority OEM -  
o /tmp/signed_single_app.bin sign_single_dpa_app
```

Query manifest from single elf

```
mlxdpa -s /tmp/singleApp.elf -o /tmp/manifest.bin query_manifest
```

Create Dpa app removal container

```
mlxdpa --dpa_app_uuid 7c0ab0fc-082e-11ee-bd9d-e43d1a1f06ae -o  
/tmp/dpa_app_removal_container.bin --life_cycle_priority OEM  
create_dpa_app_removal
```

Sign Dpa app removal container

```
mlxdpa --dpa_app_removal_container  
/tmp/dpa_app_removal_container.bin --keypair_uuid 3c8f46b2-159f-  
11ee-9ac4-e43d1a1f06ae -p /tmp/p_key.pem -o  
/tmp/signed_dpa_app_removal_container.bin --life_cycle_priority  
OEM sign_dpa_app_removal
```

Where:

-e --host_elf	Path to the Host ELF file containing DPA applications
-c --cert_chain	Path to a certificate chain file to embed in the crypto data
-p --private_key	Path to a private key PEM file for signature generation
-o --output_file	Path to output signed Host ELF
-h --help	Show help message
-v --version	Show tool version
--cert_chain_count <Hex number>	Number of certificates in the provided certificate chain
--dpa_app_removal_container <Path>	Path to a dpa app removal container to sign
--manifest <Manifest>	Path to the manifest file
-m --app_metadata <App Metadata>	Path to the app metadata yaml file
-s --single_app <Single App>	Path to the single app file

Creating a Certificate Container

Container for adding a certificate:

```
mlxdpa --cert_container_type add -c <.DER formatted certificate>
-o <output path> --life_cycle_priority <Nvidia,OEM,User>
create_cert_container
```

Container for removing a certificate:

```
mlxdpa --cert_container_type remove [--cert_uuid <uuid of the
certificate for removal>] [--remove_all_certs] -o <output path> --
life_cycle_priority <Nvidia,OEM,User> create_cert_container
```

Create a certificate upload container with the keep_sig flag

```
mlxdpa --cert_container_type add -c /tmp/cert.der -o  
/tmp/cert_container.bin --life_cycle_priority OEM --keep_sig  
create_cert_container
```

Create certificate upload container with nvidia_signed_oem flag

```
mlxdpa --cert_container_type add -c /tmp/cert.der -o  
/tmp/cert_container.bin --nvidia_signed_oem create_cert_container
```

Signing a Certificate Container

Container for adding a certificate:

```
mlxdpa --cert_container <container> -p <private key pem file> --  
keypair_uuid <uuid> --cert_uuid <uuid> --life_cycle_priority  
<Nvidia,OEM,User> -o <output path> sign_cert_container
```

Container for removing a certificate:

```
mlxdpa --cert_container <container> -p <private key pem file> --  
keypair_uuid <uuid> --life_cycle_priority <Nvidia,OEM,User> -o  
<output path> sign_cert_container
```

Where:

--cert_container	Path to a certificate container to sign
--cert_container_type <Add/Remove>	Type of a certificate container to create

-c --certificate	Path to a .DER formatted certificate
--keypair_uuid	Key-pair UUID of the private key used for signing
--cert_uuid	Time base UUID generated right before signing
--remove_all_certs	Remove all CA Certificates, provide with the sign_cert_remove command
--life_cycle_priority <Nvidia, OEM, User>	Life-cycle priority of a requested certificate container
-o --output_file	Path to an output file
-p --private_key	Path to a private key PEM file for signature generation
--nvidia_signed_oem	NVIDIA signed OEM certificate
-k --keep_sig	The whole certificate container will be kept

mlx cableimngen - Cable Firmware Image Wrapper Generation Tool

The specifications of a compatible cable hardware must be passed to the tool to create the image wrapper.

mlx cableimngen Synopsis

```
mlx cableimngen -d <OUI> -p <vendor pn> -r <vendor rev> -w <vendor hw major> -m <vendor fw major> -n <vendor fw minor> -b <vendor fw build> -i <fw image> [-j <vendor data>] -o <output path>
generate_image
```

Where:

-d --vendor_ieee_id	Vendor IEEE ID in Hex (6 characters)
-p --vendor_pn	Part number provided by vendor in ASCII (16 characters)
-r --vendor_rev	Revision level for part number provided by vendor in ASCII (2 characters)

-w --vendor_hw_major	Module hardware major revision in Hex (2 characters)
-m --vendor_fw_major	Module firmware major revision in Hex (2 characters)
-n --vendor_fw_minor	Module firmware minor revision in Hex (2 characters)
-b --vendor_fw_build	Module firmware build revision in Hex (4 characters)
-i --image_path	Path to FW image file
-j --vendor_data_path	Path to vendor data file (optional)
-o --output_path	Path to output image file

nvredfish

The nvredfish tool enables the user to query the BMC firmware and update the BMC firmware.

Users can perform firmware update to BMC (for the update to take effect, a full AC cycle of the board is needed).

Note

For the update to take effect, a full AC cycle of the board is needed.

Note

Initial FW burn is outside the scope of this feature.

Note

For the nvredfish tool to be installed as part of the MFT package, the user must provide `--with-nvredfish` argument to the install script.

User Flow

1. Generate token (not MFT related)
2. Generate mst device representing the BMC:

```
mst redfish add <bmc ip> <token>
```

3. Query:

```
nvredfish -d <> query
```

4. Burn the image:

```
nvredfish -d <> -p <.fwpkg> burn
```

After the burn command, for the firmware update to take effect, an AC cycle (physically disconnecting and then reconnecting the system's main power) of the board is needed.

Debug Utilities

This section contains:

- [fwtrace Utility](#)
- [mlxtrace Utility](#)
- [mlxptrace Utility](#)
- [mstdump Utility](#)
- [mlx2c Utility](#)
- [i2c Utility](#)


- [mget_temp Utility](#)
- [mlxdump Utility](#)
- [mlxmcg Utility](#)
- [pckt_drop Utility](#)
- [mlxuptime Utility](#)
- [wqdump Utility](#)
- [mlxmdio Utility](#)
- [mlxreg Utility](#)
- [mlxlink Utility](#)
- [mlxfwstress Utility](#)
- [resourcedump Utility](#)
- [resourceparse Utility](#)
- [stedump Utility](#)

fwtrace Utility

The fwtrace utility extracts and prints trace messages generated by the firmware running on 5th generation (Group II) devices iRISCs.

These trace messages inform developers of software drivers about internal status, events, critical errors, etc. Trace messages generated by iRISCs are stored in the trace buffer. The trace buffer is located in host memory. The tool also supports mem free mode where it uses a device internal small buffer.

By default, the firmware does not print trace messages. Please contact your FAE for more details on how to enable firmware tracing.



When using secure firmware, the user needs to validate that the value "1" is set to /sys/kernel/debug/tracing/events/mlx5/fw_tracer/enable.

As of MFT v4.30.0, fwtrace can extract events from secure devices (for supported Firmware versions) using mlxptrace utility and without the need of mlx5 driver. fwtrace will automatically use the new capabilities if the device supports it.

Note

Memory mode on 5th generation (Group II) devices is supported only by PCI mst devices.

Note

For the tool to properly work with Inband devices, both the MFT and the Firmware must be updated to the latest (MFT version 4.18.0 and above, and Firmware version XX.32.1xxx and above).

fwtrace Usage

1. Start the mst driver (mst start or mst restart)
2. Enter the following command:

```
# fwtrace [options...]
```

where

-h --help	Print this help message and exit
-----------	----------------------------------

-d --device	mst device name
-f --fw_strings	Fw strings db file containing the FW strings
--tracer_mode	Tracer mode [FIFO MEM]
--real_ts	Print real timestamps in [hh:mm:ss:nsec] format
-i --irisc	iRISC name (See below for full list of irisc names)
-t --tile	Allow the user to specify which tile events he would like to see. # "1.all" will enable risc 1 in all tiles. # "1" will be treated like "1.all" # "all" will be treated like all.all # "all.1" will enable all iriscs in tile 1 # .1 is invalid input.
-a --apu	If enabled, tool will show APU events.
--include_phy_uc	If enabled, tool will also show phy_uc events related to the enabled riscs (main / tiles)
--keep_cfg	If enabled, the FWtrace will not delete the temporary cfg file (if one was created during the current run)
-s --stream	Run in streaming mode
-c --cfg	Hardware tracer events cfg file
-n --snapshot	Take events snapshot - this assumes previous FW configurations
-S --buf_size	Hardware tracer MEM buffer size in [MB]
-p --dump	Dump file name
--raw_dump	Used with --dump flag to inform the tool the dump input type is .dump, which is coming from reasource_dump, and not .trc type that come from tracer tool
-m --mask	Trace class mask, use "+" to enable multiple classes or use integer format, e.g: -m class1+class2+... or 0xff00ff00
-l --level	Trace level
--log_delay	Firmware tracer log delay in uSec
v --version	Print tool's version and exit
--gvmi	Global virtual machine interface
--ignore_old_events	Ignore collecting old events
--mem_access	Memory access method: OB_GW, VMEM, UDRIVER

<code>--keep_running</code>	Keep the hardware tracer unit running after exit
<code>--config_only</code>	Configure tracer and exit
<code>--fw_cfg_only</code>	Skip HW config and only configure FW events (default=off)

Device Specific Info:

To view device specific information, run `"fwtrace -d <mst_dev> -h".`

Example:

```
fwtrace -d /dev/mst/mt4123_pciconf0 -i all -s -l 0 -m 0xFFFFFFFF
-I- Found FW string db cache file, going to use it
Got ownership successfully!
mlxtrace -d /dev/mst/mt4123_pciconf0 -m MEM --skip_ownership -c
/tmp/itrace_2946580.cfg -S
-I-      Tracer Configuration:
-I-      =====
-I-      Mode                                     : Collector
-I-      Activation Mode                         : Memory Mode
-I-      Memory Access Method                    : NA
-I-      Configuration File Path                 :
/tmp/itrace_2946580.cfg
-I-      Output file (Trace File) Path           : mlxtrace.trc
-I-      User Buffer Size                        : NAMBytes
-I-      Use Stream Mode                        : YES
-I-      Configure Only                         : NO
-I-      Only Snapshot (Skip Configuration Stage) : NO
-I-      Ignore old events                      : NO
-I-      Continuous fill                        : NO
-I-      Print timestamp in hh:mm:ss:nsec format : NO
-I-      Output file for streaming               : STDOUT
-I-      Delay between samples                   : 0usec
-I-      Stop tracer after exit                  : YES
-I-      =====
-I-      Tracer ownership is already taken or skipped
```

```

-I-      Device is: ConnectX6
-I-      Configuring Tracer...
-I-      Invalidating kernel buffer... (Press ^C to skip)
-I-      Done
-I-      Tracer was configured successfully
Device frequency: 430MHz
-I-      Starting event streaming...
#time stamp, unreliable, lost, missing TS, event name
Reading new events...
512458354925      I3              in pll_management_handler. freq_in
= 3.
512458355201      I3              in pll_management_handler. set pll
0 in center pll 0 to state 0.
512458355749      I3              in pll_management_handler. freq_in
= 3.
512458356030      I3              in pll_management_handler. set pll
1 in center pll 0 to state 0.
512458356583      I3              in pll_management_handler. freq_in
= 3.
512458356865      I3              in pll_management_handler. set pll
2 in center pll 0 to state 3. .
.
.

```

mlxtrace Utility

The mlxtrace utility is used to configure and extract HW events generated by different units in NVIDIA devices. The utility generates a dump ".trc" file which contains HW events that assist us with debug, troubleshooting and performance analysis. Events can be stored in host memory if driver is up or in a small on-chip buffer (always available) depending on the utility running mode. In order to run the utility it's required to have a configuration file first, this file should be provided by the NVIDIA representative.

A dump file "mlxtrace.trc" will be generated by end of run (file name can be controlled by "-o" flag), this file should be sent to the NVIDIA representative for further diagnostics/troubleshooting.

Note

Memory mode on 5th generation (Group II) devices is supported only by PCI mst devices. Memory mode is supported in Windows, as well as in Linux.

Note

For the tool to properly work with Inband devices, both the MFT and the Firmware must be updated to the latest (MFT version 4.18.0 and above, and Firmware version XX.32.1xxx and above).

mlxtrace Usage

1. The mst driver must be started prior to running the mlxtrace tool.
2. For MEM buffer mode driver must be "loaded" also.
3. Enter the following command:

```
mlxtrace [options]
```

Options

-h, --help	Print help and exit
-v, --version	Print version (default=off)
-p, --parse	Move to parser mode (default=off)

Mode: CollectMode

-d, --device=MstDev	Mst device
---------------------	------------

-m, --mode=Mode	Activation mode: FIFO - HW BUFFER , MEM - KERNEL BUFFER (possible values="FIFO", "MEM")
-a, --mem_access=MemMethod	Memory access method: OB_GW, VMEM, UDRIVER, PERFMON (possible values="OB_GW"/ "VMEM"/ "UDRIVER" "PERFMON")
--gvmi	Global virtual machine interface
-c, --cfg=CfgFile	Mlxtrace configuration file
-o, --trc_file=TrcPath	Output TRC file path (default= `mlxtrace.trc`)
-C, --config_only	Configure tracer and exit (default=off)
-b, --backpressure	Enable "Allow_backpressure" for all supported hardware events (default=off)
-n, --snapshot	Take events snapshot - This assumes previous run with --config_only (default=off)
-s, --buf_size=BufSize	User buffer size [MB] (default= `1`)
-S, --stream	Don't save events to file parse it immediately (default=off)
--ignore_old_events	Ignore collecting old events in MEM mode (default=off)
-g, --continuous_fill	Do not stop recording (stopping only with ^C), keep filling user's buffer cyclically (default=off)
--sample_delay=Delay	Delay between samples when polling new events in [usec] (default= `0`)
--keep_running	Keep the HW tracer unit running after exit (default=off)
--enable_limiting_every_chunk	Limit the HW tracer after reading every chunk (default=off)
--fw_cfg_only	Skip HW config and only configure FW events (default=off)
--skip_ownership	Skip taking ownership (default=off)

Mode: ParseMode

-i, --input=TrcFile	Input file (default= `mlxtrace.trc`)
--csv_mode	Enable csv output format (default=off)
--print_ts	Print timestamp events (default=off)

<code>-r, --real_ts</code>	Print real timestamps in [hh:mm:ss.nsec] format (default=off)
<code>--print_raw</code>	Print event bytes in each line header (default=off)
<code>--ts_format=format</code>	Choose printed TS format hex/dec (possible values="hex", "dec" default=`dec`)
<code>--print_delta</code>	Enable printing delta between events (in cycles) (default=off)
<code>-f, --print_file=FilePath</code>	Print parsed event to the given file and not to stdout
<code>--enable_db_check</code>	Enable events DB checks (default=off)

Examples:

Choose the suitable .cfg file depending on the device you are using, and run the following command to generate a .trc file:

```
# mlxtrace -d /dev/mst/mt4123_pciconf0 -c ConnectX6.cfg -m MEM -o
ConnectX6.trc
```

To generate a .trc file with a maximal size of 100 MB, run the following command:

```
# mlxtrace -d /dev/mst/mt4123_pciconf0 -c ConnectX6.cfg -m MEM -s
100 -o ConnectX6.trc
```

mlxpttrace Utility

The mlxpttrace utility is used to configure and extract FW events generated by different units in NVIDIA devices.

This utility was added in MFT v4.30 to provide solutions for supported secured devices with the need of debug token.

- The utility is only supported in Linux environment
- It is recommended to run the tool via fwtrace and not directly from command line

- the tool has similar interface to the mlxtrace and same .cfg files can be used for both tools. (for more information please review the mlxtrace utility)

mlxptrace Usage

1. The mst driver must be started prior to running the mlxptrace tool.
2. Enter the following command:

```
mlxptrace [options]
```

Options:

-h, --help	Print help and exit
-p, --parse	Move to parser mode (default=off)
-d, --device=MstDev	Mst device
-m, --mode=Mode	Currently only FIFO mode is supported (possible values are "FIFO", "MEM" for compatibility with mlxtrace).
--gvmi	Global virtual machine interface
-c, --cfg=CfgFile	mlxtrace configuration file
-o, --trc_file=TrcPath	Output TRC file path (default= ` mlxtrace.trc`)
-C, --config_only	Configure tracer and exit (default=off)
-n, --snapshot	Take events snapshot - This assumes previous run with --config_only (default=off)
-s, --buf_size=BufSize	User buffer size [MB] (default= ` 1`)
-S, --stream	Don't save events to file parse it immediately (default=off)
--ignore_old_events	Ignore collecting old events in MEM mode (default=off)
-g, --continuous_fill	Do not stop recording (stopping only with ^C), keep filling user's buffer cyclically (default=off)
--keep_running	Keep the HW tracer unit running after exit (default=off)
--fw_cfg_only	Skip HW config and only configure FW events (default=off)
--skip_ownership	Skip taking ownership (default=off)

-i, --input=TrcFile	Input file (default= `mlxtrace.trc')
--raw_dump	When set, the parse input file will be considered as raw dump taken from resource dump instead of .trc file. Must be used with --cfg and --parse flags.
--csv_mode	Enable csv output format (default=off)
--print_ts	Print timestamp events (default=off)
--print_raw	Print event bytes in each line header (default=off)
--ts_format	Switch printed TS format to hex, default=dec
--print_delta	Enable printing delta between events (in cycles) (default=off)

mstdump Utility

The mstdump utility dumps device internal configuration registers. The dump file is used by the Support team for hardware troubleshooting purposes. It can be applied on all NVIDIA devices.

Note

For the tool to properly work with Inband devices, both the MFT and the Firmware must be updated to the latest (MFT v4.18.0 & firmware vXX.32.1014).

Note

If ConnectX-4 adapter card is used as an Inband device, for the tool to work properly, you need to use MFT 4.17.0.

mstdump Usage

To run mstdump:

```
# mstdump [-full] <mst device> > <dump file>_FW_VERSION
```

where the `-full` flag dumps all internal registers

positional arguments:

device	The device name
--------	-----------------

optional arguments:

-h, --help	show help message and exit
-v, -version, --version	show program's version number and exit
-full, --full	Dump more expanded list of addresses
-ignore_fail, --ignore_fail	Continue dumping, even if some addresses fails
-c CSV, -csv CSV, --csv CSV	Database path
--cause address.offset	Specify address and offset
--i2c_secondary I2C_SECONDARY	I2C secondary [0-127]

Example:

```
[root@mymach]# mstdump /dev/mst/mt4099_pci_cr0 >
mt4099_12_16_2600.dmp
```

This dumps the internal configuration data of the device into the mt4099.dmp file.

mlx2c Utility

The mlx2c utility provides a way to route the I2C bus to 4th generation (Group I) switches.

mlx2c Usage

The mst driver must be started prior to running mlx2c.

To start mlx2c:

1. Start the mst driver (mst start or mst restart). Note: This step is not required in Windows.
2. Run mlx2c with the following command line syntax:

```
# mlx2c [switches...] <command> [parameters...]
```

Switches Options

-d <device>	mst i2c device name default: "/dev/mst/mtusb-1" Affected commands: all
-h	Print this help information
-s, --i2c-secondary <address>	Change the I2C secondary address.
-v	Print version and exit

Commands

p <i2c_component>	Route the i2c path to the indicated i2c component
scan	Scan the i2c slave addresses

Example:

Display the addresses of all I2C-accessible devices:

```
# mlx2c -d /dev/mst/mtusb-1 scan
```

i2c Utility

The i2c utility provides low level access to the I2C bus on any NVIDIA switch platform, enabling the user to read or write data.

i2c Usage (Advanced Users)

The mst driver must be started prior to running i2c tool.

To start i2c:

1. Start the mst driver (mst start or mst restart). Note: This step is not required in Windows.
2. Run i2c with the following command line syntax:


```
# i2c [OPTIONS] <device> <cmd> <i2c_addr> <addr> [<data>]
```

where:

-h	Prints this message.
-a <addr_width>	Sets address width (in bytes) to the specified value. May be 0, 1, 2 or 4. Default: 1.
-d <data_width>	Sets data width (in bytes) to the specified value. May be 1, 2 or 4s. Default is 1.
-x <data_len>	Presents each byte of data as two hexadecimal digits (such as 013C20343B). Note that this option is mutually exclusive with the "-d" option.

The remaining parameters are:

<device>	Valid mst device.
<cmd>	Command. May be "r[ead]" or "w[rite]".
<i2c_addr>	I2C slave address.
<addr>	Address (of length addr_width) inside I2C target device to read/write operation. Note that the <addr> value is ignored if <addr_width> = 0.
<data>	Data (bytes of length data_width) to write to target device.



Note

All parameters are interpreted as hexadecimal values.

Examples:

Read two bytes from address 0 of target I2C slave address 0x56:

```
# i2c -a 2 -d 2 /dev/mst/mtusb-1 r 0x56 0x00
0000
```

Write two bytes to the address above then read them:

```
# i2c -a 2 -d 2 /dev/mst/mtusb-1 w 0x56 0x00 0x1234
# i2c -a 2 -d 2 /dev/mst/mtusb-1 r 0x56 0x00
3412
```

Read (as separate) 16 bytes in hexadecimal format starting from address 0 of the target device above:

```
# i2c -a 2 -x 16 /dev/mst/mtusb-1 r 0x56 0x00
12340000000000000000000000000000
```

Exit Return Values

The following exit values are returned:

- 0 - successful completion
- >0 - an error occurred

mget_temp Utility

The `mget_temp` utility reads the hardware temperature from NVIDIA devices with temperature sensors (all NVIDIA devices) and prints the result in Celsius degrees.

mget_temp Usage

To run `mget_temp`:

```
# mget_temp [OPTIONS]
```

where:

-h	Print the help message.
-d <dev>	mst device name.
--version	Display version info.
-s <i2c-secondary>	I ² C secondary address
-v	print a table of all thermal diode data

Example on how to read a device temperature:

```
# mget_temp -d /dev/mst/SW_MT51000_0002c903007e76a0_lid-0x0002
```

Note

`mget_temp` utility reads the IC temperature, it does not support reading temperature from peripheral sensors on the board.

mixdump Utility

The mlxdump utility dumps device internal configuration data and other internal data (such as counters, state machines).

The data can be used for hardware troubleshooting. It can be applied to all NVIDIA devices.

The tool has 3 run modes: [fast | normal | full] while the default is "fast", the "full" mode dumps all available data but might run slower than normal and fast modes.

The tool also can dump only flow steering information using the fsdump sub-command (See example below). The fsdump sub-command has the flag --type to specify the type of the flow steering: STE or FT or All.

The tool can dump only mstdump information using the mstdump sub-command (see example below). The mstdump sub-command has multiple flags: --full, i2c_slave, cause_addr and cause_offset which enable the user to run with the needed parameters.

mlxdump Usage

The mst driver must be started prior to running mlxdump tool.

```
mlxdump OPTION <command> [COMMAND OPTIONS] [-d|--device MstDevice] [-h|--help] [-v|--version]
```

where:

-d --device MstDevice	mst device name
-h --help	Show help message and exit
-v --version	Show version and exit
mstdump	Read mstdump information
fsdump	Read Flow Steering information. Note: Reading flow steering information is supported in ConnectX-4 and above adapter cards.
snapshot	Dump everything

Note

To view <command> related options please run: "mlxdump OPTION <command> -h"

Examples:

To generate "mlxdump.udmp" while running in fast mode:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 snapshot
```

To generate "mlxdump.udmp" while running in full mode:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 snapshot -m full
```

To generate "mlxdump_13_1_2013.udmp" while running in normal mode:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 snapshot -m normal -o  
mlxdump_13_1_2013.udmp
```

To generate flow steering information:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 fsdump --type=All --gvmi=0
```

To generate mstdump information::

```
# mlxdump -d /dev/mst/mt4119_pciconf0 mstdump
```

mlxmcg Utility

The mlxmcg tool displays the current multicast groups and flow steering rules configured in the device. Target users: Developers of Flow Steering aware applications.

This tool dumps the internal steering table which is used by the device to steer Ethernet packets and Multicast IB packets to the correct destination QPs.

Each line in the table shows a single filter and a list of destination QPs. Packets that match the filter are steered to the list of destination QPs.

Note

- mlxmcg is not supported against In-band device.
- mlxmcg is supported in ConnectX-3/ConnectX-3 Pro only.

mlxmcg Usage

The mst driver must be started prior to running mlxmcg tool. To start mlxmcg:

1. [Optional for Windows OSs] Start the mst driver (mst start or mst restart).
2. Enter an mlxmcg command that complies with the following command syntax:

```
# mlxmcg [OPTIONS]
```

where:

-h, --help	Show this help message and exit
------------	---------------------------------

-d DEV, --dev=DEV	mst device to use, required
-f FILE, --file=FILE	MCG dump file to use (for debug). Used as input - no need for a device.
-p PARAMS, --params=PARAMS	Mcg params, (MCG_ENTRY_SIZE, HASH_TABLE_SIZE, MCG_TABLE_SIZE), default is (64, 32768, 65536)
-q, --quiet	Do not print progress messages to stderr
-v, --version	Print tool version
-c, --hopcount	Add hopCount column
-a, --advanced	Show all rules

This will display all the current multicast groups and flow steering rules configured in the device.

Example:

```
Command : mlxmcg -d /dev/mst/mt4099_pci_cr0
MCG table size: 64 K entries, Hash size: 32 K entries, Entry size:
64 B
Progress: HHHHHLLLL
Bucket Index ID Prio Proto DQP Port VLAN MAC SIP DIP I-MAC I-VLAN
VNI L4 SPort DPort Next QPs
0 0 0 0 all -- 2 -- -- -- -- -- -- -- -- -- 1009c 11
af9 fee0 0 5000 IPv6 -- ff0e:0000:0000:0000:0000:e000:0001 - -- --
-- -- -- 8012 SB
e3f e3f 0 5000 L2 -- 2 -- 01:80:c2:00:00:0e -- -- - -- -- -- --
8012 40048
1139 1139 0 5000 L2 -- 2 -- 01:00:5e:00:00:01 -- -- - -- -- -- --
8014 40048
26fc 26fc 0 5000 L2 -- 2 -- ff:ff:ff:ff:ff:ff -- -- - -- -- -- --
-- 8018 40048
2a3e 2a3e 0 5000 L2 -- 2 -- 33:33:00:00:00:01 -- -- - -- -- -- --
801a 40048
4000 4000 0 0 all -- 2 -- -- -- -- -- -- -- -- -- 1009c 10
45d7 45d7 0 5000 L2 -- 1 -- 01:00:5e:00:00:fb -- -- - -- -- -- --
- 8000 4004a
```

```

4af9 fef8 0 5000 IPv6 -- ff0e:0000:0000:0000:0000:e000:0001 -- --
-- -- -- 8002 SB
4e3f 4e3f 0 5000 L2 -- 1 -- 01:80:c2:00:00:0e -- -- -- -- -- -- --
- 8002 4004a
5139 5139 0 5000 L2 -- 1 -- 01:00:5e:00:00:01 -- -- -- -- -- -- --
8004 4004a
66fc 66fc 0 5000 L2 -- 1 -- ff:ff:ff:ff:ff:ff -- -- -- -- -- -- --
-- 8008 4004a
6a3e 6a3e 0 5000 L2 -- 1 -- 33:33:00:00:00:01 -- -- -- -- -- -- --
800a 4004a
734b 734b 0 5000 L2 -- 1 -- 33:33:e0:00:00:01 -- -- -- -- -- -- --
- 800c 4004a
Duplicated MCGS: Count
1000 1000 0 5000 L2 -- 2 -- 00:02:c9:00:00:02 -- -- -- -- -- -- --
8015 40048 2048
4002 4002 0 5000 L2 -- 1 -- 00:02:c9:00:00:01 -- -- -- -- -- -- --
8001 4004a 2046
16 Unique rules, 4108 Total
Index QPs
=====
fee0 40054 40055 40056 40057 40058 40059 4005a 4005b 4005c 4005d 4005e
4005f 40060
40061 40062 40063 40064 40065 40066 40067 40068 40069 4006a 4006b 4006c
4006d
4006e 4006f 40070 40071 40072 40073 40074 40075 40076 40077 40078 40079
4007a
4007b
=====
fef8 40054 40055 40056 40057 40058 40059 4005a 4005b 4005c 4005d 4005e
4005f 40060
40061 40062 40063 40064 40065 40066 40067 40068 40069 4006a 4006b 4006c
4006d
4006e 4006f 40070 40071 40072 40073 40074 40075 40076 40077 40078 40079
4007a
4007b
=====

```

pckt_drop Utility

The pckt_drop utility corrupts the next transmitted packet from a ConnectX family adapter port.

pckt_drop Usage

Run the pckt_drop with the following command line syntax:

-d, --device	Specify the mst device to configure. (Required.)
-h, --help	Print this help screen and exit.
-m, --mode	Specify operating mode. Supported modes are: EDP : Inserts error on next transmitted data packet. (Default: EDP)
-p, --port	Select which port to configure. Use `1`/`2` for port1/port2, respectively, or `b` for both. (Default: b)
-v, --version	Print the application version and exit.

Example:

```
# pckt_drop -d /dev/mst/mt4117_pciconf0 -p 1
```

The example above shows how to use the pckt_drop to corrupt a packet from port 1.

mlxuptime Utility

The mlxuptime is a firmware which prints NVIDIA devices' up time and measured/configured frequency.

mlxuptime Usage

```
mlxuptime [options]
```

where:

-d <dev> --device	Mst device name
-s <time> --sample	Sampling interval for measuring frequency (default: 1 [sec])
-h --help	Print help and exit
-v --version	Print tool version and exit
-f, --force_sample	Force sampling interval for measuring frequency. Default: Reading up time from device.

Examples:


Print all info:

```
# mlxuptime -d /dev/mst/mt4117_pciconf0
Measured core frequency      : 427.099818 MHz
Device up time               : 10:01:20.456344 [h:m:s.usec]
```

wqdump Utility

The wqdump utility dumps device internal work queues. A work queue is an object containing a Queue Pair Context (QPC) which contains control information required by the device to execute I/O operations on that QP, and a work queue buffer which is a virtually-contiguous memory buffer allocated when creating the QP.

The dumped data can be used for hardware troubleshooting. It can be applied on ConnectX adapter cards family and Connect-IB adapter devices.



wqdump on ConnectX-3 and ConnectX-3 Pro is not supported against in-band devices.

wqdump Usage

The mst driver must be started prior to running the wqdump utility. To start the wqdump utility:

1. Start the mst driver (mst start or mst restart).
2. Run wqdump:

```
# WQDump <-d|--device DeviceName> <--source ContextType> [--  
gvmi Gvmi] [--qp ContextNumber]  
<--dump DumpType> [--fi StartIndex] [--num NumberOfItems] [--  
format Format]  
[--address Address] [--size Size] [-v|--version] [-h|--help]  
[--clear_semaphore] [--gw_access]
```

where:

--d --device DeviceName	Device name
--source ContextType	Type of context to dump. Options are: Snd, Rcv, Cmp, Srq, Eqe, Connect-X3/Pro: MCG,5th generation devices: MKC, SXDC, FullQpConnectX-5: CMAS_QP_WQE, CMAS_QP_SWQ, CMAS_SRQ_WQE, CMAS_CQ_BUFF, CMAS_QP_DBR, CMAS_QP_SDB, CMAS_SRQ_DB, CMAS_CQ_DBR, CMAS_CQ_ARM, CMAS_EQ_BUFF, CMAS_TAG_MATCH.CMAS_INLINE
--gvmi Gvmi	Guest VM ID (5th generation devices)
--qp ContextNumber	Context number to dump
--dump DumpType	Dump Type. Options are: WQ, QP, WQ_QP, ALL_QPC, ALL_VALID_QPNS, ICM

--fi StartIndex	Index of first element to dump, (Default:0)
--num NumberOfItems	Number of elements to dump from buffer, (Default: keep reading)
--format Format	Output format: options are : text, raw, dw, (Default: text)
--address Address	Memory Address
--size Size	Memory size in bytes
-v --version	Show tool version and exit
-h --help	Show usage
-- clear_semaphore	Force clear semaphore
--gw_access	Force get QPC by GW access (Connect-X 3/Pro)

4th Generation Device Examples:

Print all valid qpns

The example below will dump all valid qpns of type mcg context.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source mcg --dump
ALL_VALID_QPNS
```

Dump mcg qp

The example below will dump mcg context number 0x10.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source mcg --dump QP -qp
0x10
```

Dump other qpns

The example below will dump snd context number 0x10 in a raw format.


```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source snd --dump QP -qp
0x10 --format raw
```

Dump wq

The example below will dump send work queue buffer number 0x42.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source snd --dump wq -qp
0x42
```

Dump mcg qp by GW access

The example below will dump mcg context number 0x10 by GW access.

```
# wqdump -d /dev/mst/mt4103_pci_cr0 --source mcg --dump QP -qp
0x10 --gw_access
```

5th Generation Device Examples:

FullQp: The QP context of the Rcv and Snd with the common part. Note, FullQp does not have dump as WQ.

- Get opened contexts from the first 20 indexes:

```
# wqdump -d /dev/mst/mt4117_pciconf0 --source FullQp --dump
ALL_VALID_QPNS --num 20
Numbers of valid contexts (in the range 0x0 - 0x13):
index 0x00000003
index 0x00000006
index 0x00000007
index 0x0000000b
index 0x0000000c
```

```
index 0x00000013
```

```
-----  
Number of valid contexts: 6  
-----
```

- Show the QP Context (RAW):

```
# wqdump -d /dev/mst/mt4117_pciconf0 --source FullQp --dump QP --  
qp 0x0000000b --format raw  
== Common Part (Not Connected) ==  
0. 80000000 0000001e 05000000 00000000  
1. 70000000 00000000 00000000 00000000  
2. 0000000b 00ffffff 00000000 00000000  
3. 00000000 00000000 00000000 80010000  
-----  
Send Qpc gvmi 0000 QP Index 0000000b  
0. 80000000 0000001e 05000000 00000000  
1. 70000000 00000000 00000000 00000000  
2. 0000000b 00ffffff 00000000 00000000  
3. 00000000 00000000 00000000 80010000  
-----  
== Responder Part (Not Connected (mac)) ==  
Recv Qpc gvmi 0000 QP Index 0000000b  
0. b8eccd02 00000000 d8f5cd02 00000000  
1. d0010000 00000000 40000000 00000000  
2. e0e03903 00000000 f0e03903 00000000  
3. 00000000 00000000 00000000 00000000  
-----
```

SRQ

- Opened QPs:

```
# wqdump -d /dev/mst/mt4115_pciconf0 --source Srq --dump
all_valid_qpns
Numbers of valid contexts (in the range 0x0 - 0xffffffff):
gvmi 0x0000 index 0x00000060
gvmi 0x0000 index 0x00000061
gvmi 0x0000 index 0x00000066
```

- Dump WQs:

```
0x00000066# wqdump -d /dev/mst/mt4117_pciconf0 --source Srq --dump
wq --qp 0x60
[Element Index 0]
----- SRQ Next -----
next_wqe_index : 0x1
signature : 0x0
----- scatter entry (0) -----
byte_count : 0x0
wqe_inline : 0x0
local_key : 0x0
local_address_63_32 : 0x0
local_address_31_0 : 0x0
[Element Index 0x1]
----- SRQ Next -----
next_wqe_index : 0x0
signature : 0x0
----- scatter entry (0) -----
byte_count : 0x0
wqe_inline : 0x0
local_key : 0x0
local_address_63_32 : 0x0
local_address_31_0 : 0x0
```

CMAS

- Opened contexts from some CMAS type (CMAS_EQ_BUFF for ex):

```
#wqdump -d /dev/mst/mt4119_pciconf0 --source CMAS_EQ_BUFF --dump
ALL_VALID_QPNS
Numbers of valid contexts (in the range 0x0 - 0xffffffff):
gvmi 0x0000 index 0x00000002
gvmi 0x0000 index 0x00000010
gvmi 0x0000 index 0x00000011
gvmi 0x0000 index 0x00000012
gvmi 0x0000 index 0x00000013
gvmi 0x0000 index 0x00000014
gvmi 0x0000 index 0x00000015
```

- Dump raw data:

```
# wqdump -d /dev/mst/mt4119_pciconf0 --source CMAS_EQ_BUFF --dump
QP --qp 0x15 --format raw
CMAS gvmi 0000 CMAS Index 00000015
0. 80000002 00000000 00000000 e4f80000
1. 00000000 00000000 00000000 00000000
2. 00000000 00000000 00000000 00000000
3. 00000000 00000000 00000000 00000000
-----
```

mlxmdio Utility

The mlxmdio tool is used to read/write MDIO registers (Clause 45) on Boards with externally managed PHY.

mlxmdio Usage

To run mlxmdio, use the following line:

```
# mlxmdio -d mst_dev -m phy_addr:dev_addr -g mdio_gw -a  
addr[:data] [-r size] [-w input_file]
```

where:

-d <device>	mst device
-m <mdio_id>	The mdio id of the target device in phy_addr:dev_addr format.
-a <addr[:data]>	Access a single MDIO reg. If data is specified, the reg is written, Otherwise, it is read. Addr and data should be in hex format.
-g <mdio_gw>	Select which mdio gateway <0..10> to use.
-c <clause>	Select which clause to use: • 22: clause 22. • 45: clause 45 (Default).
-r <size>	Read a block of <size> 16-bit words (max size 64)
-w <input_file>	Write a block from <input_file>. Every line of input file should be addr:data in hex.
-h	Show usage.
-v	Show tool version.

Methods for Sending MDIO Transactions

mlxmdio will attempt to send the MDIO transaction through a firmware interface if supported (on supported devices only). The mdio gateway values should be in the range of 0..10.

Note

Sending MDIO transactions via FW requires specification of the PCI device.

Example:

To read mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -a 0x0 -g 6
```

To write mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -a 0x0:0x0124 -g 6
```

To read block of 5 sequential operations through mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -a 0x14 -g 6 -r 5
0x0014:0x0010
0x0015:0x0003
0x0016:0x0030
0x0017:0x0040
0x0018:0x0050
```

Note

The address of the beginning of the block should be provided with the "-a" flag (e.g., `-a 0x14`).

To write block of operations through mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -g 6 -w input.txt
```

Note

Every line of the input file should be formatted as addr:data in hex.
The address of every line is not necessarily in a sequential order.

An example of the input file:

0x0017:0x0040

0x0014:0x0010

0x0015:0x0003

0x0018:0x0050

0x0016:0x0030

mlxreg Utility

The mlxreg utility allows users to obtain information regarding supported access registers, such as their fields and attributes. It also allows getting access to register data from firmware and setting access register data on firmware.

Registers can be get/set in unknown (RAW) mode by providing register ID and length.

Note

Unknown (RAW) mode is risky as no checks are performed, please consult with [Support](#) before using it.

mlxreg Usage

mst driver must be started prior to running mlxreg tool.

Some access registers depend on setup configuration such as link up/down. Invalid setup may cause failures.

To run mlxreg, use the following line:

```
mlxreg [options]
```

where:

-h --help	Displays help message.
-v --version	Displays version info.
-d --device <device>	Performs operation for a specified mst device.
-a --adb_file <adb_file>	An external ADB file
--reg_name <reg_name>	Known access register name
--reg_id <reg_ID>	Access register ID
--reg_len <reg_length>	Access register layout length (bytes)
-i --indexes <idxs_vals>	Register indexes
-g --get	Register access GET
-s --set <reg_dataStr>	Register access SET
--show_reg <reg_name>	Prints the fields of a given reg access (must have reg_name)
--show_regs	Prints all available access registers
--yes	Non-interactive mode, answer yes to all questions
--i2c_secondary <i2c_secondary>	I ² C secondary address
-w --overwrite	Set only specified fields, set unspecified fields to zero (only valid for SET command)
--full_path	Show field names with full hierarchical path. (Recommended to use it always to avoid field ambiguity)

Examples:

Show all available access registers (the example below shows a sample of the whole list):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --show_regs
```

```
Available Access Registers
```

```
=====
```

```
CWTP
```

```
CWTPM
```

```
MCIA
```

```
MLCR
```

```
MPCNT
```

```
MPEIN
```

```
NCFG
```

```
PAOS
```

```
PDDR
```

```
PMDR
```

```
PMLP
```

```
PPAOS
```

```
PPCNT
```

```
PPLM
```

```
PPLR
```

```
PPRT
```

```
PPTT
```

```
PTAS
```

```
PTYS
```

```
ROCE_ACCL
```

```
SBCM
```

```
SBD CR
```

```
SBPM
```

```
SBPR
```

```
SBSR
```

```
SLRG
```

```
SLRP
```

```
SLTP
```

.....

Query a single access register (PAOS):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --show_reg PAOS
```

Field Name	Address (Bytes)	Offset (Bits)	Size (Bits)	Access
------------	-----------------	---------------	-------------	--------

oper_status	0x00000000	0	4	R0
admin_status	0x00000000	8	4	RW
local_port	0x00000000	16	8	INDEX
swid	0x00000000	24	8	INDEX
e	0x00000004	0	2	RW
ee	0x00000004	30	1	WO
ase	0x00000004	31	1	WO

Note: There might be indexes in access register fields that must be provided when setting or getting data.

Get access register data (PAOS with indexes: local port 1, swid 0):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --reg_name PAOS --get --
```

```
indexes "local_port=0x1,swid=0x0"
```

Field Name	Data
------------	------

oper_status	0x00000001
admin_status	0x00000001
local_port	0x00000001
swid	0x00000000
e	0x00000000
ee	0x00000000
ase	0x00000000

```
=====
```

Set access register data (PAOS with indexes: local_port 1 swid 0x0 and data: e 1):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --reg_name PAOS --indexes
"local_port=0x1,swid=0x0" --yes --set "e=0x1"
You are about to send access register: PAOS with the following
data:
Field Name | Data
=====
oper_status | 0x00000002
admin_status | 0x00000001
local_port   | 0x00000001
swid         | 0x00000000
e            | 0x00000001
ee           | 0x00000000
ase          | 0x00000000
=====
Do you want to continue ? (y/n) [n] : y
Sending access register...
```

Get access register data (PAOS (0x5006) in unknown mode (RAW) with indexes: local_port=0x1 swid=0x0):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --reg_id 0x5006 --reg_len 0x10 -
-indexes "0x0.16:8=0x1,0x0.24:8=0x0" --get
Address      | Data
=====
0x00000000 | 0x00010101
0x00000004 | 0x00000000
0x00000008 | 0x00000000
0x0000000c | 0x00000000
```

=====

Set access register data (PAOS in unknown mode (RAW) with indexes: local_port=0x1 swid=0x0 and data e 1):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --reg_id 0x5006 --reg_len 0x10 -
-indexes "0x0.16:8=0x1,0x0.24:8=0x0" --yes --set "0x4.0:2=0x1"
You are about to send access register id: 0x5006 with the
following data:
Address      | Data
=====
0x00000000 | 0x00010102
0x00000004 | 0x00000001
0x00000008 | 0x00000000
0x0000000c | 0x00000000
=====
Do you want to continue ? (y/n) [n] : y
Sending access register...
```

mlxlink Utility

The mlxlink tool is used to check and debug link status and related issues. The tool can be used on different links and cables (passive, active, transceiver and backplane).

Note

- In order for mlxlink to function properly, make sure to update the firmware version to the latest version.
- mlxlink is intended for advanced users with appropriate technical background.
- When using mlxlink to disable the port state ("--port_state dn" flag) on a NIC connected through a Socket-Direct connection,

the port must be disabled on both mst devices representing the physical port.

- Do not use mlxlink to disable the port connecting between the host and the unmanaged switch using (“--port_state dn”) flag.
- When running mlxlink to show SLTP for 16nm technology, the “--advanced” flag should be added to the run command.
- mlxlink errors, warnings and notes are printed on stderr console.
- Setting the speeds (50GbE, 100GbE and 200GbE) for the new devices (NVIDIA ConnectX-6 and above, NVIDIA Quantum switches and above) requires specifying the number of lanes for the speed: mlxlink -d <dev> --speeds [50G_2X | 50G_1X | 100G_2X | 100G_4X | 200G_4X].
- In ConnectX-7 and later cards, configuring the loopback can be applied when the link is fully down (not in polling state).

mlxlink Usage

To run mlxlink:

```
mlxlink [OPTIONS]
```

where:

Options:

-h --help	Display help message.
-v --version	Display version info.
-d --device <device>	Perform operation for a specified mst device
-p --port <port_number>	Port Number
--port_type <port_type>	Port Type [NETWORK(Default)/PCIE/OOB]

--depth <depth>	Depth level of the DUT of some hierarchy (valid for PCIe port type only)
--pcie_index <pcie_index>	PCIe index number (Internal domain index) (valid for PCIe port type only)
--node <node>	The node within each depth (valid for PCIe port type only)
--json	Print the output in JSON format

Queries:

--show_links	Show valid PCIe links (valid for PCIe port type only)
-m --show_module	Show Module Info
-c --show_counters	Show Physical Counters and BER Info
-e --show_eye	Show Eye Opening Info
--show_fec	Show FEC Capabilities
--show_serdes_tx	Show Transmitter Info
--show_tx_group_map <group_num>	Display all label ports mapped to group <group_num> (for NVIDIA Spectrum-2 and NVIDIA Quantum devices).
--show_device	General Device Info
--show_ber_monitor	Show BER Monitor Info. Note: The flag is not supported in HCAs.
--show_external_phy	Show External PHY Info Note: The flag is supported in NVIDIA Spectrum switch systems only.
--show_plr	Show Physical Layer Retransmission (PLR) Info Note: The flag is supported in NVL5 (and above) switch systems only.
--show_kr	Show Link Training Optimization (KR) Info Note: The flag is supported in NVL5 (and above) switch systems only.
-- show_rx_recovery_counters	Show Rx Recovery Counters Note: The flag is supported in NVL5 (and above) switch systems only.
--show_peq	Show Link Periodic Equalization (PEQ) Info Note: The flag is supported in NVL5 (and above) switch systems only.

Commands:

-a --port_state <port_state>	Configure Port State [UP(up)/DN(down)/TG(toggle)]
-s --speeds <speeds>	Configure Speeds [speed1,speed2,...]
--link_mode_force	Configure Link Mode Force (Disable AN)
-l --loopback <loopback>	Configure Loopback Mode [NO(no loopback)/RM(phy re]
-k --fec <fec_override>	Configure FEC [AU(Auto)/NF(No-FEC)/FC(FireCode FEC)/
--fec_speed <fec_speed>	Speed to Configure FEC [100G/50G/25G/...] (Default is A
--serdes_tx <params>	Configure Transmitter Parameters [polarity,ob_tap0,...]
--serdes_tx_lane <transmitter_lane>	Transmitter Lane to Set (Optional - Default All Lanes)
--database	Save Transmitter Configuration for Current Speed Perm
--tx_params_override	Set the parameters according to Data Base only, otherw
--tx_group_map <group_num>	Map ports to group <group_num> (for NVIDIA Spectrun
--ports <ports>	Ports to be mapped [1,2,3,4..]
--test_mode <prbs_mode>	Physical Test Mode Configuration [EN(enable)/DS(disabl
--rx_prbs <rx_prbs_mode>	RX PRBS Mode [PRBS31(Default)/PRBS7/...] (Optional - I
--tx_prbs <tx_prbs_mode>	TX PRBS Mode [PRBS31(Default)/PRBS7/...] (Optional - I
--rx_rate <rx_lane_rate>	RX Lane Rate [EDR(Default)/25G/10G/...] (Optional - Defa
--tx_rate <tx_lane_rate>	TX Lane Rate [EDR(Default)/25G/10G/...] (Optional - Defa
--invert_tx_polarity	PRBS TX polarity inversion (Optional - Default No Inversi
--invert_rx_polarity	PRBS RX polarity inversion (Optional - Default No Inversi
--lanes	PRBS lanes to set (one or more lane separated by comm Optional: Default all lanes
--rx_modulation	RX Modulation [NRZ/PAM4/PAM4_PRECODING/PAM4_N
--tx_modulation	TX Modulation [NRZ/PAM4/PAM4_PRECODING/PAM4_N
-b --ber_collect <csv_file>	Port Extended Information Collection [CSV File]
--amber_collect <csv_file>	AmBER Port Extended Information Collection For 16nm
--ber_limit <limit_criteria>	BER Limit Criteria [Nominal(Default)/Corner/Drift] (Optic
--iteration <iteration>	Iteration Number of BER Collection

--pc		Clear Counters
--set_external_phy		Set External PHY Note: The flag is supported in NVIDIA Spectrum switch
	--twisted_pair_force_mode <twisted_pair_force_mode>	Twisted Pair Force Mode [MA(Master)/SL(Slave)]
--cable		Perform operations on the cables
	--dump	Dump cable pages in raw format
	--ddm	Get cable Digital Diagnostic Monitoring information
	--read	Perform read operation from specific page
	--length <length>	Length of data to read in bytes (Optional - Default 1 byte)
	--page <pageNum>	Specific page number to read/write
	--offset <offset>	Specific page offset to read/write
	--write <bytes>	Perform write operation with specific data (list of bytes)
	--prbs_select <side>	Module PRBS test mode side selector [MEDIA, HOST]
	--prbs_mode <cmd>	Perform PRBS test mode on the Module [EN(Enable),DS
	--generator_pattern <pattern>	Set PRBS generator pattern [PRBS31(default),PRBS23,F
	--swap_generator	Enable PAM4 MSB <-> LSB generator swapping (Optional)
	--invert_generator	Enable PRBS generator inversion (Optional)
	--generator_lanes <lanes>	PRBS generator lanes to set (one or more lane separate
	--checker_pattern <pattern>	Set PRBS checker pattern [PRBS31(default),PRBS23,PR
	--swap_checker	Enable PAM4 MSB <-> LSB checker swapping (Optional)
	--invert_checker	Enable PRBS checker inversion (Optional)
	--checker_lanes <lanes>	PRBS checker lanes to set (one or more lane separated
	--lane_rate <rate>	Set PRBS checker and generator lane rate [HDR(50G)(de
	--show_diagnostic_info	Show PRBS diagnostic counters information
	--clear_diagnostic_info	Clear PRBS diagnostic counters
	--control_parameters	Show Module Control Parameters

	--tx_equalization <value>	Set Module Tx Input Equalization in dB [NE(No Equalizat
	--rx_emphasis <value>	Set Module RX Output Emphasis in dB. for CMIS, pre-en
	--rx_post_emphasis <value>	Set Module Rx Post Emphasis in dB [NE(No Equalization
	--rx_amplitude <value>	Set Module Rx Output Amplitude [0(100-400mV),1(300-
--margin		Read the SerDes eye margins per lane
	--measure_time <time>	Measure time in seconds for single eye [10, 30, 60, 90, 1
	--eye_select <eye_sel>	Eye selection for PAM4 [UP, MID, DOWN, ALL] (Default A
	--lane <lane_index>	Run eye for specific lane index (Default all lanes)
--rx_error_injection		Enable the RX link deterioration
	--mixer_offset0 <value>	Fine change to the center of the eye [0x0 to 0x7ff]
	--mixer_offset1 <value>	Coarse change to the center of the eye [0x0 to 0x3ff]
	--show_mixers_offset	Show mixer offset 0 and mixer offset 1
--rx_fec_histogram		Provide histogram of FEC errors. The result is divided to
	--show_histogram	Show FEC errors histogram
	--clear_histogram	Clears FEC errors histograms
--pcie_error_injection		Start/show PCIe error injection
	--error_type <type>	PCIe error type [ABORT(0),BAD_DLLP_LCRC(1),BAD_TLP_LCRC(2),BAD_1
	--error_duration <duration>	Error duration, depend on the error type
	--injection_delay <delay>	Delay in micro-seconds before applying the error (Optio
	--error_parameters <params>	Comma-separated parameters for selected error type (r
	--dbdf <dbdf>	Destination bus device function, e.g af:00.0 (Optional us
--yes		Non-interactive mode, answer yes to all questions
--link_training <link_training_mode>		Link Training Optimization Configuration EN(enable)/DS(
--phy_recovery <phy_recovery_mode>		Configure PHY Recovery EN(enable)/DS(disable)
	--recovery_type <type>	Configure Recovery Type host_serdes_freq/host_logic_re

<code>--set_link_peq <interval></code>	Set link Periodic Equalization (PEQ) interval [10-40000] u Only multiples of 10 are supported.
--	---

Examples:

Get info of <device>, <port_number>:

```
mlxlink -d <device> -p <port_number>
```

Get info of <device>, <port_number> and BER Counters:

```
mlxlink -d <device> -p <port_number> -c
```

Get info of <device>, <port_number> and Transmitter Parameters:

```
mlxlink -d <device> -p <port_number> --show_serdes_tx
```

Configure Port State:

```
mlxlink -d <device> -p <port_number> --port_state UP
```

Configure Port Speeds:

```
mlxlink -d <device> -p <port_number> --speeds 25G,50G,100G
```

Configure FEC:

```
mlxlink -d <device> -p <port_number> --fec RS
```

Configure Port for Physical Test Mode:

```
mlxlink -d <device> -p <port_number> --test_mode EN (--rx_prbs  
PRBS31 --rx_rate 25G --tx_prbs PRBS7 --tx_rate 10G --  
invert_rx_polarity --invert_tx_polarity)
```

Perform PRBS Tuning:

```
mlxlink -d <device> -p <port_number> --test_mode TU
```

Note

RX and TX lane rates for new devices include the PAM4 speeds (50G_1X and 100G_2X).

eg:

```
mlxlink -d <device> --test_mode EN --rx_rate [normal  
speeds | 50G_1X | 100G_2X] --tx_rate [normal speeds |  
50G_1X | 100G_2X]
```

Note

The PRBS pattern configured in PAM4 rates is PRBSQ.

Cable operations:

```
mlxlink -d <device> --cable [Options]
```

Dump cable EEPROM pages:

```
mlxlink -d <device> --cable --dump
```

Get cable DDM information:

```
mlxlink -d <device> --cable --ddm
```

Read from cable:

```
mlxlink -d <device> --cable --read --page <page number> --offset  
<bytes offset> --length <number of bytes>
```

Write to cable:

```
mlxlink -d <device> --cable --write <bytes separated by comma> --  
page <page number> --offset <bytes offset>
```

Configure Transmitter Parameters (on lane, to database):

```
mlxlink -d <device> -p <port_number> --serdes_tx <polar-ity>,  
<ob_tap0>,<ob_tap1>,<ob_tap2>,<ob_bias>,<ob_preemp_mode>,  
<ob_reg>,<ob_leva> (--serdes_tx_lane <lane number>) (--database)
```

Configure Transmitter Parameters for 16nm devices:

```
mlxlink -d <device> -p <port_number> --serdes_tx <pre_2_tap>,  
<pre_tap>,<main_tap>,<post_tap>,<ob_m2lp>,<ob_amp>
```

Getting PCIe links info:

```
mlxlink -d /dev/mst/mt41682_pciconf0 --port_type PCIE --  
show_links  
Valid PCIe Links  
-----  
: depth, pcie_index, node, port  
Link 1 : 3, 0, 0, 60  
Link 2 : 3, 0, 1, 61  
Link 3 : 3, 0, 2, 62  
..
```

To query information for a specific link, the depth, pcie_index and node for the link must be specified:

```
mlxlink -d /dev/mst/mt41682_pciconf0 --port_type PCIE --depth 3 -  
-pcie_index 0 --node 1 --show_serdes_tx --show_eye PCIE  
Operational (Enabled) Info  
-----  
Depth, pcie index, node : 3, 0, 1  
Link Speed Active (Enabled) : 8G-Gen 3 (16G-Gen 4)  
Link Width Active (Enabled) : 2X (16X)  
  
EYE Opening Info (PCIe)  
-----  
Physical Grade : 84, 84  
Height Eye Opening [mV] : 1194, 1194
```

```
Phase Eye Opening [psec] : 84, 84
```

```
Serdes Tuning Transmitter Info (PCIe)
```

```
-----
```

```
Serdes TX parameters      : Pol ,tap0 ,tap1 ,tap2 ,bias  
,preemp_mode ,reg ,leva  
Lane 0                    : 0   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 1                    : 1   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 2                    : 0   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 3                    : 1   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 4                    : 0   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 5                    : 1   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 6                    : 0   ,21   ,92   ,7   ,15   ,1  
,10  ,9  
Lane 7                    : 1   ,21   ,92   ,7   ,15   ,1  
,10  ,9
```

To print the output in JSON format:

```
mlxlink -d <device> --show_module --json
```

To show ports group map (for NVIDIA Quantum and NVIDIA Spectrum-2):

```
mlxlink -d<device> --show_tx_group_map 0
```

To assign ports to a specific group on NVIDIA Quantum and NVIDIA Spectrum-2:

```
mlxlink -d <device> --tx_group_map 1 -ports 1,2,3,5,4,8,7,8,9,10,11
```

To show histogram of FEC errors:

```
mlxlink -d /dev/mst/mt4125_pciconf0 --rx_fec_histogram --  
show_histogram
```

To clear histogram:

```
mlxlink -d /dev/mst/mt4125_pciconf0 --rx_fec_histogram --  
clear_histogram
```

Margin Scan Tool

The margin scan tool is used for scanning PCIe or Network ports (in EDR\25G or HDR\PAM4 speeds).

Note

If the margin scan fails with an "eye scan not completed" message, perform a reboot and run the scan again.

To enable the margin scan with a measure time of 10 seconds:

```
mlxlink -d <device> --port_type PCIE -margin -measure_time 10
```

To enable the margin scan for Multi-host or Socket Direct systems through:

- depth, pcie_index and node:

```
mlxlink -d <device> --port_type PCIE -depth 0 -pcie_index 1 -  
node 0 -margin -measure_time 30
```

- The local port (can be shown by the `-show_links` command):

```
mlxlink -d <device> --port_type PCIE -port 1 -margin -  
measure_time 10
```

RX Error Injection

Allows modifying the Eye Center capability by changing the mixer_offset0 (fine change) and mixer_offset1 (coarse change) flags for 28nm products to produce RX errors.

Flags Usage

- To change the mixers values:

```
mlxlink -d /dev/mst/mt4117_pciconf0 --rx_error_injection --  
mixer_offset0 0x200 --mixer_offset1 0x305
```

Note

Modifying `mixer_offset0` and `mixer_offset1` flags can change the Eye Center and might cause link degradation.

- To query the mixers values:


```
mlxlink -d /dev/mst/mt4117_pciconf0 --rx_err r_injection --  
show_mixers_offset
```

Rx-to-Tx Loopback Mode Activation

This capability enables Rx-to-Tx remote loopback mode.

Prerequisite

- The port should be disabled and configured with Force mode [Disable the Auto-negotiation]
- Remote loopback is supported for 25G/50G per lane speed
- If the NIC has 2 ports, both ports should be configured with the same speed

To enable Rx-to-Tx remote loopback mode:

1. Disable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state DN
```

2. Configure the link mode to Force [Disable the Auto-negotiation].

```
mlxlink -d /dev/mst/mt4123_pciconf0 --speeds 100G --  
link_mode_force
```

3. Configure loopback with remote loopback [RM].

```
mlxlink -d /dev/mst/mt4123_pciconf0 -loopback RM
```

4. Enable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state UP
```

To return to the normal link operation:

1. Disable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state DN
```

2. Clear the loopback configuration using the "NO loopback" option.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -loopback NO
```

3. Enable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state UP
```

Module PRBS Test Mode

The module PRBS test mode can be performed by using the new flags under the `--cable` command.

Note

- This feature supports Active/Optical CMIS modules only.
- Either the media or host side can run with PRBS mode.

- To enable the PRBS test mode, the module should be plugged in and active.

Enabling\Disabling The Module PRBS Test Mode

To enable the module PRBS test mode, the side of the module should be selected using the `--prbs_select` flag. After providing the `--cable` flag, either the HOST or the MEDIA side should be selected, so the `--prbs_mode` <EN\DS> can be used to enable or disable the PRBS test mode process.

For example, the following command will enable the PRBS test mode on the HOST side of the module:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --  
prbs_select HOST --prbs_mode EN
```

The command above will put the HOST side of the module in PRBS test mode with default Checker and Generator parameters.

The Checker and Generator parameters can be overridden while enabling the PRBS test mode according to their related flags in the help menu:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --  
prbs_select HOST --prbs_mode EN --checker_pattern PRBS13 --  
invert_checker --generator_pattern PRBS31 --swap_generator --  
lane_rate HDR
```

To disable the PRBS test mode, the following command can be executed:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --  
prbs_select HOST --prbs_mode DS
```

Getting Module Information

Some of the module information can be presented using the `--show_module` flag.

For example, the following command will present the module information for the module connected to port 1 on the switch:

```
mlxlink -d /dev/mst/mt53120_pci_cr0 --port 1 --show_module
```

Module Info

Identifier	: OSFP
Compliance	: IB HDR,200GBASE-SR4
Cable Technology	: 850 nm VCSEL
Cable Type	: Optical Module (separated)
OUI	: Nvidia
Vendor Name	: NVIDIA
Vendor Part Number	: MMA4U00-HS
Vendor Serial Number	: MT2134FT06348
Rev	: A3
Wavelength [nm]	: 850
Transfer Distance [m]	: 10
Attenuation (5g,7g,12g,25g,53g)[dB]	: N/A
FW Version	: 40.55.0
Digital Diagnostic Monitoring	: Yes
Power Class	: 12.0 W max
CDR RX	: ON, ON, ON, ON, ON, ON, ON, ON
CDR TX	: ON, ON, ON, ON, ON, ON, ON, ON
LOS Alarm	: N/A
Temperature [C]	: 36 [-10..80]
Voltage [mV]	: 3280 [3100..3500]
Bias Current [mA]	:
7.460, 7.490, 7.292, 7.348, 7.430, 7.200, 7.392, 7.300	[5.492..8.5]
Rx Power Current [dBm]	: -40, -40, -40, -40, -40, -40, -40, -40
	[-13.372..5.4]

Tx Power Current [dBm]	:	
	:	0.473, 0.477, 0.282, 0.434, 0.766, 0.645, 0.500, 0.500 [-11.427..5.4]
Intra-ASIC Latency [ns]	:	N/A
Module Datapath Latency [ns]	:	N/A
Round Trip Latency [ns]	:	N/A
SNR Media Lanes [dB]	:	N/A
SNR Host Lanes [dB]	:	N/A
IB Cable Width	:	N/A
Memory Map Revision	:	64
Linear Direct Drive	:	0
Cable Breakout	:	Unspecified
SMF Length	:	N/A
MAX Power	:	48
Cable Rx AMP	:	1
Cable Rx Emphasis (Pre)	:	0
Cable Rx Post Emphasis	:	0
Cable Tx Equalization	:	0
Wavelength Tolerance	:	15.0nm
Module State	:	Ready state
DataPath state [per lane]	:	
DPActivated, DPActivated, DPActivated, DPActivated, DPActivated, DPActivated	:	
Rx Output Valid [per lane]	:	0, 0, 0, 0, 0, 0, 0, 0, 0
Nominal bit rate	:	N/A
Rx Power Type	:	Average power
Manufacturing Date	:	24_08_21
Active Set Host Compliance Code	:	IB HDR
Active Set Media Compliance Code	:	200GBASE-SR4
Error Code Response	:	ConfigUndefined
Module FW Fault	:	0
DataPath FW Fault	:	0
Tx Fault [per lane]	:	0, 0, 0, 0, 0, 0, 0, 0, 0
Tx LOS [per lane]	:	0, 0, 0, 0, 0, 0, 0, 0, 0
Tx CDR LOL [per lane]	:	0, 0, 0, 0, 0, 0, 0, 0, 0
Rx LOS [per lane]	:	0, 0, 0, 0, 0, 0, 0, 0, 0
Rx CDR LOL [per lane]	:	1, 1, 1, 1, 1, 1, 1, 1, 1
Tx Adaptive EQ Fault [per lane]	:	0, 0, 0, 0, 0, 0, 0, 0, 0

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --  
prbs_select HOST --clear_diagnostic_info
```

PRBS Diagnostic Counters Information

After performing the PRBS test mode, the module counters can be queried by using the following command:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --  
prbs_select HOST --show_diagnostic_info
```

The module PRBS test mode counters can be cleared by using the following command, which will clear the diagnostic counters on the HOST side only:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --  
prbs_select HOST --clear_diagnostic_info
```

Module Control Parameters

Some of the module parameters can be controlled by mlxlink after providing the `--control_paramenter` flag, which can be executed under the `--cable` flag.

The possible parameters can be controlled as follows:

- Reading and configuring Tx Equalization
- Reading and configuring Rx Emphasis (PreCursor & PostCursor)
- Reading and configuring Rx Amplitude

Note

- To apply the changes, the link should be disabled first.
- After configuring a new parameter, the link should be raised again to allow the firmware to load the new configuration.
- Cable control parameters are valid for active\optical modules only.

Querying and Configuring The Module Control Parameters

To query the currently configured module control parameters, the

`--control_parameters` flag can be used under the `--cable` flag as follows:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --cable --control_parameters
...
Module Control Parameters
-----
TX Equalization                : 1dB
RX Emphasis (pre)              : 2.5dB
RX Post Emphasis               : No Equalization
RX Amplitude                   : 600-1200 mV (P-P)
```

To configure the module control parameters, the following command can be executed:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --cable --control_parameters
--tx_equalization 2 --rx_amplitude 1
```

Tool Usage with NIC vs. Switch (-p Flag)

When using the mlxlink tool with an adapter card, notice that the "label_port" `-p` flag should not be used. To address different ports, please use different MST devices.

For example:

To address port 1 when using ConnectX-4:

```
mlxlink -d /dev/mst/mt4115_pciconf0
```

To address port 2, use:

```
mlxlink -d /dev/mst/mt4115_pciconf0.1
```

Note

- Any mlxlink command for a switch should include the "`-p`" flag to address the specific port in the switch.
- When working with an adapter card, if an MTUSB is used for communication with the NVIDIA NIC, to address port 2, use

```
mlxlink -d /dev/mst/mt4115_pciconf0 --  
gvmi_address  
<0xAddress>.
```

Tool Usage on NVIDIA Quantum HDR Switch Systems with Split Ports

If the split port number is not provided by the ibdiagnet tool, to use mlxlink on NVIDIA Quantum HDR based switch systems split ports, run:


```
mlxlink -d lid-<LID> -p <formula>
```

Formula:

In case of 2X port:

- 1- port_num = round_down[(lblinkinfo_port_num + 1)*0.5]
- 2- if (lblinkinfo_port_num + 1) modulo 2 = 1 then append '/2' to port_num

In case of 4X port, use only item #1 above.

Example:

```
43 23[ ] == ( 2X 53.125 Gbps Active/ LinkUp) ==> mlxlink -d lid-43 -p  
12  
43 24[ ] == ( 2X 53.125 Gbps Active/ LinkUp) ==> mlxlink -d lid-43 -p  
12/2
```

Tool Usage on NVIDIA Quantum-2 NDR Switch Systems

In NVIDIA Quantum-2 NDR switch systems, there are 32-OSFP cages (8x), where each one holds 2 (4x) ports instead of 1, and each port can be accessed by providing the cage number and the port in the cage - "Cage/Port".

```
mlxlink -d <mst device> -p <Cage>/<Port>
```

If the split profile is ready, it is possible to access the split ports by providing the number of split to the port flag, e.g.:

- To access the main port of 15/2:

```
mlxlink -d <mst device> -p 15/2
```

- To access the split port of 15/2:

```
mlxlink -d <mst device> -p 15/2/2
```

PCIe

Link Speed and Width

For PCIe link speed and width, use the following flag: `--port_type PCIE`.

```
PCIe Operational (Enabled) Info
-----
Depth, pcie index, node      : [Depth, pcie index, node]
Link Speed Active (Enabled)  : [Freq - Gen]
Link Width Active (Enabled)  : [Width]
```

PCIe Switch

When using NVIDIA ConnectX-5 and newer devices, the PCIe interface can be configured for a PCIe switch. When the PCIe switch is enabled, the depth, pcie_index and node parameters are needed in order to specify the PCIe port from which the requested information (such as counters or eye info) is gathered.

Parameters	Description
Depth	This parameter defines the number of layers from the Root Complex to the specific port. • For NVIDIA ConnectX adapter cards multi-host mode, the depth should be set to 0.

Parameters	Description
	For NVIDIA BlueField/BlueField-2 JBoF, the depth should be set to 3.
Pcie_index	This parameter defines the root complex ID or host index. - For NVIDIA ConnectX adapter cards multi-host mode, the pcie_index is the host index (0-3). - For NVIDIA BlueField/BlueField-2 JBoF, the pcie_index is always 0.
Node	This parameter defines the specific PCIe port. - For NVIDIA ConnectX adapter cards multi-host mode, the node is always 0 for each host_index. - For NVIDIA BlueField JBoF mode, this parameter range is 0x0-0xF, which amounts for up to 16 possible ports for BlueField JBoF. - For NVIDIA BlueField-2, this parameter's range is 0x0-0x7. Note: For NVIDIA BlueField/BlueField-2 SmartNIC mode, the PCIe link information can only be gathered from the external host. The PCIe interface status cannot be retrieved from the Arm side. When retrieving the PCIe link information from the external host, there is no need to specify the depth, pcie_index and node.

Example: NVIDIA BlueField JBoF Mode

```
# mlxlink -d /dev/mst/mt41682_pciconf0 --port_type pcie --depth 3
--pcie_index 0 --node 4 -c
```

PCIe Operational (Enabled) Info

```
Depth, pcie index, node           : 3, 0, 4
Link Speed Active (Enabled)       : 8G-Gen 3 (16G-Gen 4)
Link Width Active (Enabled)       : 2X (2X)
```

Management PCIe Timers Counters Info

```
dl down                           : 0
```

Management PCIe Performance Counters Info

```
-----  
RX Errors                      : 0  
TX Errors                      : 0  
CRC Error d1lp                : 0  
CRC Error tlp                 : 0
```

Link Counters

For PCIe counters information, use the `--port_type PCIe -c` flag.

Management PCIe Timers Counters Info

```
-----  
dl down                        : [link down counter]
```

Management PCIe Performance Counters Info

```
-----  
RX Errors                      : [Rx Errors]  
TX Errors                      : [Tx Errors]  
CRC Error d1lp                : [CRC Errors d1lp]  
CRC Error tlp                 : [CRC Errors tlp]
```

- RX Errors: indicate the number of transitions to recovery required due to framing errors and CRC (dlp and tlp) errors.
- TX Errors: indicate the number of transitions to recovery required due to EIEOS and TS errors.
- CRC Error d1lp: indicate CRC error in Data Link Layer Packets.
- CRC Error tlp: indicate CRC error in Transaction Layer Packet.

Example:

```
# mlxlink -d /dev/mst/mt4123_pciconf0 --port_type PCIE -c
```

PCIe Operational (Enabled) Info

```
Depth, pcie index, node      : 0, 0, 0
Link Speed Active (Enabled)   : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)   : 16X (16X)
```

Management PCIe Timers Counters Info

```
dl down                        : 3
```

Management PCIe Performance Counters Info

```
RX Errors                      : 0
TX Errors                      : 16
CRC Error dllp                 : 0
CRC Error tlp                  : 0
```

Link Eye Opening and Grade

For PCIe link physical grade and eye opening information, use the

`--port_type PCIE -e` flag.

EYE Opening Info (PCIE)

```
Physical Grade : [Grade0, Grade1, Grade2, Grade3, Grade4, Grade5,
Grade6, Grade7, Grade8, Grade9, Grade10, Grade11, Grade12,
Grade13, Grade14, Grade15]
Height Eye Opening [mV] : [Height0, Height1, Height2, Height3,
Height4, Height5, Height6, Height7, Height8, Height9, Height10,
Height11, Height12, Height13, Height14, Height15]
```

Phase Eye Opening [psec] : [Phase0, Phase1, Phase2, Phase3, Phase4, Phase5, Phase6, Phase7, Phase8, Phase9, Phase10, Phase11, Phase12, Phase13, Phase14, Phase15]

Example:

```
# mlxlink -d /dev/mst/mt4123_pciconf0 --port_type PCIE -e

PCIE Operational (Enabled) Info
-----
Depth, pcie index, node          : 0, 0, 0
Link Speed Active (Enabled)      : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)      : 16X (16X)

EYE Opening Info (PCIE)
-----
Physical Grade                   : 57279, 56340, 59340, 61824, 55140,
60501, 61530, 57392, 61573, 58930, 62752, 60421, 57188, 59796, 60066, 60847
Height Eye Opening [mV]         : 292, 288, 314, 325,
278, 310, 319, 299, 316, 318, 343, 323, 310, 311,
335, 318
Phase Eye Opening [psec]        : 30, 30, 30, 30,
30, 30, 30, 30, 30, 28, 28, 28, 28, 30,
28, 30
```

Pass/Fail Criteria

SLRED (ConnectX-6/ConnectX-6 Dx/ConnectX-6 Lx)

```
mlxlink -d [device] --port_type PCIE --margin
```

Gen3

Gen3	
Eye Grade	Figure of Merit (FOM)
$0 < \text{Eye Grade} < 700$	FAIL
$700 < \text{Eye Grade} < 2300$	Gray area
$2300 < \text{Eye Grade}$	PASS

Gen4

Gen4	
Eye Margin	FOM
$0 < \text{Eye Grade} < 150$	FAIL
$150 < \text{Eye Grade} < 400$	Gray area
$400 < \text{Eye Grade}$	PASS

PCIe Error Injection

This test feature allows errors injection over the PCI links. It is used to verify that the system can handle the PCIe errors, which rarely occur in regular usage.

The ConnectX-7 device includes testability features that can be configured to act as an error injection 'exerciser' in order to test other components in the system. This is supported when the ConnectX-7 is used as a PCIe switch.

Note

- This is a PCIe related feature that should be run over PCIe links only (`--port_type PCIe`) with specific depth, PCIe index and node (DPN).
- If the DPN is not provided, the tool will take the default values - 0,0 and 0, respectively.

- The mapping between the BDF and its DPN can be found by executing the `show_links` command (see example below).

Error Types

ID	Error Type	Description	Unit	Additional Parameters (-- <code>errors_parameters</code>)
0	ABORT	Cancels the current pending error, if exists.	NA	NA
1	BAD_DLLP_LCRC	Flips a bit in the LCRC of the next " <code>error_duration</code> " DLLPs that are transmitted through the port.	Packets	NA
2	BAD_TLP_LCRC	Flips a bit in the LCRC of the next " <code>error_duration</code> " TLPs that are transmitted through the port. The packets are VDM TLPs that are sent by the port to the destination BDF - " <code>dbdf</code> ".	Packets	NA
3	BAD_TLP_ECRC	Flips a bit in the ECRC of the next " <code>error_duration</code> " TLPs that are transmitted through the port. The packets are VDM TLPs that are sent by the port to the destination BDF - " <code>dbdf</code> ".	Packets	NA
4	ERR_MSG	Sends an error signaling message to the RC.	Packets	Parameter 0: message type 0 - Correctable

				1 - Nonfatal 2 - Fatal
5	MALFORMED_TLP	Sends an "error_duration" PM_ACTIVE_STATE_NACK message to the destination BDF - "dbdf" with TC=1 instead of 0.	Packets	NA
6	POISONED_TLP	Sends an "error_duration" VDMs with data to the destination BDF - "dbdf" with EP = 1.	Packets	NA
7	UNEXPECTED_CPL	Sends "error_duration" completions to the destination BDF - "dbdf" with 0xff tag.	Packets	NA
8	ACS_VIOLATION	Sends "error_duration" VDMs to the destination BDF - "dbdf" with source_bdf=0.	Packets	NA
100	SURPRISE_LINK_DOWN	Sets a port state to DETECT.	NA	NA
101	RECEIVER_ERROR	Sends a clock instead of data for "error_duration" usecs. A value of 0 in 'error_duration' means that this error must be toggled by the firmware as fast as possible.	uSec	NA

PCIe Error Injection Inputs

The following values should be provided in the error injection command line. Some values may be optional according to the error type.

Input	Command Line Flag	Description	Obligatory	Default
Error Type	<code>--error_type</code>	Error type according to the table above.	Yes	-
Error Duration	<code>--duration</code>	The minimal number of packets with this error that will be sent, or the minimal amount of time that this error state would be applied.	No	1
Injection Delay	<code>--injection_delay</code>	Delay in microseconds before the error is applied. This allows time for the completion to return to the tool caller correctly. A higher value can be used to allow the system to get to a lower power state.	No	0
Destination BDF	<code>--dbdf</code>	Destination BDF. Relevant for some of the errors that require packet generation. See error table above.	No	0:00.0
Additional Parameters	<code>--errors_parameters</code>	Additional parameters according to the error type. See error table above.	No	0

Mlxlink will trigger the firmware to start the error injection process by providing the `--pcie_error_injection` flag with the requested configuration parameters.

Note that the command returns immediately, but the error injection can take longer to complete (according to the error duration and injection delay inputs).

When the tool is run without the parameters above, it will query the error injection state – Whether it is ready to start a new error injection, or it is in the middle of the previous injection.

Usage Example

Start the process by performing error injection with error type UNEXPECTED_CPL.

This example shows how to start the error injection by sending 5 unexpected completion packets. The packets (of error type UNEXPECTED_CPL (id 7)) are directed from BDF 05:00.0 to BDF 06:00.0 after 500µs of sending the command in the following environment:

PCIe Component	BDF
Root port	00:01.0
(exerciser) PCIe Switch Upstream port	01:00.0
(exerciser) PCIe Switch Downstream port	05:00.0
Endpoint	06:00.0

To get the related depth, pcie_index and node for the specific BDF 05:00.0, the `show_links` command should be executed as follows:

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIE --show_links
```

Valid PCIe Links

Legend	:	depth	,pcie_index	,node	,port
,bdf					
Link 1	:	0	,0	,0	,0
,01:00.0					
Link 2	:	3	,0	,0	,60
,05:00.0					

In this case, the depth, pcie_index, and node flags for the downstream port should be 3, 0, and 0, respectively.

Then, the following command can be executed to start the process:

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIE --depth 3 --  
pcie_index 0 --node 0 --pcie_error_injection --error_type
```

```
UNEXPECTED_CPL --error_duration 5 --dbdf 06:00.0 --
injection_delay 500
```

```
PCIe Operational (Enabled) Info
```

```
-----
```

```
Depth, pcie index, node      : 3, 0, 0
Link Speed Active (Enabled)   : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)   : 16X (16X)
```

PCIe error injection might cause a PCIe bus failures or a system hang

Do you want to [continue](#)? yes

Starting PCIe Error Injection...

Query Error Injection Status

After sending the configuration command, the progress of the process can be checked by executing the tool with the `pcie_error_injection` flag only:

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIE --depth 3 --
pcie_index 0 --node 0 --pcie_error_injection
```

```
PCIe Operational (Enabled) Info
```

```
-----
```

```
Depth, pcie index, node      : 3, 0, 0
Link Speed Active (Enabled)   : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)   : 16X (16X)
```

```
PCIe Error Injection Info
```

```
-----
```

```
Error Injection Status      : In progress
Error Injection Type         : UNEXPECTED_CPL
```

Error Injection Duration : 5 Packets

Once the process is complete, the output will be changed to "ready". This means that another error injection request can be submitted:

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIE --depth 3 --  
pcie_index 0 --node 0 --pcie_error_injection
```

PCIe Operational (Enabled) Info

```
Depth, pcie index, node      : 3, 0, 0  
Link Speed Active (Enabled)  : 16G-Gen 4 (16G-Gen 4)  
Link Width Active (Enabled)  : 16X (16X)
```

PCIe Error Injection Info

```
Error Injection Status      : Ready  
Error Injection Type        : N/A  
Error Injection Duration    : N/A
```

mlxfwstress Utility

Note

The tool can support new devices only once the tool is upgraded to its latest version.

mlxfwstress enables/disables various firmware stress flows. It can work in multiple modes:

- Enable/disable a specific set of stress types
- Clear all stress types
- Random mode:
 - Single mode - choose one stress type in each iteration and enable/disable it
 - Wild-mode- choose multiple stress types in each iteration and enable/disable them

Each time a stress type is chosen in a random iteration, the opposite operation is done on it (e.g., if a stress type is turned on, in the next iteration it will be turned off and vice versa).

- Toggle mode:
 - Turns on and off the list of stress types alternating. Can be used with iterations.

Note

To disable a stressor while in toggling mode, first you must disable the mlxfwstress tool, and only after that disable the stressor.

- Clear semaphore:

Note: This functionality is supported in ConnectX-3 Pro adapter cards only.

mlxfwstress Synopsis

```
# mlxfwstress [-d|--dev <DeviceName>] [-h|--help] [-v|--version]
[-o|--operation <Operation>] [--rand-mode <Random mode>] [-t|--
stress-type <Stress type>] [--iterations <Iterations>] [--stress-
```

```
delay <Stress delay>] [--max-rand-on <Max rand on>] [--hang-type
<Hang type>] [--seed <seed>] [--toggle-time <x,y>]
```

where:

-d --dev <DeviceName>	Perform operation for a specified device
-h --help	Show this message and exit
-v --version	Show the executable version and exit
-o --operation <Operation>	Choose operation: on, off, clear_all, random query, clear_semaphore
--rand-mode <Random mode>	Choose a random mode: single, wild
-t --stress-type <Stress type>	Specify a list of stress types separated by comma. (<i>See Stress Types.</i>)
--iterations <Iterations>	Specify the number of iterations.
--stress-delay <Stress delay>	Specify the stress delay in seconds (can be float). Note: Some stress flows may take more time. Recommended values: 0-1
--max-rand-on <Max rand on>	Specify the maximal time a stress is allowed to be on in random mode in seconds. Recommended values (0,1] Default is 1
--hang-type <Hang type>	Specify a list of hang types separated by comma. (<i>See Hang Types.</i>)
--seed <seed>	Specify the seed for the random.
--toggle-time <x,y>	Toggle time after off, both in seconds (can be float). If y is not supplied the tool will use equal values for x and y

Stress Types

ConnectX-4/ConnectX-4 Lx/ConnectX-5 Adapter Cards Stress Types

The following are the stress types available for ConnectX-4/ConnectX-4 Lx/ConnectX-5 adapter cards:

Category	Stress Type	Description	Notes
Transparent	PAUSE_STORM_GENERATION	Generates pause frames from the device toward the network	
	INVALIDATE_INTERNAL_CACHE_RX_1	Invalidates STE cache	
	INVALIDATE_INTERNAL_CACHE_RX_2	Invalidates qp LO cache (RX)	
	INVALIDATE_INTERNAL_CACHE_RX_3	Invalidates dct LO cache (RX)	
	INVALIDATE_INTERNAL_CACHE_RX_4	Invalidates scatter list cache in RX	
	INVALIDATE_INTERNAL_CACHE_CQ	Invalidates CQC cache	
	INVALIDATE_INTERNAL_CACHE_SX1	Invalidates SXDC cache	
	INVALIDATE_INTERNAL_CACHE_RX_5	Invalidates LDB cache	
	INVALIDATE_INTERNAL_CACHE_GENERAL_1	Invalidates RO caches	
	INVALIDATE_INTERNAL_CACHE_SX2	Invalidates pkey cache (SX)	
	INVALIDATE_INTERNAL_CACHE_SX3	Invalidates guid cache (SX)	

Category	Stress Type	Description	Notes
	INVALIDATE_INTERNAL_CACHE_QP	Invalidates QPC (main QP cache unit)	
Hang FW/HW	PACKET_DROP	Drops N packets on portx	This type require following extra fl • num_of_pa - 8 bit (max • port_num - (should be 2)

ConnectX-3 Pro Adapter Cards Stress Types

The following are the stress types available for ConnectX-3 Pro adapter cards:

Note

Stressors in "Transparent" category that are active for more than 100 msec, may cause resiliency.

Category	Stress Type	Description
Transparent	STOP_CE_INSTAGE_EQE	Stops sending EQEs created by the hardware (not the ones created by the firmware).
	STOP_EDBH	Stops the handling of external doorbells.
	STOP_IDBH	Stops the handling of internal doorbells.
	STOP_QPC_MISS_MACHINE_0 STOP_QPC_MISS_MACHINE_1 STOP_QPC_MISS_MACHINE_2 STOP_QPC_MISS_MACHINE_3	Spots reading a QPC from the ICM on a miss-blocking hardware/firmware that accesses the QPC

Category	Stress Type	Description
	LOCK_CEGW	Locks the CQE gateway.
	LOCK_OBGW_TPT LOCK_OBGW_TCU LOCK_OBGW_SXD	Locks the OBGW (access to the host memory gateway).
	LOCK_QPCGW_RX	Locks QPCGW.
	LOCK_SEMAPHORE_IPC_RX0 LOCK_SEMAPHORE_IPC_RX1 LOCK_SEMAPHORE_IPC_LDB LOCK_SEMAPHORE_IPC_SX1	Locks the IPC semaphore.
	INVALIDATE_CACHES	Invalidates caches.
Performance	STOP_SXP_VL_ARB_PORT1 STOP_SXP_VL_ARB_PORT2	Stops transmission of packets to the wire. Causes head-of-line packet drop (HLL) if enabled.
	RX_BACKPRESSURE	Stops the RX pipe - back-pressure to wire- sending tx pauses.
	DROP_PACKETS_TX	Drops packets on the TX side.

Turning On Stress Types

To turn on a specific stress type:

```
mlxfwstress -d mt4103_pciconf0 -o on -t STOP_CE_INSTAGE_EQE
-----
Operation: [ON]
-----
Turning ON stress type: stop_ce_instage_eqe -PASSED
```

To turn on a set of stress types:

```
mlxfwstress -d mt4103_pciconf0 -o on -t
STOP_CE_INSTAGE_EQE, STOP_QPC_MISS_MACHINE_3, LOCK_SEMAPHORE_IPC_RX1
```

```
-----  
Operation: [ON]  
-----  
Turning ON stress type: stop_ce_instage_eqe -PASSED  
Turning ON stress type: stop_qpc_miss_machine_3 -PASSED  
Turning ON stress type: lock_semaphore_ipc_rx1 -PASSED
```

To turn on all the available stress types:

```
mlxfwstress -d mt4119_pciconf0 -t ALL -o on  
Random seed: [1587969653]  
-----  
Operation: [ON]  
-----  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_CQ  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_GENERAL_1  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_QP  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_1  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_2  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_3  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_4  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_5  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_SX1  
-PASSED  
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_SX2  
-PASSED
```

```
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_SX3
-PASSED
```

Turning Off Stress Types

To turn off a specific stress type:

```
mlxfwstress -d mt4103_pciconf0 -o off -t STOP_CE_INSTAGE_EQE
-----
Operation: [OFF]
-----
Turning OFF stress type: stop_ce_instage_eqe -PASSED
```

To turn off a set of stress types:

```
mlxfwstress -d mt4103_pciconf0 -o off -t
STOP_CE_INSTAGE_EQE,STOP_QPC_MISS_MACHINE_3,LOCK_SEMAPHORE_IPC_RX1
-----
Operation: [OFF]
-----
Turning OFF stress type: stop_ce_instage_eqe -PASSED
Turning OFF stress type: stop_qpc_miss_machine_3 -PASSED
Turning OFF stress type: lock_semaphore_ipc_rx1 -PASSED
```

Querying the Stress Types

To query the state of all stress types:

```
mlxfwstress -d mt4117_pciconf0 -o query -t ALL
```

Operation: [QUERY]

Querying stress type: INVALIDATE_INTERNAL_CACHE_CQ ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_GENERAL_1 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_QP ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_1 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_2 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_3 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_4 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_5 NOT SUPPORTED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_SX1 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_SX2 ENABLED	-
Querying stress type: INVALIDATE_INTERNAL_CACHE_SX3 ENABLED	-

Hang Types

ConnectX-4/ConnectX-4 Lx/ConnectX-5 Adapter Cards Hang Types

The following are the hang types available for ConnectX-4/ConnectX-4 Lx/ConnectX-5 adapter cards:

Category	Stress Type	Description	Notes
Hang FW/HW	FFSER	Initialize FaultInjector object	- This hang type is supported in BlueField-2 device only. - No extra flag is required.
	STOP_RX_PER_PRIOR ¹		This type requires the following extra flags: - vl_mask - 16 bit - port_num - 8 bit

```

mlxfwstress -d mt4115_pciconf0 -o on --hang-type
STOP_RX_PER_PRIOR --extra %STOP_RX_PER_PRIOR[0x00100FF]
Random seed: [1588056318]
-----
Operation:          [ON]
-----
Turning ON hang type: STOP_RX_PER_PRIOR
PASSED

```

To turn this Hang Type, the command must be executed in the following format:

Example:

```

mlxfwstress -d mt4115_pciconf0 -o on --hang-type STOP_RX_PER_PRIOR
--extra % STOP_RX_PER_PRIOR [0x000100FF]
output:
Random seed: [1573642282]
-----
Operation: [ON]
-----
Turning ON hang type: STOP_RX_PER_PRIOR-PASSED

```

Turning On Hang Types

To turn on a specific hang type:

```
mlxfwstress -d mt4103_pciconf0 -o on --hang-type HANG_SX1
-----
Operation: [ON]
-----
Turning ON hang type: Sx1 -PASSED
```

To turn on a set of hang types:

```
mlxfwstress -d mt4103_pciconf0 -o on --hang-type
HANG_SX1,HANG_RX1
-----
Operation: [ON]
-----
Turning ON hang type: Sx1 -PASSED
Turning ON hang type: Rx1 -PASSED
```

Turning Off Hang Types

To turn off a specific hang type:

```
mlxfwstress -d mt4103_pciconf0 -o off --hang-type HANG_SX1
-----
Operation: [OFF]
-----
```

```
Turning OFF hang type: Sx1 -PASSED
```

To turn off a set of hang types:

```
mlxfwstress -d mt4103_pciconf0 -o off --hang-type
HANG_SX1,HANG_RX1
-----
Operation: [OFF]
-----
Turning OFF hang type: Sx1 -PASSED
Turning OFF hang type: Rx1 -PASSED
```

Querying the Hang Types

To query the state of all hang types:

```
mlxfwstress -d mt4103_pciconf0 -o query --hang-type ALL
-----
Operation: [QUERY]
-----
Querying hang type: Sx1 -ENABLED
Querying hang type: Rx1 -ENABLED
Querying hang type: Tx -ENABLED
Querying hang type: Rx -ENABLED
```

Clearing all Stress/Hang Types

To clear all stress/hang types:


```

mlxfwstress - d mt4103_pciconf0 -o clear_all
-----
Operation: [CLEAR_ALL]
-----
Turning OFF hang type: Sx1 -PASSED
Turning OFF hang type: Rx1 -PASSED
Turning OFF hang type: Tx -PASSED
Turning OFF hang type: Rx -PASSED
Turning OFF stress type: stop_ce_instage_eqe -PASSED
Turning OFF stress type: stop_sxp_vl_arb_port1 -PASSED
Turning OFF stress type: stop_sxp_vl_arb_port2 -PASSED
Turning OFF stress type: stop_edbh -PASSED
Turning OFF stress type: stop_idbh -PASSED
Turning OFF stress type: stop_qpc_miss_machine_0 -PASSED
Turning OFF stress type: stop_qpc_miss_machine_1 -PASSED
Turning OFF stress type: stop_qpc_miss_machine_2 -PASSED
Turning OFF stress type: stop_qpc_miss_machine_3 -PASSED
Turning OFF stress type: lock_cegw -PASSED
Turning OFF stress type: lock_obgw_tpt -PASSED
Turning OFF stress type: lock_obgw_tcu -PASSED
Turning OFF stress type: lock_obgw_sxd -PASSED
Turning OFF stress type: lock_qpcgw_rx -PASSED
Turning OFF stress type: lock_semaphore_ipc_sx1 -PASSED
Turning OFF stress type: lock_semaphore_ipc_rx0 -PASSED
Turning OFF stress type: lock_semaphore_ipc_rx1 -PASSED
Turning OFF stress type: lock_semaphore_ipc_ldb -PASSED
Turning OFF stress type: invalidate_caches -PASSED

```

Clearing the Semaphore

To clear the semaphore:

```
mlxfwstress -d mt4103_pciconf0 -o clear_semaphore
```

```
-----  
Operation: [CLEAR_SEMAPHORE]  
-----
```

```
Semaphore was cleared successfully
```

Random Operation

There are two random modes you can choose from:

- Single - gives a set of stress types, in each iteration one stress type is chosen and toggled ON/OFF according to his current state
- Wild - gives a set of stress types, in each iteration a random subset of stress types is chosen and toggled ON/OFF according to their current state

Setting the Random Mode for the Stress Types

To set the Single Mode:

```
mlxfwstress -d mt4103_pciconf0 -o random --rand-mode single -t  
STOP_CE_INSTAGE_EQE --stress-delay 0.2 --iterations 10  
-----
```

```
Operation: [RANDOM]  
-----
```

```
#####
```

```
Random:
```

```
Iterations delay: 0.2 [sec]
```

```
Iterations number: 10
```

```
Max on time: 1 [sec]
```

```
#####
```

```
RANDOM ITERATION: [1]
```

```
[stop_ce_instage_eqe]: [ON] , duration since last operation: 0  
[ms]
```

```
RANDOM ITERATION: [2]
```

```
[stop_ce_instage_eqe]: [OFF], duration since last operation: 200  
[ms]
```

```

RANDOM ITERATION: [3]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 201
[ms]
RANDOM ITERATION: [4]
[stop_ce_instage_eqe]: [OFF], duration since last operation: 200
[ms]
RANDOM ITERATION: [5]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 200
[ms]
RANDOM ITERATION: [6]
[stop_ce_instage_eqe]: [OFF], duration since last operation: 201
[ms]
RANDOM ITERATION: [7]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 200
[ms]
RANDOM ITERATION: [8]
[stop_ce_instage_eqe]: [OFF], duration since last operation: 201
[ms]
RANDOM ITERATION: [9]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 200
[ms]
Turning OFF stress type: stop_ce_instage_eqe
RANDOM ITERATION: [10]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 200
[ms]
=====
Turning off all stress types after random:
Turning OFF stress type: stop_ce_instage_eqe

```

- As seen in the example above, after the specified number of iterations, the tool turns off all the stress types.
- The default value for stress-delay is 1 second.
- If no number of iterations was supplied then the user is expected to stop the tool with ctrl+c. The tool turns off all the stress types.

To set the Wild Mode:

```
mlxfwstress -d mt4103_pciconf0 -o random --rand-mode wild -t ALL
--stress-delay 0.2 --max-rand-on 1 --iterations 5
-----
Operation: [RANDOM]
-----
#####
Random:
Iterations delay: 0.2 [sec]
Iterations number: 5
Max on time: 1 [sec]
#####

RANDOM ITERATION: [1]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 0
[ms]
[stop_sxp_vl_arb_port2]: [ON] , duration since last operation: 0
[ms]
[stop_edbh]: [ON] , duration since last operation: 0 [ms]
[stop_idbh]: [ON] , duration since last operation: 0 [ms]
[stop_qpc_miss_machine_0]: [ON] , duration since last operation:
0 [ms]
[stop_qpc_miss_machine_3]: [ON] , duration since last operation:
0 [ms]
[lock_cegw]: [ON] , duration since last operation: 0 [ms]
[lock_obgw_tcu]: [ON] , duration since last operation: 0 [ms]
[lock_qpcgw_rx]: [ON] , duration since last operation: 0 [ms]
[lock_semaphore_ipc_sx1]: [ON] , duration since last operation: 0
[ms]

RANDOM ITERATION: [2]
[stop_sxp_vl_arb_port1]: [ON] , duration since last operation: 0
[ms]
[stop_edbh]: [OFF], duration since last operation: 203 [ms]
```

```
[stop_idbh]: [OFF], duration since last operation: 203 [ms]
[stop_qpc_miss_machine_3]: [OFF], duration since last operation:
202 [ms]
[lock_cegw]: [OFF], duration since last operation: 202 [ms]
[lock_obgw_tpt]: [ON] , duration since last operation: 0 [ms]
[lock_obgw_tcu]: [OFF], duration since last operation: 203 [ms]
[lock_semaphore_ipc_rx0]: [ON] , duration since last operation: 0
[ms]
[lock_semaphore_ipc_rx1]: [ON] , duration since last operation: 0
[ms]
[lock_semaphore_ipc_ldb]: [ON] , duration since last operation: 0
[ms]
```

RANDOM ITERATION: [3]

```
[stop_ce_instage_eqe]: [OFF], duration since last operation: 406
[ms]
[stop_sxp_vl_arb_port2]: [OFF], duration since last operation:
406 [ms]
[stop_edbh]: [ON] , duration since last operation: 203 [ms]
[stop_idbh]: [ON] , duration since last operation: 203 [ms]
[stop_qpc_miss_machine_0]: [OFF], duration since last operation:
406 [ms]
[stop_qpc_miss_machine_2]: [ON] , duration since last operation:
0 [ms]
[lock_obgw_tpt]: [OFF], duration since last operation: 203 [ms]
[lock_obgw_sxd]: [ON] , duration since last operation: 0 [ms]
[lock_semaphore_ipc_sx1]: [OFF], duration since last operation:
405 [ms]
[lock_semaphore_ipc_ldb]: [OFF], duration since last operation:
203 [ms]
```

RANDOM ITERATION: [4]

```
[stop_sxp_vl_arb_port2]: [ON] , duration since last operation:
203 [ms]
[stop_edbh]: [OFF], duration since last operation: 202 [ms]
[stop_idbh]: [OFF], duration since last operation: 202 [ms]
```

```
[stop_qpc_miss_machine_1]: [ON] , duration since last operation:
0 [ms]
[stop_qpc_miss_machine_3]: [ON] , duration since last operation:
406 [ms]
[lock_obgw_tpt]: [ON] , duration since last operation: 202 [ms]
[lock_obgw_tcu]: [ON] , duration since last operation: 406 [ms]
[lock_obgw_sxd]: [OFF], duration since last operation: 203 [ms]
[lock_semaphore_ipc_sx1]: [ON] , duration since last operation:
203 [ms]
[lock_semaphore_ipc_rx1]: [OFF], duration since last operation:
406 [ms]
[invalidate_caches]: [ON] , duration since last operation: 0 [ms]
```

```
Turning OFF stress type: stop_sxp_vl_arb_port1
Turning OFF stress type: stop_sxp_vl_arb_port2
Turning OFF stress type: stop_qpc_miss_machine_1
Turning OFF stress type: stop_qpc_miss_machine_2
Turning OFF stress type: stop_qpc_miss_machine_3
Turning OFF stress type: lock_obgw_tpt
Turning OFF stress type: lock_obgw_tcu
Turning OFF stress type: lock_qpcgw_rx
Turning OFF stress type: lock_semaphore_ipc_sx1
Turning OFF stress type: lock_semaphore_ipc_rx0
Turning OFF stress type: invalidate_caches
```

```
RANDOM ITERATION: [5]
```

```
[stop_sxp_vl_arb_port2]: [ON] , duration since last operation:
202 [ms]
[stop_idbh]: [ON] , duration since last operation: 322 [ms]
[lock_obgw_tpt]: [ON] , duration since last operation: 202 [ms]
[lock_obgw_tcu]: [ON] , duration since last operation: 202 [ms]
[lock_qpcgw_rx]: [ON] , duration since last operation: 202 [ms]
[invalidate_caches]: [ON] , duration since last operation: 202
[ms]
```

```
=====
```

```
Turning off all stress types after random:
```

```
Turning OFF stress type: stop_sxp_vl_arb_port2
Turning OFF stress type: stop_idbh
Turning OFF stress type: lock_obgw_tpt
Turning OFF stress type: lock_obgw_tcu
Turning OFF stress type: lock_qpcgw_rx
Turning OFF stress type: invalidate_caches
```

ConnectX-3/ConnectX-3 Pro Adapter Cards Hang Types

The following are the hang types available for ConnectX-3/ConnectX-3 Pro adapter cards:

Category	Stress Type	Description	Notes
Hang FW/HW	HANG_SX1		
	HANG_RX1		
	HANG_TX		
	HANG_RX		
	ALL		Hang types that require extra flags are not supported when running with the 'ALL' option.

resourcedump Utility

The resourcedump tool extracts and prints data segments generated by the firmware. It is supported in 5th generation NIC's devices. The dump output is used by NVIDIA for debug and troubleshooting.

Note

Scapy and Pyverbs are no longer resourcedump dependencies. The same functionality has been changed with a C code that is based on

the RDMA core included in OFED (v5.7 and up) or Upstream (Kernel v5.14 and up).

Note

mstresourcedump can be used only if Python 3.x is installed. Using lower versions will result in tool's failure.

Note

To use the memory mode, the user must install the MLNX_OFED driver version that includes the rdma-core package, and in addition, must install the scapy package.

Note

It is important for the user to generate a bin file for debugging and troubleshooting cases when needed by NVIDIA.

Note

If the firmware version used is not supported, the tool will generate the following error message:

```
"Error: Failed to fetch query data with exception:  
Failed to send Register RESOURCE DUMP with rc: 515.  
Exiting..."
```


resourcedump Usage

```
resourcedump [-h] [-v] {dump,query}
```

where

dump	Dump command
query	Query command
-h, --help	Show help message and exit
-v, --version	Shows tool version and exit

resourcedump query Usage

```
resourcedump query [-h] [-v VIRTUAL_HCA_ID] [-m [MEM]] -d DEVICE
```

where

-h, --help	Show help message and exit
-v, --virtual-hca-id	The virtual HCA (host channel adapter, NIC) ID
-d, --device	The device name
-m, --mem	Perform the dump through memory (OFED with rdma-core dependency). Optionally accepts: [rdma device (for example "mlx5_4")]

An example of how to run the query command:

```
# resourcedump query --device /dev/mst/mt4119_pciconf0
```

Segment Type - 0x1300 (FULL_EQC)

Dump Params Values	Applicability	Special
-----	-----	-----
-		
index1 (EQN)	Mandatory	N/A
num-of-obj1	N/A	N/A
index2 (N/A)	N/A	N/A
num-of-obj2	N/A	N/A

Segment Type - 0x1000 (FULL_QPC)		
Dump Params Values	Applicability	Special
-----	-----	-----
-		
index1 (QPN)	Mandatory	N/A
num-of-obj1	N/A	N/A
index2 (N/A)	N/A	N/A
num-of-obj2	N/A	N/A
...		
...		
...		

resourcedump dump Usage

```
usage: resourcedump dump [-h] -d DEVICE -s SEGMENT [-v
VIRTUAL_HCA_ID] [-i1 INDEX1]
[-i2 INDEX2] [-n1 NUM_OF_OBJ1] [-n2 NUM_OF_OBJ2] [-de DEPTH] [-b
BIN] [-m [MEM]]
```

where

-h, --help	Show help message and exit
-v, --virtual-hca-id	The virtual HCA (host channel adapter, NIC) ID
-i1, --index1	The first context index to dump (if supported for this segment)
-i2, --index2	The second context index to dump (if supported for this segment)
-n1, --num-of-obj1	The number of objects to be dumped (if supported for this segment). accepts: ["all", "active", number, depends on the capabilities]
-n2, --num-of-obj2	The number of objects to be dumped (if supported for this segment). accepts: ["all", "active", number, depends on the capabilities]
-de, --depth	The depth of walking through reference segments. 0 stands for flat, 1 allows crawling of a single layer down the struct, etc. "inf" for all
-b, --bin	The output to a binary file that replaces the default print in hexadecimal, a readable format
-d, --device	The device name
-s, --segment	The segment to dump
-m, --mem	Perform the dump through memory (OFED with rdma-core dependency). Optionally accepts: [rdma device (for example "mlx5_4")]

Examples of how to:

- Run the dump command:

```
# resourcedump dump --device /dev/mst/mt4119_pciconf0 --
segment 0x1200 --index1 0x404 --depth 0
Found 10 segments:
-----
Segment Type: 0xffff
Segment Size: 16 Bytes
Segment Data:
0x0004FFFE 0x00000000 0x00000000 0x101A0111
-----
Segment Type: 0xfffa
Segment Size: 20 Bytes
Segment Data:
```

```
0x0005FFFA 0x12000000 0x00000404 0x00000000
0x00000000
-----
```

- Run the Dump command and save it in bin file:

```
# resourcedump dump --device /dev/mst/mt4119_pciconf0 --
segment 0x1200 --index1 0x404 --depth 0 --bin segment_1200.bin
write to file: segment_1200.bin
```

resourceparse Utility

The resourceparse tool parses and prints data segments content. The parser's output is used by NVIDIA representatives for debugging and troubleshooting.

This tool parses the output of the "resourcedump" tool. There are several parsing methods (see --parser):

- ABD:

This parsing method receives an ADB file and parses each segment data according to the ADB layout of the node with the segment_id attribute corresponding to the segment.

- Map:

This parsing method assumes that the provided resource-segments represent a memory map by DWORD pairs of address-value, and outputs each pair in a new line (similar to mstdump).

Note

The tool applicable inputs for parsing can be the resourcedump outputs (bin file or the "human readable" format), or the devlink json

format output.

Note

To parse the segments data in the most efficient way, the user must use the most suitable adb file. For the adb file, please contact [Support](#).

resourceparse Usage

```
resourceparse -d DUMP_FILE [-p RESOURCE_PARSER] [--version] [-o OUT] [-v] -a ADB_FILE [-r]
```

where

-d, --dump-file	Location of the dump file used for parsing
-p, --parser	RESOURCE_PARSER: Available options: ['adb', 'map']. Default: 'adb'. see Parsing Methods.
-a, --adb-file	Location of the ADB file
-h, --help	Shows this help message and exit
--version	Shows the tool's version and exit
-o, --out	Location of the output file
--out-dir	Location of the output directory, a separate file is created for each segment
-r, --raw	Prints the raw data in addition to the parsed data
--hide-segment-header	Hide segment header during printing
-v	Verbosity notice

Examples:

- How to run basic parsing:

```
# resourceparse --dump-file notice.txt --adb-file fw-4119-  
rel-16_23_2008.adb
```

```
Parse 4 segments:
```

```
-----  
-----
```

```
Segment - segment_info (0xfffe)
```

```
segment_header.segment_type = 0xfffe
```

```
segment_header.length_dw = 0x4
```

```
dump_version = 0x0
```

```
hw_version = 0x0
```

```
fw_version = 0x1063232c
```

```
-----  
-----
```

```
Segment - segment_command (0xffffa)
```

```
segment_header.segment_type = 0xffffa
```

```
segment_header.length_dw = 0x5
```

```
vhca_id = 0x0
```

```
segment_called = 0x2000
```

```
index1 = 0x21
```

```
index2 = 0x0
```

```
num_of_obj1 = 0x0
```

```
num_of_obj2 = 0x0
```

```
-----  
-----
```

```
Segment - segment_notice (0xfff9)
```

```
segment_header.segment_type = 0xfff9
```

```
segment_header.length_dw = 0xc
```

```
syndrome_id = 0x211
```

```
notice[0] = 0x2000
```

```
notice[1] = 0x21
```

```
notice[2] = 0x0
```

```
notice[3] = 0x0
```

```
notice[4] = 0x496e7661
```

```
notice[5] = 0x6c696420
```

```
notice[6] = 0x52657300
```

```
notice[7] = 0x0
```

```
notice msg = !Invalid Res
```

```

-----
-----

Segment - segment_terminate (0xffffb)

segment_header.segment_type = 0xffffb

segment_header.length_dw = 0x1

-----
-----

```

- How to run parsing with 'raw' and 'verbosity' options:

```

# resourceparse --dump-file notice.txt --adb-file fw-4119-
rel-16_23_2008.adb -raw -v

Notice - adb fw version 16.23.2008 is used for parsing while dump
fw version is 16.99.9004

Parse 4 segments:

-----
-----

Segment - segment_info (0xffffe)

segment_header.segment_type = 0xffffe

segment_header.length_dw = 0x4

dump_version = 0x0

```



```
hw_version = 0x0
```

```
fw_version = 0x1063232c
```

```
RAW DATA:
```

```
DWORD [0-3]      :0x0004FFFE 0x00000000 0x00000000 0x1063232C
```

```
-----  
-----
```

```
Segment - segment_command (0xfffa)
```

```
segment_header.segment_type = 0xfffa
```

```
segment_header.length_dw = 0x5
```

```
vhca_id = 0x0
```

```
segment_called = 0x2000
```

```
index1 = 0x21
```

```
index2 = 0x0
```

```
num_of_obj1 = 0x0
```

```
num_of_obj2 = 0x0
```

```
RAW DATA:
```

```
DWORD [0-3]      :0x0005FFFA 0x20000000 0x00000021 0x00000000
```

```
DWORD [4]        :0x00000000
```


Segment - segment_notice (0xfff9)

segment_header.segment_type = 0xfff9

segment_header.length_dw = 0xc

syndrome_id = 0x211

notice[0] = 0x2000

notice[1] = 0x21

notice[2] = 0x0

notice[3] = 0x0

notice[4] = 0x496e7661

notice[5] = 0x6c696420

notice[6] = 0x52657300

notice[7] = 0x0

RAW DATA:

DWORD [0-3] : 0x000CFFF9 0x00000211 0x00000000 0x00000000

DWORD [4-7] : 0x00002000 0x00000021 0x00000000 0x00000000

DWORD [8-11] : 0x496E7661 0x6C696420 0x52657300 0x00000000

notice msg = !Invalid Res

```

-----
-----

Segment - segment_terminate (0xffffb)

segment_header.segment_type = 0xffffb

segment_header.length_dw = 0x1

RAW DATA:

DWORD [0] :0x0001FFFB
-----
-----

```

- How to run parsing and save it into a file:

```

# resourceparse --dump-file notice.txt --adb-file fw-4119-
rel-16_23_2008.adb -out out_flie.txt

write to file: out_flie.txt

```

stedump Utility

The stedump tool is a packet simulator for host NIC steering solutions. It is supported in 5th generation NIC devices and only when using Python v3.4 and above. The dump output of HW steering is used for debugging and troubleshooting.

Prerequisites

Using the MFT with the `--with-pcap` option to install `stedump` utility requires the following third-party dependencies:

- Libraries and header files for the `libpcap` library
- Libraries and header files for Python development library
- Package Installer for Python (PIP) available

stedump Usage


```
stedump [-h] --read-file <read_file> [--packet-format  
<packet_format>] [--output-file <output_file>] [--verbosity  
<verbosity>] [-v] {live,offline}
```

Where

<code>-h, --help</code>	Show help message and exit
<code>--version</code>	Show version information and exit
<code>--packet-format</code>	Specifies the I/O packet file format (default: hex)
<code>--output-file</code>	Redirect the output to specific file (default: stdout)
<code>--verbosity</code>	Increase output verbosity (default: 0)
<code>--read-file</code>	Specifies the packet(s) filename to read from
<code>live</code>	Run in live mode.
<code>offline</code>	Run in offline mode.

There are three kind of packet formats:

1. `hex` - Represents one or more packets separated by a newline in hexadecimal format.
2. `pcap` - Represents one or more packets in packet capture format.
3. `raw` - Represents a single packet in binary data format.



The pcap packet format is not supported by default, and requires installing MFT with the --with-pcap option.

Note

Offline mode is not supported.

stedump live Usage

```
stedump live [-h] --device <device> --port <physical_port>
{egress,ingress}
```

Where

-h, --help	Show help message and exit
-d , --device	Perform operation for a specified MST device
--port	Specifies the physical port number
egress	Specifies the packet source to be egress for TX flows
ingress	Specifies the packet source to be ingress for RX flows

stedump live egress Usage

```
stedump live egress [-h] [--reg-a <reg_a_value>] [--virtual-hca-
id <virtual_hca_id>] [--sqn <sqn>] [--force-loopback] [--special-
root]
```

Where

-h, --help	Show help message and exit
--reg-a	Specifies steering register A value (default: 0)
--virtual-hca-id	Specifies the source virtual HCA ID (default: 0)
--sqn	Specifies the send queue context number (default: 0)
--force-loopback	specifies whether to use QP force loopback
--special-root	specifies whether to use QP special root

An example of how to run the egress (TX) packet flow:

```
# stedump --read-file tcp.hex live --device
/dev/mst/mt4119_pciconf0 --port 0 egress

PACKET_DATA

C0 C1 C2 C3 C4 C5 A0 A1 A2 A3 A4 A5 08 00 45 00

00 28 00 00 40 00 40 06 34 CB 01 01 01 01 02 02

02 02 10 E1 22 3D 00 00 BA BA 00 00 DE DA 51 23

FF FF AD 29 00 00

STE_MASKED[1] OUTER: source_qp: 0x40

[HIT] - hit_ix=0x6e polarity

STE_MASKED[2] OUTER: encapsulation_type: ROCE
```

[HIT] - hit_ix=0x6d polarity

STE_MASKED[3] : Always Hit

[HIT] - hit_ix=0x2000001a

STE_MASKED[4] : Always Hit

[HIT] - hit_ix=0xf0000000

STE_MASKED[5] : Always Hit

[HIT] - hit_ix=0xf0000009

STE_MASKED[6] OUTER: dmac: c0:c1:c2:c3:c4:c5, l3_type: IPV4

[HIT] - hit_ix=0xf000000e

STE_MASKED[7] OUTER: sip: 1.1.1.1

[ACTION] - COUNT { flow_counter_id=0x801199, gvmi=0x0 }

[ACTION] - MODIFY_HEADER { number_of_re_write_actions:11, ix=0x57
}

[HIT] - hit_ix=0x1a44c

```
STE_MASKED[8] : Always Hit
```

```
[ACTION] - COUNT { flow_counter_id=0x2a, gvmi=0x0 }
```

```
[ACTION] - WIRE { }
```

```
[HIT] - hit_ix=0x0
```

```
[ACTION] - SX TERMINATOR { WIRE }
```

```
- STEERING_HOPS - 8
```

An example of how to run the ingress (RX) packet flow:

```
# stedump --read-file tcp.hex live --device  
/dev/mst/mt4119_pciconf0 --port 0 ingress
```

```
PACKET_DATA
```

```
E0 E1 E2 E3 E4 E5 A0 A1 A2 A3 A4 A5 08 00 45 00
```

```
00 5E 00 00 40 00 40 11 34 8A 01 01 01 01 02 02
```

```
02 02 04 D2 17 C1 00 4A DC C1 01 80 65 58 CC CE
```

```
23 00 61 61 61 61 B0 B1 B2 B3 B4 B5 A0 A1 A2 A3
```

```
A4 A5 08 00 45 00 00 28 00 00 40 00 40 06 34 CB
```

```
01 01 01 01 02 02 02 02 10 E1 22 3D 00 00 BA BA
```


00 00 DE DA 51 23 FF FF AD 29 00 00

STE_MASKED[1] OUTER: encapsulation_type: ROCE

[ACTION] - COUNT { flow_counter_id=0x29, gvmi=0x0 }

[HIT] - hit_ix=0x2000001a polarity

STE_MASKED[2] : Always Hit

[HIT] - hit_ix=0xf0000000

STE_MASKED[3] : Always Hit

[HIT] - hit_ix=0xf0000009

STE_MASKED[4] OUTER: dmac: e0:e1:e2:e3:e4:e5, l3_type: IPV4

[HIT] - hit_ix=0xf000000f

STE_MASKED[5] OUTER: sip: 1.1.1.1

[ACTION] - COUNT { flow_counter_id=0x801199, gvmi=0x0 }

[ACTION] - DECAP { L2 }

```
[ACTION] - MODIFY_HEADER { number_of_re_write_actions:1, ix=0xd7 }

[HIT] - hit_ix=0xa00001a5


STE_MASKED[6] : Always Hit

[HIT] - hit_ix=0xa00001a2


STE_MASKED[7] : Always Hit

[ACTION] - QP { gvmi=0x0, qp=0x108d }

[HIT] - hit_ix=0x0


[ACTION] - RX TERMINATOR {  }

- STEERING_HOPS - 7
```

Cable Utilities

MFT can work against the cables that are connected to the devices on the machine, or in the InfiniBand fabric in the following scenarios:

- Accessing the cable using the local PCI device. Supported in:
 - ConnectX-4 and newer devices
 - All the platforms
- Accessing the cable using the IB fabric. Supported in:

- All the devices
- Linux and Windows since IB driver is required
- Supported cables are all QSFP and SFP

Cable Discovery

How to Discover the Cables

To discover the cables that are connected to the local devices:

```
mst cable add
```

This command will scan all the local PCI devices and try to discover cable connected to each port.

To expand the discovery to include also the IB fabric, use the "--with_ib" flag. This flag by default will scan all the ib devices from the ibstat/ibv_devices output. To run only a specific interface and port, the interface or the port should be specified after the flag.

Examples:

To scan all the fabric:

```
mst cable add --with_ib
```

To scan a specific interface:

```
mst cable add --with_ib mlx4_0
```

or:

```
mst cable add --with_ib mlx4_0 1
```

Representing the Cables in mst Status

Local Cables

The name of the cable will be the same name as the mst-device/PCI-device with `_cable_<port>`.

Examples:

```
mst cable add
-I- Added 2 cable devices.
```

```
mst status
MST modules:
...
Cables:
-----
mt4115_pciconf0_cable_0
mt4115_pciconf0.1_cable_1
```

Remote Cables

When using the '`--with_ib`' flag, the name of the cable devices are created the same as the Inband devices with `_cable`.

```
> mst cable add --with_ib
-I- Added 4 cable devices ..
> mst status
```

Cables:

CA_MT4113_HCA-4_lid-0x0002,mlx5_0,1_cable

CA_MT4115_HCA-2_lid-0x0001,mlx5_0,1_cable

mt4115_pciconf0_cable_0

mt4115_pciconf0_cable_1

Working with Cables

The following are the tools that can work with cables: mstdump, mlxdump and mlx cables.

The below are examples using the tools mentioned above.

mstdump

```
mstdump mt4115_pciconf0_cable_0
```

```
0x00000000 0x0002060d
```

```
0x00000004 0x00000000
```

```
0x00000008 0x00000000
```

```
0x0000000c 0x00000000
```

```
0x00000010 0x00000000
```

```
0x00000014 0x4a340000
```

```
0x00000018 0x8b7f0000
```

```
0x0000001c 0x00000000
```

```
0x00000020 0xc0210000
```

```
0x00000024 0x901aa61d
```

```
0x00000028 0x6dc9521c
```

```
0x0000002c 0xe2d12fca
```

```
...
```

```
...
```

```
...
```

mlxdump

```
# mlxdump -d mt4115_pciconf0_cable_0 snapshot
-I- Dumping crspace...
-I- crspace was dumped successfully
-I- Dump file "mlxdump.udmp" was generated successfully
```

For the mlxables example, refer to section [mlxables](#).

mlxables - Cables Tool

Note

- mlxables is used for R/W to cable EEPROM
- The information of the devices will be collected by PRM command from switch Asic by mlxlink tool only
- mlxables will continue to support R/W operations to EEPROM, and will not be deprecated currently due to Independent module. Meaning, new features will not be supported in mlxables

The mlxables tool allows users to access the cables and do the following:

- Query the cable and get its IDs
- Read specific addresses in the EEPROM
 - Read a specific register by its name. Supported registers are received by the tool (depends on the cable type)
 - Dump all the cable EEPROM bytes in RAW format
 - Upgrade the FW image on the cable uC (Only on cables that support ISSU)

mlxables Synopsis

```
[-d|--dev <DeviceName>] [-h|--help] [-v|--version] [-q|--query]
[--DDM] [-r|--read] [--print_raw] [--dump] [-b|--bytes_line
<bytesPerLine>] [-p|--page <pageNum>] [-o|--offset <pageOffset>]
[-l|--length <length>] [-a|--address <address>] [-y|--yes] [--no]
[--read_reg <Register>] [--read_all_regs] [--show_all_regs] [--
customization <Customization_type>]
```

where:

-d --dev <DeviceName>	Perform operation for specified cable
-h --help	Show this message and exit
-v --version	Show the executable version and exit
-q --query	Query cable info
--DDM	Get cable DDM query
-r --read	Read from cable
--print_raw	Print bytes in raw format
--dump	Dump all cable pages in RAW format
-b --bytes_line <bytesPerLine>	Bytes per line in the raw print (multiples of 4, default: 4)
-p --page <pageNum>	Specific Page number to do the read/write operation
-o --offset <pageOffset>	Specific Page offset
-l --length <length>	Length of the needed data in bytes to read (default: 1 Byte)
-a --address <address>	Address (Replacement for page+offset)
--read_reg <Register>	Read register from cable
--read_all_regs	Read all registers from cable
--show_all_regs	Show all registers in the cable

<code>--customization</code> <code><customization_type></code>	Show cable specific customization
---	-----------------------------------

Notes:

- For QSFP transceivers, the tool reads the address from I2C address of 0x50. For further information, please see spec SFF8636.
- For SFP transceivers, the tool reads from I2C address 0x50 and names it page 0. When reading from I2C address 0x51 the pages will be read as page `<x+1>`, for example:
 - I2C address 0x51 page 0 will be referred in the tool as page 1.
 - I2C address 0x51 page 1 will be referred in the tool as page 2. For further information, please see spec SFF8472.

Examples:

To read specific byte/s in the cable pages:

```
mlxcables -d mt4115_pciconf0_cable_0 -r -p 0 -o 165 -l 3
Page[0].Byte[165] = 0x00
Page[0].Byte[166] = 0x02
Page[0].Byte[167] = 0xc9
```

Another way to read from a specific page is to use the '`--address <ADDR>`' flag where `ADDR=0x<PAGE><OFFSET>`, for example to read the same bytes with `-a`:

```
mlxcables -d mt4115_pciconf0_cable_0 -r -a 0x00A5 -l 3
Page[0].Byte[165] = 0x00
Page[0].Byte[166] = 0x02
Page[0].Byte[167] = 0xc9
```

To read in raw format:


```
# mlx cables -d mt4115_pciconf0_cable_0 -r -p 0 -o 128 -l 12 --
print_raw
```

```
128: 0d 8c 23 81
```

```
132: 00 00 00 00
```

```
136: 00 00 00 05
```

To control Bytes per line, use -b:

```
# mlx cables -d mt4115_pciconf0_cable_0 -r -p 0 -o 128 -l 12 --
print_raw -b 8
```

```
128: 0d 8c 23 81 00 00 00 00
```

```
136: 00 00 00 05
```

To query the cable:

```
mlx cables -d mt4115_pciconf0_cable_0 -q
```

```
Cable name      : mt4115_pciconf0_cable_0
```

```
FW version      : 2.2.550
```

```
FW Dev ID       : 0x21
```

```
FW GW version   : Legacy
```

```
----- Cable EEPROM -----
```

```
Identifier      : QSFP+ (0dh)
```

```
Technology      : 1550 nm DFB (50h)
```

```
Compliance      : 40G Active Cable (XLPPI), 100G AOC or 25GAUI C2M
AOC. Providing a worst BER of 10^(-12) or below
```

```
Wavelength      : 1550 nm
```

```
OUI             : 0x0002c9
```

```
Vendor          : Mellanox
```

```
Serial number    : MT1602FT00022
```

```
Part number      : MFS1200-E003
```

```
Revision      : AB
Temperature   : 54 C
Length        : 3 m
```

Get the DDM query of the cable:

```
# mlx cables -d mt4115_pciconf0_cable_0 --DDM
Cable DDM:
-----
Temperature : 37C
Voltage      : 3.3010V
RX Power     : -0.6712dBm
TX Power     : 0.8877dBm
TX Bias      : 6.7500mA
----- Flags -----
Temperature:
  Alarm high   : 0
  Warning high : 0
  Warning low  : 0
  Alarm low    : 0
Voltage:
  Alarm high   : 0
  Warning high : 0
  Warning low  : 0
  Alarm low    : 0
RX/TX Power and TX Bias:
  RX Power alarm high : 0
  RX Power warning high: 0
  RX Power warning low : 0
  RX Power alarm low   : 0
  TX Power alarm high  : 0
  TX Power warning high: 0
  TX Power warning low : 0
  TX Power alarm low   : 0
```

```

TX Bias alarm high      : 0
TX Bias warning high   : 0
TX Bias warning low    : 0
TX Bias alarm low      : 0
----- Thresholds -----
Temperature high alarm threshold : 80C
Temperature high warning threshold : 70C
Temperature low warning threshold : 0C
Temperature low alarm threshold   : -10C

Voltage high alarm threshold : 3.5000V
Voltage high warning threshold: 3.4650V
Voltage low warning threshold : 3.1350V
Voltage low alarm threshold   : 3.1000V

RX Power high alarm threshold : 5.3999dBm
RX Power high warn threshold  : 2.4000dBm
RX Power low warn threshold   : -10.3012dBm
RX Power low alarm threshold  : -13.3068dBm

TX Power high alarm threshold : 5.3999dBm
TX Power high warn threshold  : 2.4000dBm
TX Power low warn threshold   : -8.4013dBm
TX Power low alarm threshold  : -11.4026dBm

TX Bias high alarm threshold : 8.5000mA
TX Bias high warn threshold  : 8.0000mA
TX Bias low warn threshold   : 6.0000mA
TX Bias low alarm threshold  : 5.4920mA

```

To read by register name:

Get the list of the supported registers.

```

mlxables -d mt4115_pciconf0_cable_0 --show_all_regs
Available registers per page:
=====
page00_high registers:
=====
identifier      |
ext_identifier   |
connector_type  |
..
..
..
vendor_oui      |
..

```

Read the register with the register name you choose (e.g. vendor_oui, identifier).

```

mlxables -d mt4115_pciconf0_cable_0 --read_reg vendor_oui
vendor_oui = 0x0002c9
mlxables -d mt4115_pciconf0_cable_0 --read_reg identifier
identifier = 0x0d

```

To read all the Eeprom of the cable:

```

mlxables -d mt4115_pciconf0_cable_0 --read_all_regs
Available registers per page:
=====
page00_high registers:
=====
identifier | 0x0d
ext_identifier | 0x06
connector_type | 0x02

```

```

..
..
..
vendor_oui | 0x0002c9
..

```

This will print the same tables as "--show_all_regs" but with the data that was read.

To dump all the cable's pages in raw format:

```

# mlx cables -d mt4115_pciconf0_cable_0 --dump -b 16
+-----+
| Page: 0x00 , Offset: 000, Length: 0x80 |
+-----+
000: 0d 06 00 f0 00 00 00 00 00 00 00 00 00 00 00 00
016: 00 00 00 00 00 00 29 a7 00 00 80 7d 00 00 00 00
032: 00 00 37 fa 26 2a 33 68 1c 0c b3 f9 b2 76 c2 fc
048: c1 3e 00 00 00 00 00 00 00 00 00 00 00 00 00 00
064: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
080: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 01 00
096: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 08
112: 00 10 00 00 00 00 00 00 00 00 00 00 00 00 00 00
+-----+
| Page: 0x00 , Offset: 128, Length: 0x80 |
+-----+
128: 0d cc 23 81 00 00 00 00 00 00 00 00 05 ff 00 00
144: 00 00 03 50 4d 65 6c 6c 61 6e 6f 78 20 20 20 20
160: 20 20 20 20 1f 00 02 c9 4d 46 53 31 32 30 30 2d
176: 45 30 30 33 20 20 20 20 41 43 79 18 27 10 46 be
192: 18 07 f5 96 4d 54 31 36 31 33 46 54 30 30 36 39
208: 36 20 20 20 31 36 30 32 32 32 00 00 00 00 67 a9
224: 36 30 33 46 4d 41 32 30 33 47 31 34 32 38 20 20
240: 00 00 00 00 00 00 00 00 00 00 00 01 00 10 00 00
+-----+

```

```
| Page: 0x03 , Offset: 128, Length: 0x80 |
+-----+
128: 50 00 f6 00 46 00 00 00 00 00 00 00 00 00 00 00
144: 88 b8 79 18 87 5a 7a 76 00 00 00 00 00 00 00 00
160: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
176: 87 71 01 d3 43 e2 03 a5 00 00 00 00 00 00 00 00
192: 87 71 02 d4 43 e2 05 a5 00 00 00 00 00 00 00 00
208: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
224: a7 03 00 00 00 00 00 00 00 00 00 00 00 77 77 11 11
240: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```

MTUSB Cable Board

The mlx cables tool supports reading cable data directly via i2c when the cable is connected to a dedicated board. The board is connected to the host with an MTUSB adapter.

Examples on a Windows machine:

After adding the cables using 'mst cable add' the following mst status is presented:

```
mst status
MST devices:
-----
    mtusb-1
Cable MST devices:
-----
    mtusb-1_cable
```

Query the cable:

```
mlx cables -d mtusb-1_cable
Querying Cables ....
```

```
Cable #1:
-----
Cable name      : mtusb-1_cable
FW version      : 2.0.208
FW Dev ID       : 0x20
FW GW version   : Legacy
----- Cable EEPROM -----
Identifier      : QSFP+ (0dh)
Technology      : 850 nm VCSEL (00h)
Compliance      : 40G Active Cable (XLPPI), 100G AOC (Active
Optical Cable) or 25GAUI C2M AOC.
Wavelength     : 850 nm
OUI             : 0x0002c9
Vendor          : Mellanox
Serial number   : MT1707FT01544
Part number     : MFA1A00-E001
Revision        : A1
Temperature     : 31 C
Length          : 1 m
```

Read from a specific address:

```
mlx cables -d mtusb-1_cable -r -p 0 -o 165 -l 3
Page[0].Byte[165] = 0x00
Page[0].Byte[166] = 0x02
Page[0].Byte[167] = 0xc9
```

Cable Firmware Upgrade with Live-Patch

Live-Patch enables a seamless update of the cable firmware.

Prerequisites

The cable firmware gateway version must be set to ISFU (see "FW GW version : ISFU" in the example below).

Burn the cable firmware image binary.

```
# mlx cables -d mt52000_pciconf0_cable_22 -i img.bin -u
```

To get the cable's firmware binary, please contact Mellanox Support (support@mellanox.com).

Burning Process Example:

Query the device:

```
# mlx cables -d mt52000_pciconf0_cable_22
Querying Cables ....
Cable #1:
-----
Cable name      : mt52000_pciconf0_cable_22
FW version      : 32.20.121
FW Dev ID       : 0x22
FW GW version   : ISFU
----- Cable EEPROM -----
Identifier      : QSFP28 (11h)
Technology      : 850 nm VCSEL (00h)
Compliance      : Extended Specification Compliance is valid,
100GBASE-SR4 or 25GBASE-SR
Wavelength      : 850 nm
OUI             : 0x0002c9
Vendor          : Mellanox
Serial number   : MT1623FT01610
Part number     : MMA1B00-C100D
Revision        : A2
```



```
Temperature    : 31 C
Length         : 50 m
```

Query the image:

```
# mlx cables -i img.bin
Image name     : img.bin
FW version     : 32.30.204
FW Dev ID     : 0x22
FW GW version  : ISFU
```

Upgrade the firmware:

```
# mlx cables -i img.bin -d mt52000_pciconf0_cable_22 -u
Cable FW version : 32.20.121
Image FW version : 32.30.204
The image version is newer than the FW version on the cable, Do
you want to proceed (y/N)? y
100%
-I- The FW was updated successfully
```

Query and verify the new firmware version:

```
# mlx cables -d mt52000_pciconf0_cable_22
Querying Cables ....
Cable #1:
-----
Cable name     : mt52000_pciconf0_cable_22
FW version     : 32.30.204
FW Dev ID     : 0x22
FW GW version  : ISFU
```

```

----- Cable EEPROM -----
Identifier      : QSFP28 (11h)
Technology      : 850 nm VCSEL (00h)
Compliance      : Extended Specification Compliance is valid,
100GBASE-SR4 or 25GBASE-SR
Wavelength      : 850 nm
OUI             : 0x0002c9
Vendor          : Mellanox
Serial number    : MT1623FT01610
Part number      : MMA1B00-C100D
Revision        : A2
Temperature      : 31 C
Length          : 50 m

```

Troubleshooting

You may be able to easily resolve the issues described in this section. If a problem persists and you are unable to resolve it yourself please contact your NVIDIA representative or [Support](#).

General Related Issues

Issue	Cause	Solution
Adapter is no longer identified by the operating system after firmware upgrade	Happens due to burning the wrong firmware on the adapter, firmware corruption or adapter's hardware failure.	Power cycle the server. If the issue persists, extract the adapter and contact Support
Server is booting in loop/not completing boot after performing adapter firmware upgrade	Happens due to burning the wrong firmware on the adapter, firmware corruption or adapter's hardware failure.	Extract the adapter and contact Support
Some of the 5th generation (Group II) devices are represented with only one mst device	For 5th generation (Group II) devices, there is only one method available for accessing the hardware. For example, Connect-IB device is	When querying a 5th generation (Group II) device, use the conf mst device (for example: dev/mst/mt4113_pciconfx)

Issue	Cause	Solution
(dev/mst/mt4113_pciconfx) in the output of mst status	represented by dev/mst/mt4113_pciconfx mst device	
Enabling hardware access after configuring new secure host key, fails	The new configuration of the secure host key was not loaded by the driver	Restart the driver before enabling the hardware access again
MFT tools fail on PCI device with the following errors: • Operation not permitted • Failed to identify device • Failed to detect device ID • Unknown device • No such device • Failed to open device	Tools PCI semaphore might be locked due to unexpected process shutdown.	Run the following command: # mcra -c <mst_pci_device> *Supported on MFT-4.4.0 and newer versions.

mlxconfig Related Issues

Issue	Cause	Solution
Server not booting after enabling SRIOV with high number of VFs	Setting number of VFs larger than what the Hardware and Software can support may cause the system to cease working	To solve this issue: 1. Disable SRIOV in bios 2. Reboot server 3. Change num of VFs 4. Enable SRIOV in bios
After resetting configuration using the tool on 5th generation (Group II) devices, the configuration's value does not change	Firmware loads the default configuration only upon reboot	Reboot the server

Installation Related Issues

Issue	Cause	Solution
Unable to install the tool package on ESXi platform and the following message is printed on the screen: Got no data from process	Insufficient privileges	1. Copy the tool's package to /tmp/vmware and continue with the installation. If the issue persists, reboot the ESX server and try again 2. Use full file path of the tool's package Note: an additional reboot will be required after completing the installation
Unable to install kernel-mft in Linux due to compilation error that contains the following message: 'error: conflicting types for 'compat_sigset_t''	CONFIG_COMPAT might not be enabled in the kernel configuration.	Set the CONFIG_COMPAT to "y" in the kernel .config file, and rebuild the kernel.

Firmware Burning Related Issues

Issue	Cause	Solution
The following message is printed on screen when performing firmware update: An update is needed for the flash layout. The operation is not failsafe and terminating the process is not allowed.	A flash alignment operation is required.	Approve the alignment, avoid process interrupt.
Firmware update fails with the following message: -E- Burning FS4 image failed: Bad parameter Note: This is a rare scenario.	Firmware compatibility issue.	Re-run the burn command with --no_fw_ctrl flag.
The following message is printed on screen when performing firmware update: Shifting between different image partition sizes requires current	Firmware compatibility issue.	Re-load firmware and re-run the burn command.

Issue	Cause	Solution
image to be re-programmed on the flash. Once the operation is done, reload FW and run the command again Note: This is a rare scenario.		
The following message is printed on screen when trying to query/burn a Connect-IB device: <pre>-E- Cannot open Device: /dev/mst/mt4113_pciconf0. B14 Operation not permitted MFE_CMDIF_GO_BIT_BUSY</pre>	Using an outdated firmware version with the Connect-IB adapter.	1. Unload MLNX_OFED driver: /etc/init.d/openibd stop. 2. Add “-ocr” option to the 'flint' command. For example: flint -d /dev/mst/mt4113_pciconf0 -ocr q
The following message is reported on screen when trying to remove the expansion ROM using the 'drom' option: <pre>-E- Remove ROM failed: The device FW contains common FW/ROM Product Version - The ROM cannot be removed separately.B9</pre>	Updating only the EXP_ROM (FlexBoot) for recent firmware images which requires adding the 'allow_rom_change' option.	Allow “-allow_rom_change” option to the “flint” command. For example: flint -d <mst_device> -allow_rom_change drom
Burning command fails and the following message is printed on screen: <pre>-E- Can not open 06:00:0: Can not obtain Flash semaphore (63). You can run "flint -clear_semaphore -d <device>" to force semaphore unlock. See help for details.</pre>	Semaphore can be locked for any of the following reasons: • Another process is burning the firmware at the same time • Failure in the firmware boot • Burning process was force- fully killed • In a Multi-Host environment, another Host is	If no other process is taking place at the same time run the following command: flint -d <device> -- clear_semaphore OR Reboot the machine.

Issue	Cause	Solution
	currently burning the firmware	
Burning tool fails with the following message: -E- Unsupported binary version (2.0) please update to latest MFT package.	The binary version is incompatible with the burning tool.	Update MFT to the latest package.
mlxburn tool fails to generate a firmware image and displays the following message: -E- Unsupported MLX file version (2.0) please update to latest MFT package.	The MLX file version is incompatible with the image generation tool (mlxburn).	Update MFT to the latest package.
mlxburn tool fails to generate a firmware image and displays the following message -E- Perl Error: Image generation tool uses mic (tool) version 1.5.0 that is not supported for creating a bin file for this FW version. FW requires mic version 2.0.0 or above. Please update MFT package.	The MLX file version is incompatible with the image generation tool (mlxburn).	Update MFT to the latest package.
Burning tool fails with an error mentioning Firmware time stamping e.g -E- Burning FS3 image failed: Stamped FW version mismatch: 12.16.0212 differs from 12.16.0230	The device was set with a timestamp for a different firmware version than the one being burnt or the image is stamped with an older timestamp	Either set a newer timestamp on the image than there is on the device, or reset the timestamp completely. <code>flint -d <device> ts reset flint -i <image> ts reset</code>
Burning the image on Controlled FW (default update method: fw_ctrl in 'flint -d <device> query full' output), fails with: -E- Burning FS3 image failed: The Digest in the signature is wrong.	The image was changed without calculating the new digest on it with 'flint -i <img.bin> sign'.	Run 'flint -i <img.bin> sign', and retry.

Secure Firmware Related Issues

Issue	Cause	Solution
Changing device setting such as ROM/ GUIDS using the relevant flint commands result in failure with the following error: -E- <Operation> failed: Unsupported operation under Secure FW	Secure Firmware does not allow changes to the device data unless burning new Secure Firmware image.	N/A
Burning tool fails with the following error: -E- Burning FS3 image failed: The component is not signed.	The image is not signed with an RSA authentication.	Contact Support to receive a signed firmware image.
Burning tool fails with the following error: -E- Burning FS3 image failed: Rejected authentication.	The image authentication is rejected.	Contact Support to receive a signed firmware image.
Burning tool fails with the following error: -E- Burning FS3 image failed: Component is not applicable.	The image does not match the device (Wrong ID).	Contact Support to receive the firmware image for the device.
Burning tool fails with the following error: -E- Burning FS3 image failed: The FW image is not secured.	The image is not secured and is not accepted by the device.	Contact Support to receive a signed firmware image.
Burning tool fails with the following error: -E- Burning FS3 image failed: There is no Debug Token installed.	The debug firmware was burnt before the debug token was installed on the device.	Install the debug token using mlxconfig and then re-burn the firmware.
Burning firmware on a secure device fails with one of the following messages: -E- Burning FS3 image failed: Rejected authentication - The FW image is not secured - The key is not applicable	The image was not secured in a the proper way.	Ask for a secure image with the right keys that match the device.
Secure Firmware fails when using flint brom and drom commands.	flint brom and drom commands are not	N/A

Issue	Cause	Solution
	supported.	
mlxdump and wqdump debug utilities do not work in Secure Firmware	A customer support token was not applied.	N/A
When the CR space is in read only mode, the tracers may demonstrate an unexpected behavior.	A writing permission is required for them to work properly.	N/A
Applying token on the device fails with one of the following messages: • Component is not applicable • The manufacturing base MAC was not listed • Mismatch FW version • Mismatch user timestamp • Rejected forbidden version	The token was not generated or signed in the proper way.	N/A
Burning the firmware using the “--use_dev_rom” flag has no effect and the ROM is replaced with the one on the image.	Controlled firmware does not support changing boot image component.	Use “--no_fw_ctrl”.

Appendixes

- [Assigning PSID](#)
- [Remote Access to NVIDIA Devices](#)
- [Bootting HCA Device in Livefish Mode](#)
- [Burning a New Device](#)
- [Generating Firmware Secure and NV LifeCycle Configurations Files](#)
- [Updating Firmware Using ethtool/devlink and .mfa2 File](#)
- [Using MFT tools on Secured GPU Devices](#)

Assigning PSID

In some cases, OEMs or board manufacturers may wish to use a specific FW configuration not supplied by NVIDIA. After setting the new FW parameters in an INI file, the user should assign a unique PSID (Parameter Set ID) to this new configuration. The PSID is kept as part of the FW image on the device NVMEM. The firmware burning tools use this field to retain FW settings while updating FW versions.

This appendix explains how to assign a new PSID for a user customized FW, and how to indicate to the burning tools that a new PSID exists.

Note

Please change FW parameters with caution. A faulty setting of FW parameters may result in undefined behavior of the burnt device.

PSID Field Structure

The PSID field is a 16-ascii (byte) character string. If the assigned PSID length is less than 16 characters, the remaining characters are filled with binary 0s by the burning tool.

The table below provides the format of a PSID.

Vendor Symbol	Board Type Symbol	Board Version Symbol	Parameter Set Number	Reserved
3 characters	3 characters	3 characters	4 characters	3 characters (filled with '\0')

Example:

A PSID for NVIDIA MHXL-CF128-T HCA board is MT_0030000001, where:

MT_ Vendor symbol

003 MHXL-CF128-T board symbol

000 Board version symbol

Assigning PSID and Integrating Flow

To assign and integrate the new PSID to produce the new FW:

1. Write the new FW configuration file (in .INI format).
2. Assign it with a PSID in the format described above. Use your own vendor symbol to ensure PSID uniqueness. If you do not know your vendor symbol, please contact your local NVIDIA FAE.
3. Set the PSID parameter in the new FW configuration file.

Remote Access to NVIDIA Devices

Burning a Switch In-band Device Using mlxburn

In order to update MT52000 Switch-IB device with a specific GUID (for example, 0xe41d2d03001094b0) using In-Band, the following steps are recommended:

Note

For Linux device names should be listed with the /dev/mst prefix. For Windows, no prefix is required.

1. Make sure all subnet ports are in the active state. One way to check this is to run opensm, the Subnet Manager.

```
[root@mymach]> /etc/init.d/opensmd start  
opensm start [ OK ]
```

2. Make sure the local ports are active by running 'ibv_devinfo'.

3. Obtain the device LID. There are two ways to obtain it:

1. Using the “mst ib add” command:

The “mst ib add” runs the ibdiagnet/ibnetdiscover tool to discover the InfiniBand fabric and then lists the discovered IB nodes as an mst device. These devices can be used for access by other MFT tools.

```
[root@mymach]> mst ib add
-I- Discovering the fabric - Running: /opt/bin/ibdiagnet
-skip all
-I- Added 3 in-band devices
```

2. To list the discovered mst inband devices run “mst status”.

```
devices[root@mymach]> mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded
...
Inband devices:
-----
/dev/mst/CA_MT4103_sw005_HCA-1_lid-0x0001
/dev/mst/CA_MT4115_sw005_HCA-2_lid-0x0002
/dev/mst/SW_MT52000_lid-0x0010
[root@mymach]>
```

3. Using the ibnetdiscover tool, run:

```
ibnetdiscover | grep e41d2d03001094b0 | grep -w Switch
Switch 36 "S-e41d2d03001094b0"
```

```
# "SwitchIB Mellanox Technologies" enhanced port 0 lid 16 lmc 0
```

Note

The resulting LID is given as a decimal number.

4. Run `mlxburn` with the LID retrieved in Step 3 above to perform the In-Band burning operation.

Burn the Switch-INB device:

```
# mlxburn -d lid-0x0010 -fw ./fw-SwitchIB.mlx
-I- Querying device ...
-I- Using auto detected configuration file: ./MSB7700-
E_Ax.ini (PSID = MT_1870110032)
-I- Generating image ...
Current FW version on flash: 11.0.1250
New FW version: 11.0200.0120
Burning FS3 FW image without signatures - OK
Restoring signature - OK
-I- Image burn completed successfully.
```

In-Band Access to Multiple IB Subnets

In most cases, an adapter is connected to a single InfiniBand subnet. The LIDs (InfiniBand Local IDs) on this subnet are unique. In this state, the device access MADs are sent (to the target LID) from the first active port on the first adapter on the machine.

In case that the different IB ports are connected to different IB subnets, source IB port on the local host should be specified explicitly.


The device name would be in the format:

```
<any-string>lid-<lid-number>[,source adapter name][,source IB  
port number]
```

For example:

- On Linux: lid-3,mlx4_0,1
- On Windows: lid-3,0,1

Say we have the following setup:



H1 host has 2 adapters. Port 1 of the first adapter is connected to Switch 1, and port 2 of the second adapter is connected to Switch 2. Since the 2 adapters on the H1 are not connected to the each other, there are 2 separate IB subnets in this setup.

Subnet1 nodes: H1 Switch 1 and H2 Subnet2 nodes: H1 Switch 2 and H3

Running "ibv_devinfo" command on H1 would list the 2 adapter names. For ConnectX adapters, the names would be mlx4_0 and mlx4_1.

Running "mst ib add" would add ib devices from the default port (first active port on the first adapter) - only Subnet1 nodes would be listed.

To add the nodes of the second subnet, the source adapter and port should be specified to the "mst ib add" command in the following format:

```
# mst ib add <hca_name> <hca_port>
```

Examples:

Add nodes of both subnets, Run:

```
# mst ib add mlx4_0 1  
# mst ib add mlx4_1 2
```

List the devices:

```
# mst status  
...  
/dev/mst/CA_MT25418_H1_HCA-1_lid-0x0001,mlx4_0,1  
/dev/mst/CA_MT25418_H2_HCA-1_lid-0x0005,mlx4_0,1  
/dev/mst/SW_MT51000_Switch1_lid-0x0003,mlx4_0,1  
/dev/mst/CA_MT25418_H1_HCA-1_lid-0x0010,mlx4_1,2  
/dev/mst/CA_MT25418_H3_HCA-1_lid-0x0012,mlx4_1,2  
/dev/mst/SW_MT51000_Switch2_lid-0x0005,mlx4_1,2
```

Note

You can use the above device names with the MFT tools.

MTUSB-1 USB to I2C Adapter

The MTUSB-1 is a USB to I2C bus adapter. This chapter provides the user with hardware and software installation instructions on machines running Linux or Windows operating systems.

MTUSB-1 Device



MTUSB-1 Package Contents

Please make sure that your package contains the items listed and that they are in good condition.

Item	Quantity	Description
MTUSB-1 device	1	USB to I2C bus adapter
USB cable	1	USB_A to USB_B (1.8m)
I2C cable	1	9-pin male-to-male cable (1.5m)
Converter cable	2	9-pin female to 3-pin (small/large) (0.3m)

System Requirements

The MTUSB-1 is a USB device which may be connected to any Personal Computer with a USB Host Adapter (USB Standard 1.1 or later) and having at least one USB connection port.

Supported Platforms

MTUSB-1 is supported in Linux and Windows only.

Hardware Installation

To install the MTUSB-1 hardware, please execute the following steps in the *exact* order:

1. Connect one end of the USB cable to the MTUSB-1 and the other end to the PC.
2. Connect one end of the I2C cable to the MTUSB-1 and the other end to the system/board you wish to control via the I2C interface. If the system/board uses a 3-pin connector instead of a 9-pin connector, connect the appropriate converter cable as an extension to the I2C cable on the 9-pin end, then connect its 3-pin end to the system/board.

Software Installation

The MTUSB-1 device requires that the MFT package be installed on the machine to which MTUSB-1 is connected; see [MFT Installation](#) for installation instructions.

For a Windows machine, it is also required to install the MTUSB-1 driver; visit <http://www.diolan.com> to download this driver. This driver is required for the first use of the MTUSB-1 device.

1. Start the *mstl* driver. Enter: (Note: This step is not required in Windows.)

```
# mst start          (or mst restart if mst start was run  
earlier)
```

2. To obtain the list of *mst* devices, enter:

```
# mst status -v      (or mst restart if mst start was run  
earlier)
```

If MTUSB-1 has been correctly installed, “**mst status**” should include the following device in the device list it generates:

- On Linux: /dev/mst41:00.0/mtusb-1
- On Windows: mtusb-1

Switch Reprogramming through I2C Port

In order to reprogram the switch through the I2C adapter, follow the steps below:

For MSX1710/MSX67XX Switch systems:

1. Open the bus:

```
i2c -a 1 -d 1 /dev/mst/mtusb-1 w 0x60 0x20 0x10  
i2c -a 1 -d 1 /dev/mst/mtusb-1 w 0x62 0x00 0x01
```

2. Burn the firmware:

```
flint -d /dev/mst/mtusb-1 -i ./fw-SX.bin b
```

3. Power cycle the system by unplugging and re-plugging the power cord to load the new firmware.

For MSX6025/6036 Switch systems:

1. Open the bus:

```
i2c -d /dev/mst/mtusb-1 w 0x22 0x1a 0xfb
```

2. Route the I2C bus to the switch device:

```
i2c -d /dev/mst/mtusb-1 w 0x70 0x0 0x1
```

3. Burn the firmware:

```
flint -d /dev/mst/mtusb-1 -i ./fw-SX.bin b
```

4. Power cycle the system by unplugging and re-plugging the power cord to load the new firmware.

Remote Access to Device by Sockets

The mst device on a machine can be accessed (server side) remotely for debugging purposes using the minimum set of tools from another machine (client side) which may have more tools or faster machine.

To do so:

- The mst server should run on the 'server side machine'. Run: 'mst server start'
- The client side should add the mst 'server side'. Run: 'mst remote add <server side machine IP>'

After remote devices are added to the mst list device in the 'client side', you can run any tool that accesses the mst devices of the 'server side' as seen in the example below.

Usage of relevant command:

Command	Description
mst server start [port]	Starts mst server to allow incoming connection. Default port is 23108
mst server stop	Stops mst server.

Command	Description
mst remote add <host- name>[:port]	- Establishes connection with a specified host on a specified port (default port is 23108). - Adds devices on remote peer to local the devices list. <hostname> may be host name as well as an IP address.
mst remote del <host- name>[:port]	Removes all remote devices on a specified hostname. <host-name>[:port] should be specified exactly as in the "mst remote add" command.

Example:

The example below shows how to query the firmware of a device in the server side (machine: mft) from the client side (machine: mft1):

1. Run mst status in the server side:

```
[root@mft ~]# mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded

MST devices:
-----
/dev/mst/mt4099_pciconf0      - PCI configuration cycles
access.
                                domain:bus:dev.fn=0000:0b:00.0
                                addr.reg=88 data.reg=92
                                Chip revision is: B0
/dev/mst/mt4099_pci_cr0      - PCI direct access.
                                domain:bus:dev.fn=0000:0b:00.0
                                bar=0xd2600000 size=0x100000
                                Chip revision is: B0
/dev/mst/mtusb-1:            - USB to I2C adapter as I2C
master
```

2. Start the mst server in the 'server side':

```
[root@mft ~]# mst server start
```

3. Add mst remote device in the client side:

```
[root@mft1 ~]# mst remote add mft
```

4. Show the mst device in the 'client side' which contains remote devices for the 'server side' machine:

```
[root@mft1 ~]# mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded

MST devices:
-----
/dev/mst/mt4099_pciconf0      - PCI configuration cycles
access.                      domain:bus:dev.fn=0000:0b:00.0
addr.reg=88 data.reg=92
/dev/mst/mt4099_pci_cr0      - PCI direct access.
                              domain:bus:dev.fn=0000:0b:00.0
bar=0xd2600000 size=0x100000
                              Chip revision is: 01
Remote MST devices:
-----
/dev/mst/mft:23108, @dev@mst@mt4099_pciconf0
                              Chip revision is: B0
```

```
/dev/mst/mft:23108, @dev@mst@mt4099_pci_cr0
Chip revision is: B0
/dev/mst/mft:23108, @dev@mst@mtusb-1
```

5. Access a remote mst device from the 'client side':

```
[root@mft1 ~]# flint -d
/dev/mst/mft:23108, @dev@mst@mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.32.1092
FW Release Date: 17.8.2014
Rom Info:        type=PXE version=3.5.305 cpu=AMD64
Device ID:       4099
Description:      Node          Port1          Port2
Sys image
GUIDs:           0002c90300e6e4e0 0002c90300e6e4e1
0002c90300e6e4e2 0002c90300e6e4e3
MACs:            0002c9e6e4e1
0002c9e6e4e2
VSD:             n/a
PSID:            MT_1090120019
```

Accessing Remote InfiniBand Device by Direct Route MADs

To access IB devices remotely by direct route MADs (except for ConnectX-3 and ConnectX-3 Pro):

1. Make sure the local ports are connected to a node or more:

```
# ibstat
```

or

```
# ibv_devinfo
```

2. Obtain the device direct route path:

```
# mst ib add --use-ibdr --discover-tool ibnetdiscover mlx5_0
1
-I- Discovering the fabric - Running: ibnetdiscover -s -C
mlx5_0 -P 1
-I- Added 2 in-band devices
```

3. List the discovered direct route device:

```
# mst status MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded
MST devices:
-----
...
Inband devices:
-----
/dev/mst/CA_MT4113_server1_HCA-3_ibdr-0,mlx5_0,1
/dev/mst/SW_MT51000_switch1_ibdr-0.2,mlx5_0,1
```

4. Run any tool against the devices above.

```
#flint -d /dev/mst/CA_MT4113_server1_HCA-3_ibdr-0,mlx5_0,2 v
FS3 failsafe image
/0x00000038-0x00000f4f (0x000f18)/ (B00T2) - OK
```

```
/0x00201000-0x0020101f (0x000020)/ (ITOC_Header) - OK
/0x00203000-0x0020323f (0x000240)/ (FW_MAIN_CFG) - OK
/0x00204000-0x0020437f (0x000380)/ (FW_BOOT_CFG) - OK
/0x00205000-0x002057ff (0x000800)/ (HW_MAIN_CFG) - OK
/0x00206000-0x002060ff (0x000100)/ (HW_BOOT_CFG) - OK
/0x00207000-0x002195e3 (0x0125e4)/ (PCI_CODE) - OK
/0x0021a000-0x0021e3a7 (0x0043a8)/ (IRON_PREP_CODE) - OK
/0x0021f000-0x00226bab (0x007bac)/ (PCIE_LINK_CODE) - OK
/0x00227000-0x002a888f (0x081890)/ (MAIN_CODE) - OK
/0x002a9000-0x002a95bf (0x0005c0)/ (POST_IRON_BOOT_CODE) - OK
/0x002aa000-0x002aa3ff (0x000400)/ (IMAGE_INFO) - OK
/0x002aa400-0x002b3e7b (0x009a7c)/ (FW_ADB) - OK
/0x002b3e7c-0x002b4277 (0x0003fc)/ (DBG_LOG_MAP) - OK
/0x002b4278-0x002b427f (0x000008)/ (DBG_FW_PARAMS) - OK
/0x003fa000-0x003fbfff (0x002000)/ (NV_DATA) - OK
/0x003fd000-0x003fd1ff (0x000200)/ (DEV_INFO) - OK
/0x003ff000-0x003ff13f (0x000140)/ (MFG_INFO) - OK
/0x003ff140-0x003ff13f (0x000000)/ (VPD_R0) - OK
FW image verification succeeded. Image is bootable.
```

Booting HCA Device in Livefish Mode

In case a MLNX HCA fails to boot properly, and is not being identified by the system due to a corrupt firmware, the user is able to boot the card in livefish mode, which allows re-burning of the flash device in order to restore the device into functional mode.

The device can also be forced into booting in livefish mode (only when supported on the board). To do so, a direct access to the card is needed. By connecting the two flash present pins using a jumper while the machine is powered off, the card will boot in "flash not present" mode (the firmware will not be loaded from the flash) i.e livefish.

Booting Card in Livefish Mode

To boot the card in livefish mode:

1. Power off the machine.

2. Locate the Flash preset pins on the HCA.
3. Close the two pins using a jumper.
4. Power on the machine.

Booting Card in Normal Mode

To boot the card in normal mode:


1. Power off the machine.
2. Take off the jumper connected to the Flash Present pins on the HCA.
3. Power on the machine.


Common Locations of Flash Present Pins

The following photos show common locations of the Flash Present pins.

Note

Existence and location of Flash Present pins depends on the board manufacture.





Burning a New Device

Select the appropriate method depending upon your device model.

- [Connect-IB Adapter Card](#)
- [ConnectX-4 onwards Adapter Cards Family](#)
- [Spectrum or Switch-IB 2 Switch Systems](#)
- [Switch-IB Switch System](#)

Connect-IB Adapter Card

When burning a flash for the first time, the initial image should contain the correct GUIDs and VPD for the device. Subsequent firmware updates will not change these initial setting.

Note

flint for OEM is required for burning Connect-IB for the first time.

GUIDs and MACs

The Connect-IB image contains the Node, Port and System GUIDs and Port MACs to be used by the card. To simplify GUIDs assignment, the mlxburn tool can derive the MACs and GUIDs from a single base GUID according to NVIDIA methodology:

Description: UID	Number	Step
Port1 GUID: base	8	1
Port2 GUID: base + 8	8	1
Port1 MAC: guid2mac1(base)	8	1
Port2 MAC: guid2mac(base + 8)	8	1

Note: guid2mac(guid) is $((\text{guid} \gg 16) \& 0\text{ffffff}000000) | (\text{guid} \& 0\text{ffffff})$. Meaning, remove the 2 middle bytes of an 8 bytes GUID to generate a 6 bytes MAC.

PCI Vital Product Data (VPD)

The VPD information is returned by the firmware upon VPD access from the PCI configuration header.

- The vpd_ro file last 3 bytes are the vpd_rw tag-id and length
- The size of the vpd_r file (including the above 3 bytes) should be a multiple of 4

Burning a New Connect-IB Device

The VPD and GUIDs are stored in the last sector on flash that can be set as Write protected after the initial firmware burn.

Method 1: Generating Firmware with Specific GUIDs and Burning on the Flash

1. Generate the initial image with the correct GUIDs and VPD for the specific device, using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-ConnectIB.mlx -c FW/MCB194A-FCA_A1.ini -  
wrmage fw-ConnectIB-MCB194A-FCA_A1.bin -base_guid
```

```
0x0002c903002ef500 -vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set  
Flash0.WriteProtected=Disabled
```

3. Burn the entire flash, using the flint tool.

```
# flint -d /dev/mst/mt511_pciconf0 -i ./fw-ConnectIB-MCB194A-  
FCA_A1.bin -ocr -ignore_dev_data -allow_psid_change -nofs --  
yes burn
```

4. Set Write protection on the last sector, using mstflint:

For devices using Winbond flash:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,1-SubSectors
```

5. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set QuadEn=1
```

Method 2: Generating Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Flash

1. Generate the initial image with VPD for the specific device, using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-ConnectIB.mlx -c FW/MCB194A-FCA_A1.ini -  
writimage fw-ConnectIB-MCB194A-FCA_A1.bin -vpd_r_file  
./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set  
Flash0.WriteProtected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt5111_pciconf0 -i ./fw-ConnectIB-  
MCB194A-FCA_A1.bin -ocr -ignore_dev_data -allow_psid_change -  
nofs --yes burn
```

4. Set device manufacture GUIDs.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr -uid 0x0002c903002ef500  
smg
```

5. Set device GUIDs.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr -uid 0x0002c903002ef500  
sg
```

6. Set Write Protection on the last sector, using the mstflint tool.

For devices using Winbond flash:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,1-SubSectors
```

7. Enable flash quad SPI IO operations:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set QuadEn=1
```

1. To view flash settings, run:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw query
```

2. To view assigned GUIDs, run:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr q
```

3. To change a GUID after the initial burn, run:

```
# flint -d /dev/mst/mt4113_pciconf0 -ocr -uid  
0x0002c903002ef500 sg
```

ConnectX-4 onwards Adapter Cards Family

Upon first time device burning, the GUIDs, MACs and VPD of the device are required to be set on the flash.

The sections below demonstrate two methods of burning a new ConnectX-4 onwards device in order to set these initial settings. Subsequent firmware updates will not change these settings.

Note

flint for OEM is required for burning ConnectX-4 onwards adapter cards family for the first time.

For information regarding GUIDs, MACs and VPD, please refer to [Accessing Remote InfiniBand Device by Direct Route MADs](#).

Burning the ConnectX-4 onwards Adapter Cards Family

Method 1: Generating Firmware with Specific GUIDs and MACs and Burning it on the Device

In order to burn a new device, follow the steps below:

1. Disable the Write protection.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set  
Flash0.WriteProtected=Disabled
```

2. Burn the entire flash.

```
# flint -d /dev/mst/mt521_pciconf0 -i ./ fw-ConnectX4-  
MCX454_Ax.bin -ocr -ignore_dev_data - allow_psid_change -nofs  
--yes burn
```

3. Set Write protection

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,8-SubSectors
```

4. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set QuadEn=1
```

Method 2: Generating Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Device

In order to burn a new device, follow the steps below:

1. Disable the Write protection.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set  
Flash0.WriteProtected=Disabled
```

2. Burn the entire flash.

```
# flint -d /dev/mst/mt521_pciconf0 -i ./ fw- ConnectX4-  
MCX454_Ax.bin -ocr -ignore_dev_data - allow_psid_change -nofs
```

```
--yes burn
```

3. Set device manufacture GUIDs and MACs.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr -guid 0xe41d2d0300570fc0  
-mac 0x0000e41d2d570fc0 smg
```

4. Set device GUIDs and MACs.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr -guid 0xe41d2d0300570fc0  
-mac 0x0000e41d2d570fc0 sg
```

5. Set Write protection on the last sector using flint:

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,8-SubSectors
```

Note

The command may vary based on the Flash type used.

Protection_type can be :

- 1- Top,8-SubSectors, if it is in [W25QxxBV]
- 2- Top,1-Sectors, if it is in [MX25L16xxx, N25Q0XX, IS25LPxxx, S25FL256L, MX25Lxxx, W25Qxxx, MX25Uxxx]

6. Enable flash quad SPI IO operations.


```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set QuadEn=1
```

1. To view flash settings:

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw query
```

2. To view assigned GUIDs:

```
# flint -d /dev/mst/mt521_pciconf0 -ocr
```

3. To change a GUID after the initial burn:

```
# flint -d /dev/mst/mt4115_pciconf0 -ocr -guid  
0xe41d2d0300570fc0 sg
```

4. To change a MAC after the initial burn:

```
# flint -d /dev/mst/mt4115_pciconf0 -ocr -mac  
0x0000e41d2d570fc0 sg
```

5. To change a GUID and derive MAC from it after the initial burn, run:

```
# flint -d /dev/mst/mt4115_pciconf0 -ocr -uid  
0xe41d2d0300570fc0 sg
```

Spectrum or Switch-IB 2 Switch Systems

Upon first time flash burning, the GUIDs and VPD of the device are required to be set on the flash. The sections below demonstrate two methods of burning a new device in order to set these initial settings. Subsequent firmware updates will not change these settings.

Note

flint for OEM is required for burning Spectrum/Switch-IB 2 for the first time.

For information regarding GUIDs, MACs and VPD, please refer to [Accessing Remote InfiniBand Device by Direct Route MADs](#).

Burning the Spectrum/Switch-IB 2 Device

Method 1: Generating Firmware with Specific GUIDs and MACs and Burning it on Device

In order to burn a new Spectrum/Switch-IB 2 device, follow the steps below:

1. Generate the initial image with the correct GUIDs and VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-Spectrum.mlx -c FW/MCB194A-FCA_A1.ini -  
wrmage fw-Spectrum-MCB194A- FCA_A1.bin -base_guid  
0x0002c903002ef500 -base_mac 0x02c90ef500 -vpd_r_file  
./vpd_r_data.bin
```

2. Disable Write protection.

```
# flint -d /dev/mst/mt585_pciconf0 -  
override_cache_replacement hw set Flash0.WritePro-  
tected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt585_pciconf0 -i ./fw-Spectrum-MCB194A-  
FCA_A1.bin -override_cache_re- placement -ignore_dev_data -  
nofs -allow_psid_change -y b
```

4. Set Write protection.

```
# flint -d /dev/mst/mt585_pciconf0 -  
override_cache_replacement hw set  
Flash0.WriteProtected=Top,8-SubSectors
```

5. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt585_pciconf0 -  
override_cache_replacement hw set QuadEn=1
```

Method 2: Generating a Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Device

In order to burn a new Spectrum/Switch-IB 2 device, follow the steps below:

1. Generate the initial image VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-Spectrum.mlx -c FW/MCB194A-FCA_A1.ini -  
wrmage fw-Spectrum-MCB194A- FCA_A1.bin -vpd_r_file  
./vpd_r_data.bin
```

2. Disable Write protection.

```
# flint -d /dev/mst/mt585_pciconf0 -  
override_cache_replacement hw set Flash0.WritePro-  
tected=Disabled
```

3. Burn the entire flash using the flint tool.

```
# flint -d /dev/mst/mt585_pciconf0 -i ./fw-Spectrum-MCB194A-  
FCA_A1.bin -ocr -ignore_dev_data -nofs -allow_psid_change -y  
b
```

4. Set device manufacture GUIDs and MACs.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr -guid 0xe41d2d0300570fc0  
-mac 0x0000e41d2d570fc0 smg
```

5. Set device GUIDs and MACs.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr -guid 0xe41d2d0300570fc0  
-mac 0x0000e41d2d570fc0 sg
```

6. Set Write protection on the last sector.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,8-SubSectors
```

7. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr hw set QuadEn=1
```

1. To view flash settings:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr hw query
```

2. To view assigned GUIDs:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr q
```

3. To change a GUID after the initial burn:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr -guid  
0xe41d2d0300570fc0 sg
```

4. To change a MAC after the initial burn:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr -mac  
0x0000e41d2d570fc0 sg
```

5. To change a GUID and derive MAC from it after the initial burn, run:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr -uid  
0xe41d2d0300570fc0 sg
```

Switch-IB Switch System

Upon first time flash burning, the GUIDs and VPD of the device are required to be set on the flash.

The sections below demonstrate two methods of burning a new Switch-IB device in order to set these initial settings. Subsequent firmware updates will not change these settings.

Note

flint for OEM is required for burning Switch-IB for the first time.

For information regarding GUIDs, MACs and VPD, please refer to [Accessing Remote InfiniBand Device by Direct Route MADs](#).

Burning the Switch-IB Device

The examples below are for managed switches. For unmanaged switches, connect an MTUSB adapter (see [MTUSB-1 USB to I2C Adapter](#)) to the device and use the appropriate mst device (/dev/mst/mtusb...).

Method 1: Generating Firmware with Specific GUIDs and Burning it on the Flash

In order to burn a new Switch-IB device, follow the steps below:

1. Generate the initial image with the correct GUIDs and VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-SwitchIB.mlx -c FW/MSB7700-E_Ax.ini -  
wrimage fw-SwitchIB-MSB7700-E_Ax.bin -base_guid  
0x0002c903002ef500 -vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash0.WriteProtected=Disabled  
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash1.WriteProtected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt583_pciconf0 -i ./ fw-SwitchIB-MSB7700-  
E_Ax.bin - ocr -ignore_dev_data -allow_psid_change -nofs --  
yes burn
```

4. Set Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,2-SubSectors
```

5. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set QuadEn=1
```

Method 2: Generating Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Flash

In order to burn a new Switch-IB device, follow the steps below:

1. Generate the initial image VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-SwitchIB.mlx -c FW/MSB7700-E_Ax.ini -  
wimage fw-SwitchIB-MSB7700-E_Ax.bin  
-vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash0.WritePro-ected=Disabled  
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash1.WritePro-ected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt583_pciconf0 -i ./ fw-SwitchIB-MSB7700-  
E_Ax.bin - ocr -ignore_dev_data -allow_psid_change -nofs --  
yes burn
```

4. Set device manufacture GUIDs.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr -uid 0x0002c903002ef500  
smg
```


5. Set device GUIDs.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr -uid 0x0002c903002ef500  
sg
```

6. Set Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash0.WriteProtected=Top,2-SubSectors  
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set  
Flash1.WriteProtected=Top,1-SubSectors
```

7. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set QuadEn=1
```

1. To view flash settings:

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw query
```

2. To view assigned GUIDs:

```
# flint -d /dev/mst/mt583_pciconf0 -ocr q
```

3. To change a GUID after the initial burn:

```
# flint -d /dev/mst/mt52000_pciconf0 -ocr -uid  
0x0002c903002ef500 sg
```

Generating Firmware Secure and NV LifeCycle Configurations Files

Create Forbidden Versions Binary File

The flint "set_forbidden_versions" command takes as a parameter the binary file that contains the forbidden versions. To create this file easily you can use the mlxconfig "xml2bin" command. The forbidden versions configuration is found in the mlxconfig database.

1. Run mlxconfig "gen_tlvs_file".
2. Choose "nv_forbidden_versions".
3. Generate XML template using mlxconfig "gen_xml_template".
4. Set values for the parameters in the XML template.

You can set up to 32 forbidden versions. mlxconfig requires all the parameters in the XML template to have values, so in case you want to fill only one forbidden version you have to set the other 31 parameters to zero, you can do that by using index range as follows:

```
<forbidden_fw_version index='1..31' >0x0</forbidden_fw_version>
```

5. Run the xml2bin command to generate the binary file.

Create Tokens for Secure Firmware and NV LifeCycle

mlxconfig can be used to generate CS tokens, debug tokens and NV LifeCycle configuration files and apply it on your device.

To create the tokens:

1. Generate XML template that contains the necessary configurations for the token.

The XML template must have only one token configuration. The current available token configurations are: debug token, challenge based debug token, customer token, challenge based customer token and MLNX ID token.

The XML must also have the `file_applicable_to` configuration for all devices and an additional configuration which is device dependent:

1. For cables include the `file_device_unique` configuration.
 2. For other devices include the `file_mac_addr_list` configuration.
2. Generate a binary file that can be applied to the device using the mlxconfig `create_conf` command.

Updating Firmware Using ethtool/devlink and .mfa2 File

In order to flash the firmware on the device using ethtool, you need to prepare a .mfa2 firmware file using the mlxarchive tool - see [mlxarchive – Binary Files Compression Tool](#). Note that mlxarchive requires installing MFT with `--oem` option.

To perform firmware upgrade using ethtool/devlink, follow the steps below:

images/download/thumbnails/4291540909/Procedure_Heading_Icon-version-1-modificationdate-1757922508740-api-v2.PNG

1. Run the mlxarchive tool to generate the .mfa2 file (the following example assumes MFA2 v1.1.1).

```
# mlxarchive -v 1.1.1 --bins-dir <source binaries directory> -  
-out-file /lib/firmware/<file_name>.mfa2
```

2. Obtain the interface name of the adapter for which you wish to update firmware. For example, you can use `ifconfig -a`.

```
# ifconfig -a
...
p5p1: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether ec:0d:9a:48:af:2a txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0
    collisions 0

p5p2: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether ec:0d:9a:48:af:2b txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0
    collisions 0
...
```

3. Burn the firmware using the .mfa2 image with ethtool/devlink. Please use the .mfa2 file path relative to /lib/firmware.

ethtool command:

```
# ethtool -f <interface name> <file_name>.mfa2
```

devlink command:

```
$ devlink dev flash <dev> file <file_name>.mfa2
```

4. Query the adapter to verify that the new firmware version has been loaded following.

```
# mst start
# mst status -v
MST modules:
-----
    MST PCI module loaded
    MST PCI configuration module loaded
PCI devices:
-----
DEVICE_TYPE          MST                                PCI
RDMA                  NET                                NUMA
ConnectX5(rev:0)      /dev/mst/mt4119_pciconf0.1  05:00.1
mlx5_3                net-p5p2                      0
ConnectX5(rev:0)      /dev/mst/mt4119_pciconf0    05:00.0
mlx5_2                net-p5p1                      0
...
#

# flint -d /dev/mst/mt4119_pciconf0 q
Image type:           FS4FW Version: 16.25.1042 FW
Version(Running): 16.25.1020 FW Release Date: 30.4.2019 Product
Version: 16.25.1020 Rom Info: type=UEFI version=14.18.19
cpu=AMD64 type=PXE version=3.5.701 cpu=AMD64 Description: UID
GuidsNumber Base GUID: ec0d9a030048af2a 4 Base MAC:
ec0d9a48af2a 4 Image VSD: N/A Device VSD: N/A PSID:
MT_00000000080 Security Attributes: N/A
```

5. For the firmware update to take effect, you need to either reboot the server or run:

```
# mlxfwreset -d /dev/mst/mt4119_pciconf0 -y r
```

6. Validate the firmware update by a query.

Using mst:

```
# mst start

# flint -d /dev/mst/mt4119_pciconf0 q
Image type:          FS4
FW Version:          16.25.1042
FW Release Date:     15.5.2019
Product Version:     16.25.1042
Rom Info:            type=UEFI version=14.18.19 cpu=AMD64
                    type=PXE version=3.5.701 cpu=AMD64
Description:         UID                               GuidNumber
Base GUID:           ec0d9a030048af2a                   4
Base MAC:            ec0d9a48af2a                       4
Image VSD:           N/A
Device VSD:          N/A
PSID:                MT_00000000080
Security Attributes: N/A
#
```

Using devlink:

```
$ devlink dev info <dev>
pci/0000:05:00.0:
  driver mlx5_core
  versions:
    fixed: fw.psid MT_00000000080
    running: fw.version 16.23.1000
```

Using MFT tools on Secured GPU Devices

In systems with secured FW, GPUs cannot be accessed directly via PCIe, therefore "pci_cr" devices will become inaccessible.

The only way to send firmware queries is via the NVIDIA GPU Driver.

Please follow these instructions to discover and display GPU devices on your secured system:

1. Make sure the NVIDIA driver is loaded using "modprobe nvidia".
2. Start the mst service by running "mst start" command.
3. Discover GPU devices via the NVIDIA Driver using the "mst gpu add" command.
4. See the newly added devices using "mst status -v" command, they will appear under "GPU Devices".

Run any of the supported tools using the GPU NETIR mst device. For example:

```
mlxlink -d /dev/mst/netir10561_08.1.00_gpu0
```

ESXi

The MFT and MFT-OEM packages in VMware now include a new plugin feature. This plugin can be accessed and managed using the following command within the ESXi shell:

esxcli mellanox <package name> <tool name> <command>

For example:

esxcli mellanox mst status

To enable this functionality without requiring additional code for each tool, a wrapper has been implemented. This wrapper encapsulates the tool's command and ensures the output is returned in the correct XML format.

Additionally, a plugin generator has been developed. This generator automatically creates the necessary XML files for each tool during the packaging process, streamlining the integration of new tools into the plugin framework.

There are a few challenges with integrating existing tools into the ESXi plugin:

- Tools that generate output during their execution (e.g., progress indicators like percentage bars in mlxfwmanager) can cause issues with the VMware plugin if not handled properly
 - To address this, some tools might need to provide an option to suppress such progress indicators. For example, mlxfwmanager includes the `--no-progress` flag for this purpose
- If a tool requires user input or prompts during its execution, it must provide clear mechanisms for handling these interactions within the context of the VMware plugin
 - This may include options for non-interactive execution (e.g., `--yes`, `--force`) or clear and well-defined prompts with expected input formats and error handling
- If a tool prints output with colors, the wrapper converts the color output to regular, otherwise the VMware plugin will fail

In summary:

- Each tool might require specific adjustments or workarounds to ensure compatibility with the VMware plugin.
- In some cases, the tool's output format or behavior may be inherently incompatible with the plugin's requirements, preventing successful integration.

By carefully considering these factors and implementing appropriate solutions (such as using suppression flags or modifying tool behavior), we can maximize the number of tools that can be successfully integrated with the VMware plugin.

Supported plugin commands:

Description	Original Command	esxcli plugin command
Create special files that represent Nvidia devices in directory /dev/mst. After successfully completion of this command the MST driver is ready to work and you can invoke other Nvidia tools.	/opt/mellanox/bin/ mst start	esxcli mellanox mft mst start
Stop Nvidia MST driver service.	/opt/mellanox/bin/ mst stop	esxcli mellanox mft mst stop
Show all Nvidia devices connected to server	/opt/mellanox/bin/ mst status	esxcli mellanox mft mst status
Show all Nvidia devices connected to server [verbose mode]	/opt/mellanox/bin/ mst status -v	esxcli mellanox mft mst status -v esxcli mellanox mft mst status --verbose
Query all devices connected to server	/opt/mellanox/bin/ mlxfwmanager	esxcli mellanox mft mlxfwmanager query
Query device and look for available online FW for the given device from NVIDIA web-site , if current FW version older than latest one , FW upgrade will be done	/opt/mellanox/bin/ mlxfwmanager --online --update --no-progress --yes	esxcli mellanox mft mlxfwmanager update
Burn FW image to a given device	/opt/mellanox/bin/ flint -d <dev> -i <image> --silent -y b	esxcli mellanox mft flint burn -d <dev> -i <image> --run
start MST server for remote connections	/opt/mellanox/ mst server start -s <pass>	esxcli mellanox mft mst serverStart -s <passphrase> -p <port>
Stop MST server	/opt/mellanox/ mst server stop	esxcli mellanox mft mst serverStop

Query specific device connected to server	/opt/mellanox/bin/ flint -d <dev> q	esxcli mellanox mft flint query -d <dev> - -run
Query specific device connected to server with full option	/opt/mellanox/bin/ flint -d <dev> q full	esxcli mellanox mft flint query -d <dev> - -run --full
Verify entire device flash	/opt/mellanox/bin/ flint -d <dev> v	esxcli mellanox mft flint verify -d <dev> - -run
Show all mlxreg available supported registers for the given device	/opt/mellanox/bin/ mlxreg -d <dev> show_regs	esxcli mellanox mft mlxreg showRegs -d <dev>
The dump file is used by the Support team for hardware troubleshooting purposes. It can be applied on all NVIDIA devices.	/opt/mellanox/bin/ mstdump <dev> device_name.dmp	esxcli mellanox mft mstdump dump -d <dev>
Read the hardware temperature from NVIDIA devices with temperature sensors (all NVIDIA devices) and prints the result in Celsius degrees.	/opt/mellanox/bin/ mget_temp -d <dev>	esxcli mellanox mft mgettemp read -d <dev>
Show NVIDIA device link status	/opt/mellanox/bin/ mlxlink -d <dev>	esxcli mellanox mft mlxlink status -d <dev>

Note

If you're not sure how to run a command or you want to explore the available flag shortcuts in the esxcli plugin, you can check it by writing a partial start of a command and utilizing the output you're getting to figure out what to write next.

Example: flint tool

Write the beginning of the command like this:

```
esxcli mellanox mft flint
```

the output will be the available options for the continuation of the command:

```
[root@apps-35:~] esxcli mellanox mft flint
Usage: esxcli mellanox mft flint {cmd} [cmd options]

Available Commands:
  burn          Burn flash.
  query         Query misc. flash/firmware characteristics, use "full" to get more information.
  verify        Verify entire flash.
  version       Display flint version
[root@apps-35:~] █
```

And you can continue the command with the option you'd like to proceed with, to see which flags are needed for the chosen command.

For example, if you'd like to choose the "verify" command, write:

```
esxcli mellanox mft flint verify
```

the following output will be displayed:

```
[root@apps-35:~] esxcli mellanox mft flint verify
Error: Missing required parameter -r|--run

Usage: esxcli mellanox mft flint verify [cmd options]

Description:
  verify          Verify entire flash.

Cmd options:
  -d|--device=<str> Device flash is connected to.
  -r|--run         Use "--run" to execute command. (required)
[root@apps-35:~] █
```

Please note that in the flint command the user must use the --run or -r flag to run the command.

If the user forgets to use the required command, an informative error message will be displayed:

```
[root@apps-35:~] esxcli mellanox mft flint verify -d mt4119_pciconf0
Error: Missing required parameter -r|--run
```

```
Usage: esxcli mellanox mft flint verify [cmd options]
```

```
Description:
```

```
    verify                Verify entire flash.
```

```
Cmd options:
```

```
    -d|--device=<str>    Device flash is connected to.
```

```
    -r|--run              Use "--run" to execute command. (required)
```

```
[root@apps-35:~] █
```

Document Revision History

Release Notes Revision History

MFT Release Notes Change Log History

Component/ Tool	Description
Rev. 4.33.0-169	
mlxfwmanager	Added the ability to skip firmware update when the target is already burned on the device and the user used the skip_if_same flag. Usage: <code>mlxfwmanager -d <> -u --skip_if_same -i <.mfa></code> <code>flint -d <> -i <.bin> --skip_if_same b</code>
flint	Added support for flint to query firmware images contained within PLDM (.fwpkg) package files.
mlxlink	Added support for a new field for --show_module flag. Added support for a new capability to allow the user to configure recovery types using the flag --phy_recovery. The recovery types available are: - host_serdes_feq - host_logic_re_lock
mlxfwreset	Added support for sync 2 to reset a PCIe switch using a hot reset using the arguments --sync 2 and --method 1.
Rev. 4.32.0-120	

Component/ Tool	Description
mlxpttrace	Added support for --raw_dump flag for mlxpttrace utility. The flag allows users to take a raw resource_dump of HW_TRACE segment and translate it to readable traces, as if they were taken from mlxpttrace.
flint	Added support for displaying device mode by adding either independent, standalone or unknown mode to the flint hardware query output.
	Added support for displaying TB/BP bits as-is and for displaying the SRWD bit for specific flash types.
	Added support for Independent module Stand Alone option. SA mode on Moose is enabled.
mlxlink	Added support for FEC correctable and FEC uncorrectable in mlxlink --port_type PCIE -c.
	Added support for aggregating module information for all ASICs for an aggregated port. This feature enables to present a single value for each field instead of presenting for each link separately.
	Added support for mlxlink port mapping to FNM.
	Added support for -m options in mlxlink.
	Added new fields to support the ELS and OE unique characteristics and required telemetry.
	Added support for a new flag "module_state" with three states (up, down, tg) to allow the user to change the module state.
	Added a feature to PRBS to support dc_cpl_allow flag to run PRBS on DC coupled links. Getting a DC coupled ports into test\PRBS mode will require the user's approval, to avoid HPS shortage.
	Added support to display a detailed BER count for each lane.
mlxconfig	Rearranged the way BYTE type TLVS are handled in mlxconfig to properly support customization_number.
	Added support to output configuration to file as JSON.
mlxreg	Removed PRM reg index enforcement from mlxreg tool.
mlxfwmanager	Added support for flashing firmware binary image stored in

Component/ Tool	Description
	PLDM package for flint and mlxfwmanager tools.
mlxptrace	Added support for --raw_dump flag for mlxptrace tool. This feature supports hardware Tracer Dump From Resource D
Rev. 4.31.0-149	
flint	SECURITY_LOG section was added to image layout. Added FS5_SECURITY_LOG identifier which will be displayed during command: <pre>flint -i <bin> verify</pre> flint -d <dev> -ocr hw query: Added support for querying B (Block Protection) and TBS (Top Bottom Selection) in raw, b form. flint -d <dev> -ocr hw set: Added support for performing p sets for write protection. This allows users to set either the TBS bit or the BP bits individually, instead of requiring both to be set simultaneously. Added support for displaying flint query if the device is Soc Direct device (If not - nothing new will be printed). For BF-3 devices, will also display if aux card is connected. Added support for querying if the Aux card is connected by of MRSV.two_p_core_active. This is meaningful only if the case where the two_p_core_a strap is fed from the AUX card plug.
mlxdpa	Added support for host ELF file to appear in a format where each DPA app can contain multiple DPA ELF's for different hardware arch versions. Command: <pre>mlxdpa -e <host elf file> -c <certificate path> -p <private key path> -o <output path> sign_dpa_apps</pre>
mst	Added support for creating a planarized mst device file by providing a SystemImageGUID and the 4 lids that share it. Command: <pre>mst ib create_aggregated_device -- system_image_guid <> --lids <></pre> In case the IB devices were created with mlx5_1, the command should be as follows:

Component/ Tool	Description
	<code>mst ib create_aggregated_device --system_image_guid <> --lids <> --hca_id mlx5_</code>
mlxconfig, mlxtokengenerator	mlxconfig and mlxtokengenerator support ConnectX-7 and BlueField-3 devices with challenge-based tokens.
mlxconfig	Added support to output configuration to file as JSON. Command: <pre> mlxconfig -d /dev/mst/mt4129_pciconf0 -j /tmp/configuration.json query mlxconfig -d mt4129_pciconf0 --json_format C:\Users\Administrator\Desktop\configuration. -e query NUM_OF_VFS </pre>
mget_temp	Added support for get temperature tool to mstflint.
mlxreg	The tool no longer enforces indexes, indexes that are not specified will be set to zero.
General	Added support for RDMA devices modified names.
	Added support to detect ConnectX location using straps (to allow Same INI for both ConnectX).
Rev. 4.30.0	
flint	Detect ConnectX location using straps. If a device is multi-ASIC system component, display its geographical address to the user. Example (for a ASIC platform device): Geographical Address: ASIC 3 Note that for a device that is not multi-ASIC system component, no such data will be displayed.
	Added the option to enable the user to query the certificate status after burning the DPA cert. This tool will print a list of the certificates and their metadata. If the command includes cert uuid, the certificate will be written to the provided file. Command: <pre> flint -d <device_name> --component_type digital_cacert [--cert_uuid <cert uuid>] query_components [output file] </pre>
mlxreg	Added the option <code>--overwrite</code> for sending a SET command without sending an initial GET command that fills the

Component/ Tool	Description
	unspecified non-index fields. Example: <pre>mlxreg -d <device_name> --reg_name MNVIA -- overwrite --set "writer_id=9"</pre>
resourceparse/resourcedump	Added the option <code>--out-dir</code> to write each segment into different file under the supplied directory. Examples: <pre>resourcedump dump -d <device_name> -s <segment> --out-dir <output_directory></pre> <pre>resourceparse -d <dump_file> -p map --ou- dir <output_directory></pre> Added the option <code>--hide-segment-header</code> to hide seg header from ADB parse output.
General	Implemented new reset flow for PCIe Switch and Connect-devices to reset the device using HOT reset mechanism. Added the option to allow users to burn the QM3 FW on the BMC server using the Redfish interface. Added support for recovering a device from Zombiefish mode. A device in Zombiefish mode exposes the functional device ID (it looks like a functional device, though it does not have valid firmware running on it). To recover a device from Zombiefish mode, run the following command: <pre>flint -ocr -d -i -y b</pre>
Rev. 4.29.0	
General	Added a warning message before deprecating the support of OpenSSL engine in the next release.
flint	Added support to print new INI version field.
mlxtokengenerator	Added support for challenge data from blob file instead of device. Example of use: "mlxtokengenerator -b <challenge_blob.bin> -t switch -o /tmp/crcs_token.xml generate_token"
Rev. 4.28	

Component/ Tool	Description
General	Added support for flint query to display the port GUID, noc GUID, system GUID, and allocated GUID for devices that are of a multi-asic system.
	Expanded the MCC register to include more informative error messages which are relevant for module upgrade flows.
	Upgraded full OS.
	Added support for new flag "-s" which allows the user to determine which I2C secondary address to use when running mget_temp tool
	Added an error message stating that the image/device is encrypting and breaking the flow.
	Added support in mlxtrace and fwtrace tools to read event ArcusE.
mlxlink	Disabled physical state in optic cables.
mlxfwreset	The mlxfwreset tool might fail when using PPC64LE on the 8.7 operating system.
	Changed the default firmware reset to level 3 from level 4 for PCIe devices. To load new configurations, either execute mlxfwreset level 3 or initiate a cold boot.
Rev. 4.27.0-83	
General	When using the TACACS protocol to check scripts that are run during login, the MFT auto-completion generation is activated. The auto-complete files are now available in a separate package, which is an optional installation.
	Added flint support for querying and upgrading firmware components of modules of part number MMA4Z00-NS.
mlxlink	Added mlxlink support for read/write/dump actions via direct EEPROM. This is a Beta level support feature that is currently limited to IEF file-systems.
Rev. 4.26.1	
Bug Fixes	See MFT Bug Fixes History .
Rev. 4.26	

Component/ Tool	Description
mlxconfig	Removed the <code>--read_only</code> flag from the mlxconfig tool.
General	Added support for an additional flash type - Winbond Part W25Q256JVFIQ.
General	Removed dependency on Boost library.
General	Added support for VPATH builds.
General	The descriptors for DEB/RPM packages are now configured to include two additional tools: mstreg and mstlink. This results in the addition of build-time dependencies on <code>libexpat1-dev</code> and <code>liblzma-dev</code> .
Rev. 4.25.1	
mlxfwreset	Added a query for the last reboot. The " <code>mlxfwreset -d</code> " command now shows the cause for the last reboot, and the number of clock cycles since the last cold reset.
mlxconfig	Added a priority field to the XML header of each TLV in the mlxconfig xml file. The priority possible values are "MLNX", and "USER".
Rev. 4.25.0	
General	Added MFT package for WinPE running on Arm64 (aarch64) processors.
	Added Sha256 signature to MFT RPM packages in order to enable installation on FIPS (Federal Information Processing Standards) enabled systems.
mlxconfig	Added <code>--read_only</code> as a new flag to the mlxconfig tool. When the query with this flag is enabled, the user is able to see read-only parameters. These parameters are marked with 'RO' in the command output.
mlxfwreset	Added support for DGX H100 device reset. All DGX H100 device reset requests are handled by the mlxfwreset tool. When the device ID of the DGX H100 device is provided, the tool proceeds to reset the device accordingly. As the final step in the reset process, the reboot command is executed, resulting in a reboot of the device setup.
mlxlink	Added SNR (signal-noise ratio) for the media and host side active\optical NDR modules.

Component/ Tool	Description
mlxdpa	mlxdpa was added the ability to create and sign containers the addition and removal of certificates.
mlxdump	Starting from this release, the fsdump mode of the mlxdr tool is deprecated. Support will be provided by November 2 Please use resource-dump with the appropriate segment i
Rev. 4.24.0	
mlxlink	Updated the <code>show_module</code> command output to display F TX power in a higher resolution.
	Updated the <code>show_module</code> command output to display n module information fields - Round Trip Latency, Intra-ASIC Latency and Module Datapath Latency.
General	Added support for Microsoft CBL-Mariner Linux Operating System.
	Added a new flag, <code>[--skip_driver]</code> , to allow control of stop/start driver functionality in reset flow.
fwtrace	Added fwtrace the ability to detect when a token is applic work in relevant mode (instead of constantly working in Se Mode).

MFT Bug Fixes History

The table below lists the history of bugs fixed. For a list of old Bug Fixes, please see [MFT Archived Bug Fixes](#) file.

Internal Ref. No.	Issue
4406754	Description: Fixed an issue with wrong device enumeration.
	Keywords: Enumeration
	Discovered in Version: 4.32.0-120
	Fixed in Release: 4.33.0-169
4398750	Description: Added support for reset level 1 type 3 and 4 when the driver is signed in a UEFI system.
	Keywords: UEFI

Internal Ref. No.	Issue
	Discovered in Version: 4.32.0-120
	Fixed in Release: 4.33.0-169
4378652	Description: Added support for SIGHUP signal handling in MFT infrastructure to trigger configuration reloads or graceful runtime updates.
	Keywords: SIGHUP
	Discovered in Version: 4.26.0
	Fixed in Release: 4.32.0-120
4337526	Description: Fixed an issue relating to querying the counters for local_port 255 in Spectrum4 standalone mode.
	Keywords: local_port 255, Spectrum4
	Discovered in Version: 4.29.0-131
	Fixed in Release: 4.32.0-120
4294588	Description: Changed the polling method to check if BlueField reset is complete.
	Keywords: BlueField
	Discovered in Version: 4.31.0-149
	Fixed in Release: 4.32.0-120
4291685	Description: Removed PSID MT_0000000884 from PCIE switch map.
	Keywords: PSID, PCIE
	Discovered in Version: 4.31.0-149
	Fixed in Release: 4.32.0-120
4290640	Description: Fixed the issue of handling bad arguments in mlxreg. The tool will report the error, print the usage message and exit.
	Keywords: mlxreg, bad error code
	Discovered in Version: 4.31.0-149
	Fixed in Release: 4.32.0-120
4258362	Description: Adapted the NIC driver name to support any custom name.
	Keywords: NIC driver name

Internal Ref. No.	Issue
	Discovered in Version: 4.31.0-149
	Fixed in Release: 4.32.0-120
4220920	Description: MFT on FreeBSD OS supports PCI-CORE VSC address spaces separation.
	Keywords: FreeBSD OS, PCI-CORE VSC address
	Discovered in Version: 4.30.0-139
	Fixed in Release: 4.31.0-149
4091646	Description: Changed the field name in code from dp_st_lane0 to dp_st_lane[0].
	Keywords: mlxlink,, DataPath,dp_st_lane0, dp_st_lane[0]
	Discovered in Version: 4.28.0
	Fixed in Release: 4.30.0
4078946	Description: Added handling interrupts between burning chunks to cables.
	Keywords: interrupts, burning chunks
	Discovered in Version: 4.28.0
	Fixed in Release: 4.30.0
3953342	Description: Removed support for OpenSSL engine.
	Keywords: OpenSSL engine
	Discovered in Version: 4.29.0
	Fixed in Release: 4.30.0
3832522	Description: Created VMware domain security policy according to the needs of MFT plugins.
	Keywords: VMware
	Discovered in Version: 4.26.1.102
	Fixed in Release: 4.29.0
3993256	Description: Corrected the order of reading data via I2C from big endian to little endian
	Keywords: I2C
	Discovered in Version: 4.28.0

Internal Ref. No.	Issue
	Fixed in Release: 4.29.0
3880918	Description: Added a validation that states that the provided path is a file and provided a better error message.
	Keywords: Validation, path
	Discovered in Version: 4.28.0
	Fixed in Release: 4.29.0
3953339	Description: Added a warning message before deprecating the support for OpenSSL engine in the next release.
	Keywords: OpenSSL
	Discovered in Version: 4.28.0
	Fixed in Release: 4.29.0
3886315	Description: To reset or shut down the BlueField Arm, it is mandatory to specify the --sync 0 argument with reset level 1 and reset type 3 or 4. For example: 'mlxfwreset -d -l 1 -t 4 --sync 0 r'.
	Keywords: BlueField Arm, shutdown
	Discovered in Version: 4.28.0
	Fixed in Release: 4.29.0
3819004	Description: flint's CMIS burn flow for cables ignores signals (e.g. CTRL+C) during the burn.
	Keywords: CMIS, burn
	Discovered in Version: 4.28.0
	Fixed in Release: 4.29.0
3645548	Description: Fixed an issue that led to wrong M1-M4 measurements calculation when using ConnecX-7.
	Keywords: M1-M4 measurements, ConnecX-7
	Discovered in Version: 4.26.0
	Fixed in Release: 4.26.1
3632765	Description: Fixed an issue that occurred when attempting to unzip the mlxfwmanager self-extractor.
	Keywords: mlxfwmanager, unzipping

Internal Ref. No.	Issue
	Discovered in Version: 4.25.0
	Fixed in Release: 4.26.0
3582574	Description: Fixed an issue that prevented ConnectX-5 EX reset using the fastfwreset tool.
	Keywords: fastfwreset
	Discovered in Version: 4.25.0
	Fixed in Release: 4.26.0
3582575	Description: Fixed an issue that caused incorrect enumeration in NVIDIA devices.
	Keywords: incorrect enumeration
	Discovered in Version: 4.25.0
	Fixed in Release: 4.26.0
3613010	Description: Fixed an issue where mlxdump did not work with Quantum-2 switches due to the absence of the Quantum2.csv file from the C:\Program Files\Mellanox\WinMFT\mstdump_dbs\ folder.
	Keywords: mlxdump, Quantum-2
	Discovered in Version: 4.25.0
	Fixed in Release: 4.26.0
3474570	Description: Fixed an issue that occurred when two MFT tools were running simultaneously, and while one of them loaded the driver, the second tool, which was not supposed to reload it in this case, failed to discover the Mellanox devices.
	Keywords: Driver reload
	Discovered in Version: 4.24.0
	Fixed in Release: 4.25.0
3471307	Description: Fixed an issue where incorrect eye information was displayed for 10G speed over ConnectX-7 devices.
	Keywords: Eye information, ConnectX-7
	Discovered in Version: 4.23.0
	Fixed in Release: 4.25.0

User Manual Revision History

Revision	Date	
4.34.0-145	November 10, 2025	Updated: • Access to Hardware Devices • Supported Operating Systems and Platforms • mlxconfig – Changing Device Configuration Tool - Added -with_default, --host_id and --pf_index flags • mlxlink Utility - Added --rx_modulation and --tx_modulation flags • mlxreg Utility - Added recommendation • mlxdpa – DPA Applications Sign Tool • Examples of mlxconfig Usage • Burning a Firmware Image • Verifying the Firmware Image • Querying the Firmware Image
4.33.0-169	August 08, 2025	Updated: • mlxlink Utility • mlxconfig – Changing Device Configuration Tool - Added -i2c_secondary • mlxreg Utility - Added --full_path • mlxfwreset – Loading Firmware on 5th Generation Devices Tool - Added PCIe Switch Reset via Hot Reset • flint – Firmware Burning Tool - Added component_type and skip_if_same • mlxfwmanager – Firmware Update and Query Tool - Added --component_type componentName and --skip_if_same
4.32.0-120	May 08, 2025	Updated: • Secure Host • mlxptrace Utility - Added --raw_dump flag • fwtrace Utility - Added --raw_dump flag • Burning a Firmware Image - Added Burning PLDM Images • Updating the Device using PLDM • mlxburn – Firmware Image Generator and Burner • mlxtokengenerator - Token Creation Tool • mlxburn – Firmware Image Generator and Burner

Revision	Date	
		• Linux - Added i2c • mlxfwmanager – Firmware Update and Query Tool • mlxcables - Cables Tool - Added note
4.31.0-149	February 10, 2025	Updated: • mget_temp Utility • mlxconfig – Changing Device Configuration Tool • Linux • Using mlxconfig • Secure Host Added: • ESXi
4.30.0-139	November 11, 2024	Updated: • mlxreg Utility • resourceparse Utility • Supported Operating Systems and Platforms • mlxconfig – Changing Device Configuration Tool Added: • mlxptrace Utility
4.29.0	August 14, 2024	Updated: • flint – Firmware Burning Tool • cpldupdate – Tool for Programming On-Board CPLDs on NVIDIA Devices • mlxlink Utility
4.28.0	May 7, 2024	Updated: • mget_temp Utility
4.27.0	February 8, 2023	Added Bifurcation Configuration under mlxconfig – Changing Device Configuration Tool .
4.26.1	December 14, 2023	No changes to the User Manual.

Revision	Date	
4.26.0	November 6, 2023	Updated: • mlxdpa – DPA Applications Sign Tool • mlxconfig – Changing Device Configuration Tool
4.25.1	October 22, 2023	Added: • Advance Options to "Generating an XML Template for the Configurations" under mlxconfig Commands.
4.25.0	August 10, 2023	Updated: • Cable Burn Command Running CMIS Firmware Upgrade Flow for Supported Cables under Burning a Firmware Image. • mlxdpa – DPA Applications Sign Tool • mlxfwreset – Loading Firmware on 5th Generation Devices Tool • fwtrace Utility • mlxtrace Utility • resourcedump Utility • resourceparse Utility • mst Synopsis - Windows under Windows. • mst Synopsis - VMware under VMware ESXi. • mst Synopsis - FreeBSD under FreeBSD. • mst Synopsis - Linux under Linux. Added: • mlx cableimgen - Cable Firmware Image Wrapper Generation Tool under Firmware Generation, Configuration, and Update Tools.

Document Conventions and Related Documents

Abbreviations and Acronyms

Term	Description
MFT	NVIDIA® Firmware tools
MST	Software tools and it is the name of the script that starts/stops the driver used by MFT tools
mlx	Extension of the text firmware file which contains all the firmware content
ini	Extension of the firmware configuration file which is in INI format and contains card specific configurations.
bin	Extension of the binary firmware file which is a combination of INI and mlx file
MFA	Extension of the a firmware file that contains several binary files of firmware for different cards/boards
4th Generation ICs/ Group I of ICs	Contains the following devices: • ConnectX-3 • ConnectX-3 Pro
5th Generation ICs/ Group II of ICs	Contains the following devices and newer: • Connect-IB • Switch-IB • Switch-IB 2 • NVIDIA Spectrum • NVIDIA Spectrum-2 • ConnectX-4 • ConnectX-4 Lx • ConnectX-5 • ConnectX-5 Ex • ConnectX-6

Term	Description
	• ConnectX-6 Dx • NVIDIA BlueField

Reference Documents and Downloads

Reference Documents and Downloads	Location
MFT web page	https://network.nvidia.com/products/adapter-software/firmware-tools/
Firmware Release Notes	https://docs.nvidia.com/networking/category/adapterfw
DOCA-Host	https://docs.nvidia.com/networking/dpu-doca/index.html#doca
WinOF/WinOF-2	https://docs.nvidia.com/networking/category/winof2
VMware	https://docs.nvidia.com/networking/category/vmwareesxiasyncdrivers
FreeBSD	https://docs.nvidia.com/networking/category/freebsd

Legal Notices and 3rd Party Licenses

The following are the drivers' software, tools and HCA firmware legal notices and 3rd party licenses.

Product	Version	Legal Notices and 3rd Party Licenses
Firmware	xx.47.1012	• HCA Firmware EULA • 3rd Party Unify Notice • 3rd Party Notice
DOCA-Host	3.2.0	• License • 3rd Party Unify Notice
MFT FreeBSD	4.34.0-145	• 3rd Party Notice • License
MFT Linux		• 3rd Party Notice • License
MFT VMware		• 3rd Party Notice • License
MFT Windows		• 3rd Party Notice • License

Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation ("NVIDIA") makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer's own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer's sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer's product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF

ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

Trademarks

NVIDIA and the NVIDIA logo are trademarks and/or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

© Copyright 2025, NVIDIA. PDF Generated on 11/20/2025